
ASSEMBLY INSTRUCTION

HACKNEY

DESK

ITEM CODE 68435



For any assistance with assembly or for missing parts please refer to your receipt

PRE-ASSEMBLY PREPARATION

Before you start:

1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product


2. Take care when lifting. Product should be assembled as near as possible to the point of use

3.Ensure that you have all required contents for complete assembly


4. Always read the assembly instructions carefully before beginning assembly.

5.Keep all hardware parts and packaging out of reach of small children.

6.Do not over tighten the screws and bolts as this may damage the threads









STEP 1:

Open the folding main frame.




STEP 2:

Press the plastic parts of the panel into the corresponding round steel of the metal frame.




STEP 3:

Install an anti-fall device on the underside of the panel and lock it to the wall




ASSEMBLY IS COMPLETE



SAFETY BRACKETS INSTRUCTIONS

- Attach one Mounting Plate to the wall with the Large Screws. Make sure to attach the Mounting Plate into a stud. If mounting into brick or masonry you will need to acquire wall anchors.
- Attach the second Mounting Plate to the furniture frame with the Short Screws.
- 3. Move the furniture to its final position. Thread a Wall Strap through the both Mounting Plates and tighten until snug. Do not over tighten.
- 4. Make sure that the Mounting Plates are firmly attached to the wall and furniture and that the Wall Strap is snug.



To protect your furniture, we suggest the following:

- Avoid placing your furniture in direct sunlight.
- Do not place furniture directly under windows.
- Do not place sharp materials (knife, fork, etc.) directly onto your furniture as sharp material may scrape and damage the finish.
- Do not place material with high temperature directly onto the surface of your furniture.
- Clean up spills quickly. Water left over a prolonged period of time may cause damage. Alcohol, perfume, nail polishes, aftershave and some medication may cause severe finish damage if not cleaned immediately.
- Use a clean, soft, dry, lint free absorbent cloth to clean your furniture. Do not use any detergent as they may contain ingredients that may react and damage the finish.

NOTE: If the above care advise is not adhered to your product warranty may become void