




ASSEMBLY INSTRUCTION

MARSEILLE SOFA TABLE

ITEM CODE 67374

Imported by Amart Furniture Pty Ltd, Qld, Brisbane Australia.
For any assistance with assembly or for missing parts please
phone Amart Furniture , Customer Service Free call 1800 351
084






Imported by Amart Furniture Pty Ltd, Qld, Brisbane Australia.
For any assistance with assembly or for missing parts please phone
Amart Furniture, Customer Service Free call 1800 351 084


PRE-ASSEMBLY PREPARATION

Before you start:

1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product
2. Take care when lifting. Product should be assembled as near as possible to the point of use
3. Ensure that you have all required contents for complete assembly
4. Always read the assembly instructions carefully before beginning assembly.
5. Keep all hardware parts and packaging out of reach of small children.
6. Do not over tighten the screws and bolts as this may damage the threads

| | |
|---|---|
|  |  |
| ALLOW 20 MINUTES | 2 PEOPLE REQUIRED |
|  | |
| TOOLS REQUIRED | |

WARNING



Children have died from furniture tipover.


- ALWAYS secure it with an anchor device.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heavy items down low

**NEVER put a TV
on this furniture**










**This is a permanent label.
Do not remove!**

PARTS LIST




| | |
|---|------------------|
| 1 | TOP |
| 2 | SIDE BOARD |
| 3 | BASE BOARD |
| 4 | REAR FEET |
| 5 | RIGHT FRONT FOOT |
| 6 | LEFT FRONT FOOT |

| | | | |
|--|--|---|--|
| A. BOLT M6X30MM  AX8 | B. BOLT M6X45MM  BX16 | C. METAL CROSS DOWELS M6X10MM  CX4 | D. ALLEN KEY  DX1 |
| E. WALL FIXING <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  M4X 30mm </div> <div style="text-align: center;">  M3.5X14mm </div> <div style="text-align: center;">  EX1 </div> </div> | | | |

1


- Remove drawers from Table top.
- Slide one drawer out. With your left hand, locate the lever in the left side drawer runner and lift (step1), at the same time, with your right hand locate the lever in the right side drawer runner and push down (step2).
- Drawer will be released from runners and can be removed completely (step3).
- Repeat for second drawer.



ITEMS REQUIRED


2

A. BOLT M6X30MM




8PCS

D. ALLEN KEY



1PCS

- Invert Top and place on protected surface
- Attach side boards (2) to top (1) with bolt (A)
- Tighten with Allen Key (D).




3

ITEMS REQUIRED

| | | |
|--|--|---|
| <p>B. BOLT M6X45MM</p>  <p>4PCS</p> | <p>C. METAL CROSS DOWELS M6X10MM</p>  <p>4PCS</p> | <p>D. ALLEN KEY</p>  <p>1PCS</p> |
|--|--|---|


- Attach base board (3) to side boards (2) with bolt (B) and metal cross dowels(C).
- Tighten with Allen Key (D).



ITEMS REQUIRED


4

B. BOLT M6X45MM




12PCS

D. ALLEN KEY




1PCS

- Attach rear feet (4), right front foot (5) and left front foot (6) to the base board (3) with bolt (B).
- Tighten with Allen Key (D).




5

- Align drawer runners and slowly slide drawers in.



ASSEMBLY IS COMPLETE



SAFETY BRACKETS INSTRUCTIONS

1. Attach one Mounting Plate to the wall with the Large Screws. Make sure to attach the Mounting Plate into a stud. If mounting into brick or masonry you will need to acquire wall anchors.
2. Attach the second Mounting Plate to the furniture frame with the Short Screws.
3. Move the furniture to its final position. Thread a Wall Strap through the both Mounting Plates and tighten until snug. Do not over tighten.
4. Make sure that the Mounting Plates are firmly attached to the wall and furniture and that the Wall Strap is snug.

HARDWARE



Mounting Plate x 2




Wall Strap x 1



Large Screw x2



Small Screw x2



CARE AND MAINTENANCE

- A multi-step finish is applied to all our furniture, but all wood comes from nature. Because of this, there will be natural variations in surface texture and grain like knots, mineral streaks and sap runs that may affect the finish. These differences in character are not defects, but distinctions that make each piece of furniture unique.
- Our furniture is built to last. Following these steps for basic care should protect your investment for years to come.
- Dust frequently with a clean damp lint-free cloth. This will help remove abrasive build up which can damage a finish over time.
- Do not place hot objects on any furniture surface. Always use a hot plate or placemat. Laminate and lacquer finishes on table tops provide added scratch and heat resistance to our furniture, but they can still be damaged without proper care.
- Avoid exposing your furniture to strong sunlight, heat outlet, open windows or dampness. Prolonged exposure to direct sunlight can fade the finish of your furniture, while extreme temperature and humidity changes can cause cracking or splitting.
- Do not expose your furniture to any liquids. Never allow water to sit on your furniture. Alcohol, nail polish and perfume are also dangerous as they will dissolve the lacquer finish on contact and may require professional repairs.
- Do not allow plastic to come in direct contact with your furniture. Chemicals in the plastic of placemats etc may soften and mark the finish if left in contact with the furniture for a period of time.