


ASSEMBLY INSTRUCTION

WILKINSON

BUFFET

ITEM CODE: 85252








Imported by JWA Furniture Pty Ltd, Brisbane, QLD, Australia
For any assistance with assembly or for missing parts, please refer to your receipt


PRE-ASSEMBLY PREPARATION

Before you start:

1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product.
2. Take care when lifting. Product should be assembled as near as possible to the point of use.
3. Ensure that you have all required contents for complete assembly.
4. Always read the assembly instructions carefully before beginning assembly.
5. Keep all hardware parts and packaging out of reach of small children.
6. Do not over tighten the screws and bolts as this may damage the threads.
7. Assembly is to be carried out by a competent adult(s) ONLY.
8. During assembly, children should be kept away from the product due to possible risk to injury.
9. Do not use this item if any components are missing or damaged.
10. Please keep the instructions for future reference.

		IF REQUIRED 
Allow 60 min	For 2 person	Low speed (Ø6mm)
  ADDITIONAL TOOLS REQUIRED		

WARNING



Children have died from furniture tipover.


- ALWAYS secure it with an anchor device.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heavy items down low

**NEVER put a TV
on this furniture**




**This is a permanent label.
Do not remove!**

TO USE CAM LOCK FASTENERS



To assemble this product hardware called Cam Lock Fasteners are used. The below is information on how these work.

Cam Locks are fasteners used to join two boards together, usually the edge of one board (A) to the flat side of another board (B).




The Cam Pin is inserted into the flat side of a board, it is important that: The cam pin is kept vertical and is not put in on an angle.



Cam pin is to be inserted up to collar

Too far and it won't catch the Cam Lock (Do Not Overtighten)


Not enough and the resulting product will not be stable.




Now fit the hole in the edge of the joining board over the Cam Pin.



Notice the Cam Lock has a "C" Shaped Back. An arrow or +/- signs on the front indicate the open section on the back of the Cam Pin.



Insert the Cam Lock into the large hole so the opening of the "C" fits over the head of the Cam Pin. You must ensure that the Cam Lock is pushed to the bottom of the hole to catch the top of the Cam Pin.




Use a Flat screwdriver to turn the Cam Lock clockwise one half turn so it locks onto the head of the Cam Pin. Turn only until it is snug. Over tightening could cause the Cam to bend or break. If it will not turn the full amount, turn the Cam Pin out (Counter-clockwise) one full turn, and try the Cam Lock again.

BOX 1:



















- ② x 1
- ③ x 1
- ④ x 1
- ⑥ x 2
- ⑮ x 2
- ⑯ x 2
- ⑰ x 2
- ⑱ x 2
- ⑳ x 2

BOX 2:

- ① x 1
- ⑤ x 1
- ⑦ x 2
- ⑧ x 2
- ⑨ x 4
- ⑩ x 1
- ⑪ x 1
- ⑫ x 1
- ⑬ x 1
- ⑭ x 4










Please note - All Hardware in box 1.

A  M6×33mm 56PCS	B  Ø15×9mm 56PCS	C  Ø6×30mm 28PCS	D  2SETS
E  M4×12mm 1SET	F  M3×12mm 4PCS	G  16PCS	H  M4×14mm 32PCS
I  8PCS	J  M3.5×12mm 39PCS	K  1PC	L  M4×33mm 15PCS
M  M3×14mm 4PCS	N  M4×16mm 6SETS		
CL  L300mm 2PCS	CR  L300mm 2PCS	DL  L300mm 2PCS	DR  L300mm 2PCS




STEP 1







	J x 6PCS
	CL x 1PC
	CR x 1PC

STEP 2






	A x 20PCS
---	------------------


STEP 3



Turn over part ④ to install the other side.

	J x 5PCS
	CL x 1PC
	CR x 1PC



STEP 4



Turn over part ④ to install the other side.

	A x 12PCS
---	-----------

STEP 5




M x 4PCS






D x 2PCS



STEP 6




A x 8PCS



STEP 7




	B x 8PCS
	C x 4PCS

STEP 8




	C x 2PCS
	L x 2PCS

STEP 9



B x 4PCS

STEP 10




B x 2PCS







C x 2PCS

STEP 11




STEP 12




	B x 10PCS
	C x 6PCS


STEP 13



B x 4PCS




STEP 14




B x 2PCS





C x 2PCS





STEP 15




STEP 16




	B x 10PCS
	C x 6PCS



STEP 17




STEP 18



Lock the long side of the "E" L-shaped metal plate to the ① board with the "E" short screw




	A x 6PCS
	E x 1SET



STEP 19





	B x 6PCS
	C x 6PCS





STEP 20




	G x 16PCS
	J x 16PCS


STEP 21






x4

	H x 16PCS
	I x 8PCS
	N x 4SETS




STEP 22



	D x 4PCS
	F x 4PCS
	H x 16PCS

STEP 23


Drill a hole on the wall at the required position for anti-falling device installation.



	K x 1PC
---	----------------


STEP 24

Move the cabinet to the required position, use the "L" long screw to fix the cabinet to the wall.





 L x 1PC

STEP 25







 L x 12PCS

STEP 26




x2


	A x 10PCS
	B x 10PCS
	N x 2SETS






STEP 27




x2




	J x 12PCS
	DL x 2PCS
	DR x 2PCS

STEP 28




STEP 29


Adjusting possibilities



- Lateral adjustment by screw adjustment



- Front-to-back by slackening the hinge-arm mounting screw



- Vertical adjustment via mounting plate (via slots or, if in two pieces, by screws)

To protect your furniture, we suggest the following:

- Avoid placing your furniture in direct sunlight.
- Do not place furniture directly under windows.
- Do not place sharp materials (knife, fork, etc.) directly onto your furniture as sharp material may scrape and damage the finish.
- Do not place material with high temperature directly onto the surface surface of furniture.
- Clean up spills quickly. Water left over a prolonged period of time may cause damage. Alcohol, perfume, nail polishes, aftershave and some medication may cause severe finish damage if not cleaned immediately.
- Use a clean, soft, dry, lint free absorbent cloth to clean your furniture. Do not use any detergent as they may contain ingredients that may react and damage the finish.
- NOTE: If the above care advise is not adhered to your product warranty may become void.