


ASSEMBLY INSTRUCTION YOSHI STOOL ITEM CODE 55472

Imported by Amart Furniture Pty Ltd, Qld, Brisbane Australia. For any assistance with assembly or for missing parts please phone Amart Furniture, Customer Service Free call 1800 351 084



Imported by Amart Furniture Pty Ltd, Qld, Brisbane Australia. For any assistance with assembly or for missing parts please phone Amart Furniture, Customer Service Free call 1800 351 084

PRE-ASSEMBLY PREPARATION


Before you start:


- 1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product
- 2. Take care when lifting. Product should be assembled as near as possible to the point of use
- 3. Ensure that you have all required contents for complete assembly
- 4. Always read the assembly instructions carefully before beginning assembly.
- 5. Keep all hardware parts and packaging out of reach of small children.
- 6. Do not over tighten the screws and bolts as this may damage the threads




PARTS LIST

А	STOOL
В	LEG
С	BOLT - M8 x 16mm
D	ALLENKEY






STEP 1: Attach all 4 legs as shown below



ASSEMBLY IS COMPLETE



Product Care:

Regular Care:

- Protect from direct sunlight
- · Vaccum fabric regularly using low suction or gently brush faux fur
- Avoid exposure to new clothing, cushions or throws as this may lead to dye and permanent staining

Cleaning:

- Do not wash, Do not dry clean, Do not shampoo clean
- · Clean only with hot water extraction machine. Professional cleaning recommended
- Do not use dishwashing liquid or laundry detergent. Use only upholstery detergents
- Do not wet filling
- · Dry in shade away from direct heat and sunlight
- · Allow to dry thoroughly before re-use

Spot Cleaning:

- Do not rub
- · Do not spot clean with any solvent
- Treat spills and stains as soon as possible
- Gently scrape off any soil or blot any liquid from the surface of the fabric before applying cleaner
- Apply proprietary cleaning agents strictly according to instructions
- Do not saturate the fabric or interior with water or other cleaning liquids

Warning:

Apply only water – based soil resist (fabric protection) treatments. Do not use aerosol products

- PILLING IS NOT A FABRIC DEFECT OR FAULT AND IS NOT COVERED BY WARRANTY
- PILLING IS A NORMAL OCCURRENCE CAUSED BY WEAR AND TEAR AND DOES NOT AFFECT THE DURABILITY OR FUNCTIONALITY OF THE FABRIC AND IS EASILY REMOVED

As our timer is supplied from sustainable forests, there will be natural variations in surface texture and grain like knots, mineral streaks and sap runs that may affect the finish. These differences in character are not defects, but distinctions that make each piece of furniture unique.