



ASSEMBLY INSTRUCTION


BARBOSA 2000 OUTDOOR DINING TABLE

ITEM CODE - 53417

Imported by Amart Furniture Pty Ltd, Qld, Brisbane Australia .

For any assistance with assembly or for missing parts please phone

Amart Furniture Ewing road, Customer Service Freecall 1800 009 466



Imported by Amart Furniture Pty Ltd, Qld, Brisbane Australia .


For any assistance with assembly or for missing parts please phone

Amart Furniture Ewing road, Customer Service Freecall 1800 009 466


PRE-ASSEMBLY PREPARATION




Before you start:








1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product.
2. Take care when lifting. Product should be assembled as near as possible to the point of use.
3. Ensure that you have all required contents for complete assembly.
4. Always read the assembly instructions carefully before beginning assembly.
5. Keep all hardware parts and packaging out of reach of small children.
6. Do not over tighten the screws and bolts as this may damage the threads.



PARTS LIST












1. Table Top	
2. Legs × 4	
3. Glass	


A. Bolt  M6*20L*8PCS	B. Bolt  M6*15L*4PCS	C. Spring washer  M6*4PCS	D. Washer  M6*20PCS
E. Nut  M6*8PCS	F. Wrench  M6*1PC	G. Hexagan Key  M6*1PC	

Step 1 :

ITEMS REQUIRED


1. Table Top 	2. Legs x 4 	A. Bolt  M6*20L*8PCS	B. Bolt  M6*15L*4PCS	C. Spring washer  M6*4PCS
D. Washer  M6*20PCS	E. Nut  M6*8PCS	F. Wrench  M6*1PC	G. Hexagan Key  M6*1PC	

- Align holes in Table Top (1) over threads in Table Legs (2)
- Attach Table Legs (2) to Table Top (1) using Bolt (A & B) Spring Washer (C) Washer (D) and Nut (E) as shown in the below diagram .
- Tighten with Wrench (F) and Hexagan Key (G) .Be careful not to over tighten the bolts.




Step 2 :


ITEMS REQUIRED



- Turn table frame over onto feet
- Place Glass (3) on top of table
- Glass is secured on table with suckers .



ASSEMBLY IS COMPLETE



Care and maintenance



Cushions

- ☒ Direct exposure to the sun's harmful UV rays is likely to cause rapid colour fading to fabrics.
- ☒ To ensure product longevity it is recommended outdoor products are not left permanently exposed to the elements.

Timbers

- ☒ Prolonged exposure of timber items to the elements may cause premature deterioration.
- ☒ Regular vacuuming and dusting of items is recommended.
- ☒ Timber needs regular oiling -please contact store of purchase for further details.
- ☒ Minor cracking of timber is a natural process and will not compromise the strength of the timber.

Wicker

- ☒ Regular vacuuming and dusting of items is recommended.
- ☒ If weave on wicker becomes lacerated/damaged, Do not pull on as this may cause unravelling.
- ☒ Prolonged exposure to the elements may cause colour fading.

Glass

- ☒ If the glass is chipped or broken, stop using the product and consult place of purchase .
- ☒ Do not drop, drag or strike glass .
- ☒ Do not sit or stand upon the glass surface .
- ☒ Do not place very hot or cold items on the glass surface unless adequately thick table mats are used to prevent such items coming in contact with the glass .
- ☒ Do not place heavy objects on glass .
- ☒ Avoid scratching the glass or using as a chopping surface .
- ☒ Do not strike the glass with hard or pointed items .
- ☒ When cleaning the glass panels use a damp cloth with washing up liquid or soft soap if necessary. Do not use washing powders or any other substances containing abrasives since these may scratch the glass.