
ASSEMBLY INSTRUCTION

LACHEN
GAMING TABLE
ITEM CODE 70445







PRE-ASSEMBLY PREPARATION


Before you start:

- Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product
- 2. Take care when lifting. Product should be assembled as near as possible to the point of use
- 3. Ensure that you have all required contents for complete assembly
- 4. Always read the assembly instructions carefully before beginning assembly.
- 5. Keep all hardware parts and packaging out of reach of small children.
- 6.Do not over tighten the screws and bolts as this may damage the threads






PARTS LIST




1	Desktop panel
P1	Left Frame
P2	Right Frame
P3	Connection Pipe

P4	Support Pipe
P5	Rack




STEP 1:

Insert the fitting H into the P1 and P2.




STEP 2:

- 1. Assemble the P3 to P1 and P2 with fitting C.
- 2. Then assemble the P4 with P1 and P2 with fitting A.




STEP 3:

Assemble the Panel 1 onto the metal frame with fitting B.




STEP 4:

Install the rack G at right side of the desktop with fitting C and D.




STEP 5:

Put the fitting E and F accordingly as the below picture.



STEP 6:

- 1. Install the belt K onto the desktop with fitting D.
- 2. Insert the fitting J into the wall, and connect it with the belt by fitting I.



STEP 7:

Assembly complete!



To protect your furniture, we suggest the following:

- · Avoid placing your furniture in direct sunlight.
- Do not place furniture directly under windows.
- Do not place sharp materials (knife, fork, etc.) directly onto your furniture as sharp material may scrape and damage the finish.
- Do not place material with high temperature directly onto the surface of your furniture.
- Clean up spills quickly. Water left over a prolonged period of time may cause damage. Alcohol, perfume, nail polishes, aftershave and some medication may cause severe finish damage if not cleaned immediately.
- Use a clean, soft, dry, lint free absorbent cloth to clean your furniture. Do not use any detergent as they may contain ingredients that may react and damage the finish.

NOTE: If the above care advise is not adhered to your product warranty may become void