




ASSEMBLY INSTRUCTION

CHLOE 3 SEAT RHF CHAISE

ITEM CODE: 72896

Imported by Amart Furniture Pty Ltd, Qld, Brisbane Australia.

For any assistance with assembly or for missing parts please phone Amart Furniture, Customer Service Free call 1800 351 084



Imported by Amart Furniture Pty Ltd, Qld, Brisbane Australia.

For any assistance with assembly or for missing parts please phone Amart Furniture, Customer Service Free call 1800 351 084

Before you start:

1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product
2. Take care when lifting. Product should be assembled as near as possible to the point of use
3. Ensure that you have all required contents for complete assembly
4. Always read the assembly instructions carefully before beginning assembly.
5. Keep all hardware parts and packaging out of reach of small children.
6. Do not over tighten the screws and bolts as this may damage the threads.












ALLOW **10** MINUTES




PEOPLE REQUIRED

PARTS LIST


NO.	Picture	Description	One arm loveseat	One arm chaise
A	 H:17CM	Metal Leg	4pcs	3pcs
B	 M8x20MM	Bolt	8pcs	6pcs
C	 M8	Allen Key	1pc	1pc
D	 H:17CM	Metal Leg	N/A	1pc
E	 M5x30MM	Screws	N/A	4pcs
F	 16MM	Washer	8pcs	6pcs
G	 13MM	Washer	N/A	4pcs
H		Plastic Washer	1pc	1pc
I	 H:17CM	Plastic Leg	1pc	1pc

Hardware and legs are located in dust cover zipper compartment underneath the lounge.




ASSEMBLY INSTRUCTIONS


STEP 1: Turn over onto blanket or carpet to ensure no damage to item. Remove legs and hardware from dust cover located underneath the lounge. Attach metal legs (A), bolts (B) and washers(F) with Allen key provided (C) and place in to each corner of the sofa. Attach plastic leg (I) and washer (H) in to the middle of the sofa turning to secure tightly.



STEP 2: Attach Metal legs (A), bolts (B) and washers(F) with Allen key provided (C) and place in to each corner of the chaise. Attach plastic leg (I) and washer (H) in to the middle of the chaise turning to secure tightly. Attach metal leg (D), Screws (E) and washers (G) and place in to the corner as below, turning to secure tightly.



STEP 4: Secure pieces together by connecting both alligator clips in to each other securely as per image below. Assembly complete.



Fabric Care and Maintenance



REGULAR CARE:

- Protect from direct sunlight
- Vacuum regularly using low suction
- Rotate reversible cushions regularly

CLEANING:

- Do not remove cushion covers for separate cleaning even though they may have zippers
- Do not wash, Do not dry clean, Do not shampoo clean
- Clean with hot water extraction machine. Professional cleaning recommended
- Do not use dishwashing liquid or laundry detergent
- Use only upholstery detergents
- Do not wet filling
- Dry in shade away from direct heat and sunlight
- Allow to dry thoroughly before re-use

SPOT CLEANING:

- Do not rub
- Do not spot clean with any solvent
- Treat spills and stains as soon as possible
- Gently scrape off any soil or mop any liquid from the surface of the fabric
- Apply proprietary cleaning agents strictly according to instructions to remove the residue of the spill
- Do not saturate the fabric or interior with water or other cleaning liquids

WARNING:

Apply only water-based soil resist (fabric protection) treatments. Do not use aerosol products

* PILLING IS NOT A FABRIC DEFECT OR FAULT AND IS NOT COVERED BY WARRANTY

* PILLING IS A NORMAL OCCURRENCE CAUSED BY WEAR AND TEAR AND DOES NOT AFFECT THE DURABILITY OR FUNCTIONALITY OF THE FABRIC AND IS EASILY REMOVED