
ASSEMBLY INSTRUCTION Smithton

Laundry Hamper
ITEM CODE 70345 / 70344






Imported by JWA Furniture Pty Ltd, Qld, Brisbane Australia. For any assistance with assembly or for missing parts please refer to your receipt

PRE-ASSEMBLY PREPARATION

Before you start:

- 1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product
- 2.Take care when lifting . Product should be assembled as near as possible to the point of use
- 3. Ensure that you have all required contents for complete assembly
- 4. Always read the assembly instructions carefully before beginning assembly.
- 5. Keep all hardware parts and packaging out of reach of small children.
- 6.Do not over tighten the screws and bolts as this may damage the threads



PARTS LIST В

PARTS LIST

NO.	ITEM	QTY
D	() () ()	8PCS


NO.	ITEM	QTY
Α	SIDE PANEL	2 PCS
В	FABRIC BAG	1 PC
C 1	SUPPORT BAR	2 PCS
C2°	SUPPORT BAR	2 PCS

STEP 1: C2 needs to go on the inside arm of A X2 STEP 2: C1 needs to go on the outside arm of A X2


STEP 3: В STEP 4:

X4

STEP 5:



ASSEMBLY IS COMPLETE



To protect your furniture, we suggest the following:

- Avoid placing your furniture in direct sunlight.
- Do not place furniture directly under windows.
- Do not place sharp materials (knife, fork, etc.) directly onto your furniture as sharp material may scrape and damage the finish.
- Do not place material with high temperature directly onto the surface of your furniture.
- Clean up spills quickly. Water left over a prolonged period of time may cause damage. Alcohol, perfume, nail polishes, aftershave and some medication may cause severe finish damage if not cleaned immediately.
- Use a clean, soft, dry, lint free absorbent cloth to clean your furniture. Do not use any detergent as they may contain ingredients that may react and damage the finish.

NOTE: If the above care advise is not adhered to your product warranty may become void