


# ASSEMBLY INSTRUCTION COPELAND TRUNDLE ITEM CODE 75429

Imported by Amart Furniture Pty Ltd.Qld.Brisbane Australia.

For any assistance with assembly or for missing parts please phone

Amart Furniture, Customer Service Free call 1800 351 084




Imported by Amart Furniture Pty Ltd.Qld.Brisbane Australia. For any assistance with assembly or for missing parts please phone Amart Furniture Customer Service Free call 1800 351 084


#### PRE-ASSEMBLY PREPARATION

### Before you start:


- 1. Choose a clean,level.spacious assembly area. Avoid hard surfaces that may damage the product
- 2. Take care when lifting. Product should be assembled as near as possible to the point of use
- 3. Ensure that you have all required contents for complete assembly.
- 4. Always read the assembly instructions carefully before beginning assembly.
- 5. Keep all hardware parts and packaging out of reach of small children.
- 6. Do not over tighten the screws and bolts as this may damage the threads



## **PARTS LIST**




C1	End Rail
C2	Side Rail
C3	Slat
C4	Base Plate




75429


Step 1: Use a Phillips Head Screwdriver to assemble the Bracket(G) to the End Rail(C1) with Screw(C). Use a Phillips Head Screwdriver to assemble the Wheel(H) to the Base Plate(C4)with Screw(C).




Step 2: Use a Hex Key(E) to assemble the Base Plate(C4) to the End Rail(C1) with Bolt(B).



Step 3: Use a Hex Key(F) to assemble the End Rail(C1) to Side Rail(C2) with Bolt(A).



Step 4: Use a Phillips Head Screwdriver to tighten the Slats(C3) to the End Rail(C1) and Side Rails(C2) with Screw(D).



75429

#### PRODUCT CARE:

To protect your furniture, we suggest the following:

- · Avoid placing your furniture in direct sunlight.
- · Do not place furniture directly under windows.
- Do not place sharp materials (knife, fork, etc.) directly onto your furniture as sharp material may scrape and damage the finish.
- Do not place material with high temperature directly onto the surface of your furniture.
- Clean up spills quickly. Water left over a prolonged period of time may cause damage. Alcohol, perfume, nail polishes, aftershave and some medication may cause severe finish damage if not cleaned immediately.
- Use a clean, soft, dry, lint free absorbent cloth to clean your furniture. Do not use any detergent as they may contain ingredients that may react and damage the finish.
- NOTE: If the above care advise is not adhered to your product warranty may become void