
ASSEMBLY INSTRUCTION SHERMAN

5 TIER BOOKCASE

ITEM CODE 79027




Imported by JWA Furniture Pty Ltd, Qld, Brisbane Australia. For any assistance with assembly or for missing parts please refer to your receipt


PRE-ASSEMBLY PREPARATION

Before you start:

- 1.Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product
- 2. Take care when lifting. Product should be assembled as near as possible to the point of use
- 3. Ensure that you have all required contents for complete assembly
- 4. Always read the assembly instructions carefully before beginning assembly.
- 5. Keep all hardware parts and packaging out of reach of small children.
- 6.Do not over tighten the screws and bolts as this may damage the threads










PARTS LIST

NO.	ITEM	QTY	NO.	ITEM	QTY
Α		1PC	D	Φ 6*35	20PCS
В	Φ 6*12	4PCS	Е	() TATE	2PCS
С	Φ 6*25	40PCS			


NO.	ITEM	QTY	NO.	ITEM	QTY
1	SHELF PANEL	3 PCS	4	METAL LEG	2 PCS
2	SHELF PANEL	2 PCS	(5)	SUPPORT METAL	2 PCS
3	METAL CROSSING BAR	10 PCS			








ASSEMBLY IS COMPLETE



CAUTION: Always Lift Your Furniture When Moving /Relocating - Do Not Drag. Dragging Can Cause The Legs To Bend/Break.

SAFETY BRACKETS INSTRUCTIONS

- 1. Attach the strap to the metal leg of furniture.
- 2. Move the furniture to its final position. Attach the strap to the wall with the screw. If mounting into brick or masonry you will need to acquire wall anchors.
- 3. Make sure that the strap is firmly attached to the wall and furniture and that the wall strap is snug.



To protect your furniture, we suggest the following:

- Avoid placing your furniture in direct sunlight.
- Do not place furniture directly under windows.
- Do not place sharp materials (knife, fork, etc.) directly onto your furniture as sharp material may scrape and damage the finish.
- Do not place material with high temperature directly onto the surface of your furniture.
- Clean up spills quickly. Water left over a prolonged period of time may cause damage. Alcohol, perfume, nail polishes, aftershave and some medication may cause severe finish damage if not cleaned immediately.
- Use a clean, soft, dry, lint free absorbent cloth to clean your furniture. Do not use any detergent as they may contain ingredients that may react and damage the finish.

NOTE: If the above care advise is not adhered to your product warranty may become void