
ASSEMBLY INSTRUCTION

AMELIE

7 Tier Bookcase

ITEM CODE 75121




Imported by JWA Furniture Pty Ltd, Qld, Brisbane Australia. For any assistance with assembly or for missing parts please refer to your receipt


PRE-ASSEMBLY PREPARATION

Before you start:

- 1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product
- 2. Take care when lifting. Product should be assembled as near as possible to the point of use
- 3. Ensure that you have all required contents for complete assembly
- 4. Always read the assembly instructions carefully before beginning assembly.
- 5. Keep all hardware parts and packaging out of reach of small children.
- 6. Do not over tighten the screws and bolts as this may damage the threads
- 7. Assembly is to be carried out by a competent adult(s) ONLY
- 8. During assembly, children should be kept away from the product due to possible risk to injury.
- 9. Do not use this item if any components are missing or damaged.
- 10. Please keep the instructions for future reference.









STEP 1:

1. Attach panels 3 to main frame P1 with part A using allen key F.




STEP 2:

1. Attach main frame P2 to panels 3 with part A using allen key F.




STEP 3:

1. Attach panel 2 to main frames P1 and P2 with part A using allen key F.




STEP 4:

1. Insert panel 1 into main frame P2.




STEP 5

1. Attach panel 1 to main frames P1 and P2 with parts A and B using allen key F.




STEP 6

1. Attach panels 4 to main frame P 2 with part A using allen key F.



STEP 7


1. Attach main frame P3 to panel s 1, 2 and 4 with part A using allen key F.




STEP 8

Install Tip Kit

- Attach part E to the back of panel 1 with part D.
 Attach part E to the wall with part C.



STEP 9 Assembly complete!



8

To protect your furniture, we suggest the following:

- Avoid placing your furniture in direct sunlight.
- Do not place furniture directly under windows.
- Do not place sharp materials (knife, fork, etc.) directly onto your furniture as sharp material may scrape and damage the finish.
- Do not place material with high temperature directly onto the surface of your furniture.
- Clean up spills quickly. Water left over a prolonged period of time may cause damage. Alcohol, perfume, nail polishes, aftershave and some medication may cause severe finish damage if not cleaned immediately.
- Use a clean, soft, dry, lint free absorbent cloth to clean your furniture. Do not use any detergent as they may contain ingredients that may react and damage the finish.

NOTE: If the above care advise is not adhered to your product warranty may become void