

WARNING

**Serious or fatal injuries may occur from furniture toppling over.
To help avoid this please follow the below recommendations:**

- Install the provided "Tipping Kit" as per the instructions
- Never allow children to climb on or hang off of any part of this product
- Unless specifically designed to accommodate, do not set TVs or other heavy objects on top of this product


If this product has drawers:

- Place the heaviest items in lowest drawers
- Do not open more than 1 drawer at a time as this may cause the product to become unbalanced
- Do not tamper with or remove any drawer interlocking/running system

**Note: The use of the provided "Tipping Kit" may reduce but not necessarily eliminate the risk of furniture toppling over.
Please use this product with caution.**

This is a permanent label. Do not attempt to remove!

ASSEMBLY IS COMPLETE



ASSEMBLY

- When properly installed this kit may reduce the risk of the furniture toppling over.
- A teather 'a' comes pre assembled to the back top edge of the furniture using the screw 'd' and washer 'c'.
- Put the furniture into position and evaluate the correct position to fix the other end of the teather to the wall. Be sure to use the appropriate wall anchor for your wall type.

WARNING

To reduce the likelihood of this furniture toppling over it is recommended that you **Securely attach the anti-tilt straps or brackets provided to your wall using appropriate fixings.**

IMPORTANT

- **DO NOT** place toys or other child appealing items on top of this furniture
- **AVOID** fully opening all the drawers at the same time
- **DO NOT ALLOW** small children to climb onto drawers, shelves or to swing from open doors


CAUTION

For your safety when attaching the anti-tilt fixings;

- Check for any electrical wires or plumbing inside the wall before drilling holes (if you are unsure, please seek professional advice from a qualified tradesman).
- Walls are constructed from different materials eg; Masonry (solid brick) or plaster board lined cavity walls (hollow). It is important that you use the appropriate wall fixings for your wall type.

Your local hardware store will have the necessary drills and fixings and can offer advice if needed

ASSEMBLY IS COMPLETE





CARE INSTRUCTIONS FOR TIMBER ITEMS

A multi-step finish is applied to all of our furniture, but all wood comes from nature. Because of this, there will be natural variations in surface texture and grain like knots, mineral streaks and sap runs that may affect the finish. These differences in character are not defects, but distinctions that make each piece of furniture unique.

Our furniture is built to last. Following these steps for basic care should protect your investment for years to come.

- Dust frequently with a clean damp lint-free cloth. This will help remove abrasive build up which can damage a finish over time.
- Do not place hot objects on any furniture surface. Always use a hot plate or placemat. Laminate and lacquer finishes on tabletops provide added scratch and heat resistance to our furniture, but they can still be damaged without proper care.
- Avoid exposing your furniture to strong sunlight, heat outlet, open windows or dampness. Prolonged exposure to direct sunlight can fade the finish of your furniture, while extreme temperature and humidity changes can cause cracking or splitting.
- Do not expose your furniture to any liquids. Never allow water to sit on your furniture. Alcohol, nail polish and perfume are also dangerous as they will dissolve the lacquer finish on contact and may require professional repairs.
- Do not allow plastic to come in direct contact with your furniture. Chemicals in the plastic of placemats etc. may soften and mark the finish if left in contact with the furniture for a period of time.