




ASSEMBLY INSTRUCTION
SAN LUCAS - OUTDOOR DINING CHAIR
ITEM CODE - 72296

Imported by Amart Furniture Pty Ltd, Qld, Brisbane Australia .
For any assistance with assembly or for missing parts please phone
Amart Furniture , Customer Service Freecall 1800 351 084





Imported by Amart Furniture Pty Ltd, Qld, Brisbane Australia .
For any assistance with assembly or for missing parts please phone
Amart Furniture, Customer Service Freecall 1800 351 084


PRE-ASSEMBLY PREPARATION







Before you start:





1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product.
2. Take care when lifting. Product should be assembled as near as possible to the point of use.
3. Ensure that you have all required contents for complete assembly.
4. Always read the assembly instructions carefully before beginning assembly.
5. Keep all hardware parts and packaging out of reach of small children.
6. Do not over tighten the screws and bolts as this may damage the threads.

	
ALLOW 10 MINUTES	PEOPLE REQUIRED
ADDITIONAL TOOLS REQUIRED	

PARTS LIST









1. Right arm		1PC	2. Left arm		1PC
3. Backrest		1PC	4. Seat		1PC
5. Cushion		1PC	6. Back cushion		1PC


A. Bolt	B. Bolt	C. Hexagon Key	D. Shim
			
M6*20*2PCS	M6*35*8PCS	M6*1PC	M6*10PCS

Step 1:

ITEMS REQUIRED


1. Right arm 1PC 	2. Left arm 1PC 	4. Seat 1PC 
B. Bolt  M6*35*8PCS	D. Shim  M6*8PCS	C. Hexagon Key  M6*1PC

- Attach seat (4) to right arm (1) and left arm (2) using bolt (B) with shim (D) .
- Insert all bolts before fully tightening .
- Tighten with hexagon key (C) .




Step 2:

ITEMS REQUIRED






- Attach backrest (3) to seat (4) .
- Insert all bolts before fully tightening .




Step 3:


ITEMS REQUIRED

A.	Bolt	D.	Shim	C.	Hexagon Key
					
M6*20*2PCS		M6*2PCS		M6*1PC	

- Attach backrest (3) to left arm (2) and right arm (1) using bolt (A) with shim (D) .
- Insert all bolts before fully tightening .
- Tighten with hexagon key (C) .



ASSEMBLY IS COMPLETE



Care and maintenance



Aluminium

- ☒ Item is designed for use outdoors. However we do not recommend leaving this product outside when not in use. To preserve the life of this item, avoid prolonged exposure to the elements & store inside/under cover or use an outdoor cover.
- ☒ DO NOT allow the furniture to be left in the rain or left wet for extended periods of time.
- ☒ Wipe furniture Dry immediately after it becoming wet.
- ☒ DO NOT clean your furniture down with any harsh solvents, abrasives or chemicals.
- ☒ To remove dirt and grime, simply rinse with fresh water or periodically clean using a sponge and mild detergent solution as required

Timbers

- ☒ Prolonged exposure of timber items to the elements may cause premature deterioration
- ☒ Regular vacuuming and dusting of items is recommended
- ☒ Timber requires regular maintenance and upkeep. Please use the appropriate product to maintain your product (oil/wax), if you are unsure of which product is suitable – please contact the store that you purchased from
- ☒ Minor cracking of timber is a natural process and will not compromise the strength of the timber
- ☒ To extend the life of your product the use of an Amart approved Outdoor Furniture Cover is highly recommended.
- ☒ Please contact store of purchase for further details.

Cushions

- ☒ Direct exposure to the Sun's harmful UV rays is likely to cause rapid colour fading to fabrics. For best results we recommend avoiding exposure to direct sunlight
- ☒ To ensure product longevity it is recommended outdoor products are not left permanently exposed to the elements
- ☒ Spot clean using mild detergent and damp cloth. Dry flat in shade
- ☒ Do not unzip
- ☒ Do not put in washing machine
- ☒ Do not tumble dry
- ☒ Do not bleach
- ☒ Do not dry clean
- ☒ Cool iron only

Warning

Do not:

- ☒ Use chair/stool as a ladder
- ☒ Climb on the chair/stool
- ☒ Stand on the foot-rest of the chair, as this could lead to unbalanced and overturning