
ASSEMBLY INSTRUCTION

RAY LAMP TABLE

ITEM CODE 82198 \ 82199






Imported by JWA Furniture Pty Ltd, Brisbane Qld, Australia. For any assistance with assembly or for missing parts please refer to your receipt

PRE-ASSEMBLY PREPARATION


Before you start:


- 1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product
- 2. Take care when lifting. Product should be assembled as near as possible to the point of use
- 3. Ensure that you have all required contents for complete assembly
- 4. Always read the assembly instructions carefully before beginning assembly.
- 5. Keep all hardware parts and packaging out of reach of small children.
- 6. Do not over tighten the screws and bolts as this may damage the threads
- 7. Assembly is to be carried out by a competent adult(s) ONLY
- 8. During assembly, children should be kept away from the product due to possible risk to injury.
- 9. Do not use this item if any components are missing or damaged.
- 10. Please keep the instructions for future reference.







CAM LOCK INSTALL METHOD AS FOLLOWS









PARTS LIST




Panel No	Panel Sizes	Quantity
1	500*500*16	1
2	434*249*16	4




STEP 1: Fix dowel (B) and cam pin (A) to panel (1)(2).



STEP 52: Fix panel (2) with cam lock (C).



STEP 3: Fix panel (1)to panel (2) with cam lock (C). C=8




To protect your furniture, we suggest the following:

- Avoid placing your furniture in direct sunlight.
- Do not place furniture directly under windows.
- Do not place sharp materials (knife, fork, etc.) directly onto your furniture as sharp material may scrape and damage the finish.
- Do not place material with high temperature directly onto the surface of your furniture.
- Clean up spills quickly. Water left over a prolonged period of time may cause damage. Alcohol, perfume, nail polishes, aftershave and some medication may cause severe finish damage if not cleaned immediately.
- Use a clean, soft, dry, lint free absorbent cloth to clean your furniture. Do not use any detergent as they may contain ingredients that may react and damage the finish.

NOTE: If the above care advise is not adhered to your product warranty may become void

包装图



包装尺寸

Panel No		Panel Sizes	Quantity
3	护角	50*50*50	8
4	泡沫	500*500*10	2
5	泡沫	540*70*40	2
6	泡沫	500*70*20	2
7	泡沫	500*65*30	1
8	三角泡沫	146*146*15	4
9	纸盒	内径590*550*80	1