


# Amart

## ASSEMBLY INSTRUCTION

### ANGLESEA 4 PIECE OUTDOOR LOUNGE SETTING

ITEM CODE - 81283




Imported by Amart Furniture Pty Ltd, Qld, Brisbane Australia .  
For any assistance with assembly or for missing parts please phone  
Amart Furniture, Customer Service Freecall 1800 351 084


## PRE-ASSEMBLY PREPARATION




### Before you start:

1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product.
2. Take care when lifting. Product should be assembled as near as possible to the point of use.
3. Ensure that you have all required contents for complete assembly.
4. Always read the assembly instructions carefully before beginning assembly.
5. Keep all hardware parts and packaging out of reach of small children.
6. Do not over tighten the screws and bolts as this may damage the threads.





PARTS LIST



1. sofa		2PCS	2. Cushion		2PCS
3. Back Cushion		2PCS			

**ASSEMBLY IS COMPLETE**






# Amart

## ASSEMBLY INSTRUCTION

### ANGLESEA 4 PIECE OUTDOOR LOUNGE SETTING

ITEM CODE - 81283




Imported by Amart Furniture Pty Ltd, Qld, Brisbane Australia .  
For any assistance with assembly or for missing parts please phone  
Amart Furniture, Customer Service Freecall 1800 351 084


## PRE-ASSEMBLY PREPARATION




### Before you start:

1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product.
2. Take care when lifting. Product should be assembled as near as possible to the point of use.
3. Ensure that you have all required contents for complete assembly.
4. Always read the assembly instructions carefully before beginning assembly.
5. Keep all hardware parts and packaging out of reach of small children.
6. Do not over tighten the screws and bolts as this may damage the threads.




PARTS LIST




4. sofa  1PC	2. Cushion  3PCS
3. Back Cushion  3PCS	

**ASSEMBLY IS COMPLETE**








# Amart

## ASSEMBLY INSTRUCTION

### ANGLESEA 4 PIECE OUTDOOR LOUNGE SETTING

ITEM CODE - 81283




Imported by Amart Furniture Pty Ltd, Qld, Brisbane Australia .  
For any assistance with assembly or for missing parts please phone  
Amart Furniture, Customer Service Freecall 1800 351 084


## PRE-ASSEMBLY PREPARATION




### Before you start:






1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product.
2. Take care when lifting. Product should be assembled as near as possible to the point of use.
3. Ensure that you have all required contents for complete assembly.
4. Always read the assembly instructions carefully before beginning assembly.
5. Keep all hardware parts and packaging out of reach of small children.
6. Do not over tighten the screws and bolts as this may damage the threads.



## PARTS LIST








5	Table Top		1PC	6	Fixed Link		1PC
7	Legs		4PCS				


A.	Bolt		M6*20*8PCS	B.	Bolt		M6*30*4PCS	C.	Washer		M6*12PCS	D.	Allen Key		M6*1PC
E.	Protective Pad		4PCS												

# Step 1:

## ITEMS REQUIRED





5. Table Top 1PC 	7. Legs 4PCS 	
A. Bolt  M6*15*8PCS	D. Allen Key  M6*1PC	C. Washer  M6*8PCS

- Attach legs (7) to table top (5) using bolt (A) with washer (C) .
- Insert all bolts before fully tightening .




## Step 2:

### ITEMS REQUIRED


<p>6. Fixed Link 1PC</p> 		
<p>B. Bolt</p>  <p>M6*30*4PCS</p>	<p>D. Allen Key</p>  <p>M6*1PC</p>	<p>C. Washer</p>  <p>M6*4PCS</p>

- Attach fixed link (6) to legs (7) using bolt (B) with washer (C) .
- Insert all bolts before fully tightening .
- Tighten with allen key (D) .




## Step 3:


### ITEMS REQUIRED



- Last attach the protective pad(E) under the adjusting knob.



**ASSEMBLY IS COMPLETE**



---

## Aluminium

- ☒ Item is designed for use outdoors. However we do not recommend leaving this product outside when not in use. To preserve the life of this item, avoid prolonged exposure to the elements & store inside/under cover or use an outdoor cover.
- ☒ DO NOT allow the furniture to be left in the rain or left wet for extended periods of time.
- ☒ Wipe furniture Dry immediately after it becoming wet.
- ☒ DO NOT clean your furniture down with any harsh solvents, abrasives or chemicals.
- ☒ To remove dirt and grime, simply rinse with fresh water or periodically clean using a sponge and mild detergent solution as required

## Cushions

- ☒ Direct exposure to the Sun's harmful UV rays is likely to cause rapid colour fading to fabrics. For best results we recommend avoiding exposure to direct sunlight
- ☒ To ensure product longevity it is recommended outdoor products are not left permanently exposed to the elements
- ☒ Spot clean using mild detergent and damp cloth. Dry flat in shade
- ☒ Do not unzip
- ☒ Do not put in washing machine
- ☒ Do not tumble dry
- ☒ Do not bleach
- ☒ Do not dry clean
- ☒ Cool iron only

## Weathergrain

- ☒ Item is designed for use outdoors. However we do not recommend leaving this product outside when not in use.
- ☒ To preserve the life of this item, avoid prolonged exposure to the elements & store inside/under cover or use an outdoor cover.
- ☒ DO NOT place heavy or pointed objects on the surface of the weathergrain while using your outdoor furniture.
- ☒ DO NOT place magnifying objects on top of weathergrain in direct sunlight. Items such as wine glasses, reading glasses, etc. This may cause your product to burn.
- ☒ Leaving your outdoor furniture outside in direct sunlight may cause your product to become weak and brittle. Your product may also experience colour fading.
- ☒ DO NOT place hot objects on the surface of the weathergrain as it may damage the product.
- ☒ Wipe the surface of the weathergrain with mild soap and water.
- ☒ Do not clean your weathergrain item with solvents or any other aggressive chemicals.