

ASSEMBLY INSTRUCTION

DELEON

Dining Table

ITEM CODE 81562





PRE-ASSEMBLY PREPARATION


Before you start:

- 1.Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product
- 2.Take care when lifting. Product should be assembled as near as possible to the point of use
- 3. Ensure that you have all required contents for complete assembly
- 4. Always read the assembly instructions carefully before beginning assembly.
- 5. Keep all hardware parts and packaging out of reach of small children.
- 6.Do not over tighten the screws and bolts as this may damage the threads






PARTS LIST




1	Top Panel
2	Metal Frame




STEP 1:

1.Place metal frame 2 as the instruction shown. Twist screw A 80%.




STEP 2:

1.Place rest metal frame 2 as the instruction shown. Twist screw A 80%.




STEP 3:

1. Attach intersection of frame 2 by part A. Twist screw A 80%.




STEP 4:

1. Twist all the screws A 100%.



STEP 5:

1.Screw B to frame 2.



STEP 6:

1.Assembly complete!



To protect your furniture, we suggest the following:

- · Avoid placing your furniture in direct sunlight.
- Do not place furniture directly under windows.
- Do not place sharp materials (knife, fork, etc.) directly onto your furniture as sharp material may scrape and damage the finish.
- Do not place material with high temperature directly onto the surface of your furniture.
- Clean up spills quickly. Water left over a prolonged period of time may cause damage. Alcohol, perfume, nail polishes, aftershave and some medication may cause severe finish damage if not cleaned immediately.
- Use a clean, soft, dry, lint free absorbent cloth to clean your furniture. Do not use any detergent as they may contain ingredients that may react and damage the finish.

NOTE: If the above care advise is not adhered to your product warranty may become void