![Amart logo]

ASSEMBLY INSTRUCTION
## MACKINLEY DINING TABLE
ITEM CODE 80467

2000

1000

760

Imported by Amart Furniture Pty Ltd.Qld.Brisbane Australia.
For any assistance with assembly or for missing parts please phone Amart Furniture
Customer Service Free call 1800 351 084

80467

PRE-ASSEMBLY PREPARATION

Before you start:

1. Choose a clean,level.spacious assembly area.Avoid hard surfaces that may
    damage the product
2. Take care when lifting.Product should be assembled as near as possible to
    the point of use
3. Ensure that you have all required contents for complete assembly.
4. Always read the assembly instructions carefully before beginning assembly.
5. Keep all hardware parts and packaging out of reach of small children.
6. Do not over tighten the screws and bolts as this may damage the threads

|	
ALLOW 20 MINUTES	4 PEOPLE REQUIRED

80467

PARTS LIST

C1	Table Top
C2	Leg

| A.Bolt M8x20	☐	B.Hex Key 5MM	☐
8PCS		1PCE	

80467

Step 1: Use a Hex Key(B) to tighten the leg(C2) to the Table Top(C1) with Bolt(A).


Step 2: Using caution and 4 people, carefully turn the table upright onto its legs. Assembly complete.

Use caution when turning the table onto its legs. Do not apply any pressure the legs, by doing so may cause damage to the legs.

80467

Note -
Do not drag the furniture as this may cause damage to the legs. Instead, use 2 persons to lift carefully from either end.

80467

PRODUCT CARE:

To protect your furniture, we suggest the following:

- Avoid placing your furniture in direct sunlight.

- Do not place furniture directly under windows.

- Do not place sharp materials (knife, fork, etc.) directly onto your furniture as sharp material may scrape and damage the finish.

- Do not place material with high temperature directly onto the surface of your furniture.

- Clean up spills quickly. Water left over a prolonged period of time may cause damage. Alcohol, perfume, nail polishes, aftershave and some medication may cause severe finish damage if not cleaned immediately.

- Use a clean, soft, dry, lint free absorbent cloth to clean your furniture. Do not use any detergent as they may contain ingredients that may react and damage the finish.

- NOTE: If the above care advise is not adhered to your product warranty may become void