

ASSEMBLY INSTRUCTION CUEVAS ACCENT CHAIR 79989






Imported by JWA Furniture Pty Ltd, Qld, Brisbane Australia, For any assistance with assembly or for missing parts please refer to your receipt


PRE-ASSEMBLY PREPARATION

Before you start:


- 1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product
- 2. Take care when lifting. Product should be assembled as near as possible to the point of use
- 3. Ensure that you have all required contents for complete assembly
- 4. Always read the assembly instructions carefully before beginning assembly.
- 5. Keep all hardware parts and packaging out of reach of small children.
- 6. Do not over tighten the screws and bolts as this may damage the threads
- 7. Assembly is to be carried out by a competent adult(s) <u>ONLY</u>
- 8. During assembly, children should be kept away from the product due to possible risk to injury.
- 9. Do not use this item if any components are missing or damaged.
- 10. Please keep the instructions for future reference.




PARTS LIST



Part	ltem	QTY
1	Chair	1
2	Leg	4





PRODUCTCARE:

If the glass is chipped or broken, stop using the produ ct and consult place of purchase

WARNING:

.Donot place very hotor cold items on the glass surface unless adequ atelythick table mats are used to prevent such items coming in contact W ith theg lass

DOnotsitorstandupontheqlasssurface

DOnotusetheglassasachoppingSurface

DOnotstriketheglassWithhardorpointeditemS

When cleaning the glasspane is use a damp clothor leather With Washing up liquidors of the solution of the s

O ther su bs tan ces contain in g abrasives since these m ay scratch the glas S

0 ur fu rn iture is built to last. F ollowin g th ese steps for basic care shouldprotectyourinvestmentforyearstocome

D ust frequently W ith a clean damp lint-free clo th. This will help rem oveabrasive build up Which can damage a finish OVertime

Avoid exposing your furniture to strong sunlight, heat outlet, open

W in dOw S or dampness. Prolonged expo su re to direct sunligh t can fade th efinish of your furniture, while extreme temperature and humidity chang escan cause crackin g Or splitting

D O n ot allow plas tic to come in direct contact W ith your furniture .

C hemicals in the plastic of placemats etc. may soften and mark the

finish ifleftin contact with the furniture for a period of tim e