



Imported by Amart Furniture Pty Ltd, Qld, Brisbane
Australia. For any assistance with assembly or for missing
parts please phone Amart Furniture, Customer Service
Free Call 1800 351 084

PRE-ASSEMBLY PREPARATION






Before you start:


1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product
2. Take care when lifting. Product be assembled as near as possible to the point of use
3. Ensure that you have all required contents for complete assembly
4. Always read the assembly instructions carefully before beginning assembly
5. Keep all hardware parts and packaging out of small children
6. Do not over tighten the screws and bolts as this may damage the threads

	
ALLOW 5 MINUTES	2 PEOPLE REQUIRED


PARTS LIST

A




<p>A.1PC</p>  <p>Seat</p>	<p>B.1PC</p>  <p>Leg</p>
--	---

STEP 1 Screw feet (B) into base of seat(A)



ASSEMBLY IS COMPLETE



Fabric Care and Maintenance



REGULAR CARE:

- Protect from direct sunlight

CLEANING:

they may have zippers

recommended

SPOT CLEANING:

fabric

remove the residue of the spill

Do not saturate the fabric or interior with water or other cleaning liquids

WARNING:

Apply only water-based soil resist (fabric protection) treatments. Do not use aerosol products

* PILLING IS NOT A FABRIC DEFECT OR FAULT AND IS NOT COVERED BY WARRANTY

* PILLING IS A NORMAL OCCURRENCE CAUSED BY WEAR AND TEAR AND DOES NOT AFFECT THE DURABILITY OR FUNCTIONALITY OF THE FABRIC AND IS EASILY REMOVED