




Proudly supporting Ronald McDonald House Charities Australia.

**ASSEMBLY INSTRUCTION
SANTO ANDRE OFFICE DESK
ITEM CODE - 74553**

Imported by Amart Furniture Pty Ltd, Qld, Brisbane Australia.
For any assistance to assembly or for missing parts please phone Amart Furniture, Customer Service Freecall 1800 351 084.






Imported by Amart Furniture Pty Ltd, Brisbane QLD Australia.
For any assistance with assembly or for missing parts please phone
Amart Furniture Ewing Road, Customer Service Free call 1800 351 084

PRE-ASSEMBLY PREPARATION


Before you start:







1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product.
2. Take care when lifting. Product should be assembled as near as possible to the point of use.
3. Ensure that you have all required contents for complete assembly.
4. Always read the assembly instructions carefully before beginning assembly.
5. Keep all hardware parts and packaging out of reach of small children.
6. Do not over tighten the screws and bolts as this may damage the threads.

| | |
|--|---|
|  |  |
| ALLOW 30 MINUTES | PEOPLE REQUIRED |
|  | |
| ADDITIONAL TOOLS REQUIRED | |

|  WARNING | | |
|--|---|---|
|  |  | <p>Children have died from furniture tipover.</p> <ul style="list-style-type: none">• ALWAYS secure it with an anchor device.• NEVER allow children to stand, climb or hang on drawers, doors, or shelves.• NEVER open more than one drawer at a time.• Place heavy items down low <p>NEVER put a TV on this furniture </p> <p><small>This is a permanent label. Do not remove!</small></p> |


| PARTS LIST | | |
|------------|---------------|-----|
| No | Description | Qty |
| 1 | Table top | 1Pc |
| 2 | Side leg | 1Pc |
| 3 | Apron | 1Pc |
| 4 | Left side leg | 1Pc |
| 5 | Side right | 1Pc |
| 6 | Shelf upper | 1Pc |
| 7 | Shelf middle | 1Pc |
| 8 | Shelf bottom | 1Pc |
| 9 | Back | 1Pc |




| HARDWARE PARTS | | |
|---|---|--|
| a. Wood dowel Ø 8x25mm 16 pcs  | b. Bolt Ø 6x30mm 21 pcs  | c. Washer 21 pcs  |
| d. Screw Ø 3x15mm 2 pcs  | e. Shelf support 4 pcs  | f. Hexagon key N4 1 pc  |

STEP 1: Assembling the bookcase leg.

1.1. Insert the dowels to the shelves.





1.2. Mounting the shelves to the sides of bookcase.




**1.3. Sliding the back panel to the back side of bookcase.
Screws the back panel to the shelf upper.**

Note: 2 pre-drilled holes on the back panel must be at the upper direction part. They will use to screw the back with the shelf upper.





STEP 2: Insert the dowels to the side leg, bookcase leg and the apron.



ATTENTION !


THE SIDE LEG AND THE BOOKCASE LEG CAN BE REVERSIBLE.
PLEASE SELECT WHICH DIRECTION WILL BE SUITABLE FOR YOUR ROOM
BEFORE GOING TO NEXT STEP.

IF YOU WANT THE BOOKCASE TO BE AT THE RIGHT SIDE AS SHOWN IN
PAGE 1, PLEASE CONTINUE TO STEP 3.


IF YOU WANT THE BOOKCASE TO BE AT THE LEFT SIDE ,
PLEASE CONTINUE TO STEP 4.

STEP 3: Assembling the bookcase leg at the RIGHT side.


3.1. Mounting the bookcase leg and the apron to the table top.





3.2. Mounting the side leg to the table top and the apron.



3.3. Insert the shelf support in the indicated holes for the shelf, middle .



3.4. Place the shelf, middle on to the shelves support in the bookcase leg.
Place the slats panel in the window on table top.




The Madang desk with bookcase at RIGHT side.


FINISH.

STEP 4: Assembling the bookcase leg at the LEFT side..


4.1. Mounting the bookcase leg and the apron to the table top.





4.2. Mounting the side leg to the table top and the apron.



4.3. Insert the shelf support in the indicated holes for the shelf, middle .



4.4. Place the shelf, middle on to the shelves support in the bookcase leg.
Place the slats panel in the window on table top.




FINISH.

The Madang desk with bookcase at LEFT side.

SAFETY BRACKETS INSTRUCTIONS
IF YOUR PRODUCT REQUIRES THE ADDITION OF SAFETY
BRACKETS OR "TIPPING KITS" PLEASE INCLUDE THESE
INSTRUCTIONS BELOW.

1. Attach one Mounting Plate to the wall with the Large Screws. Make sure to attach the Mounting Plate into a stud. If mounting into brick or masonry you will need to acquire wall anchors.
2. Attach the second Mounting Plate to the furniture frame with the Short Screws.
3. Move the furniture to its final position. Thread a Wall Strap through the both Mounting Plates and tighten until snug. Do not over tighten.
4. Make sure that the Mounting Plates are firmly attached to the wall and furniture and that the Wall Strap is snug.

HARDWARE



Mounting Plate x 2




Wall Strap x 1



Large Screw x 2




Small Screw x 2



ASSEMBLY IS COMPLETE

**! As wall materials vary,
screws for fixing to wall
are not included.**

**For advice on suitable
screw systems, contact
your local specialised
dealer.**



CARE AND MAINTENANCE

PRODUCT CARE FOR HI-GLOSS ITEMS

- Hi-gloss lacquered furniture is more sensitive to marks and scratching than some other furniture products. It is important to exercise caution and care to maximise the life and beauty of this product
- Following the below simple guidelines when using your hi-gloss product will protect your investment for years to come
- Dust frequently with a clean damp lint-free cloth. This will help remove abrasive build up which can damage a finish over time
- Avoid using chemicals or solvents when cleaning the product
- Do not place hot objects on any furniture surface. Always use a hot plate or placemat. Lacquer finishes provide added scratch and heat resistance to our furniture, but they can still be damaged without proper care
- Avoid exposing your furniture to strong sunlight, heat outlet, open windows or dampness. Prolonged exposure to direct sunlight can fade the finish of your furniture, while extreme temperature and humidity changes can cause cracking or splitting
- Do not expose your furniture to any liquids. Never allow water to sit on your furniture. Alcohol, nail polish and perfume are also dangerous as they will dissolve the lacquer finish on contact and may require professional repairs
- Do not allow plastic to come in direct contact with your furniture. Chemicals in the plastic of placemats etc. may soften and mark the finish if left in contact with the furniture for a period of time
- Avoid placing sharp or rough objects on the surface of your furniture. These may scratch the surface of the product
- When moving your furniture, do not drag it across the floor. This may damage the product. Instead use two (2) people to lift carefully from either end