



CARE AND MAINTENANCE

CHAIR, DO NOT:

- Use chair as a ladder
- Climb on the chair

• Stand on the foot-rest of the chair, as this could lead to the stool becoming unbalanced and overturning

DINING TABLES, DO NOT:

- Do not drag this may cause damage to the legs
- Do not sit on the sides as this may cause the product to tip

TIMBERS:

- Prolonged exposure of timber items to the elements may cause premature deterioration
- Regular vacuuming and dusting of items is recommended

• Timber requires regular maintenance and upkeep. Please use the appropriate product to maintain your product (oil\wax), if you are unsure of which product is suitable – please contact the store that you purchased from

• Minor cracking of timber is a natural process and will not compromise the strength of the timber

• To extend the life of your product the use of an Amart approved Outdoor Furniture Cover is highly recommended. Please contact store of purchase for further details