





Imported by Amart Furniture Pty Ltd, Qld, Brisbane Australia.
for any assistance to assembly or for missing parts please phone
Amart Furniture, Customer Service Freecall 1800 351 084


PRE-ASSEMBLY PREPARATION

BEFORE YOU START :

1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product
2. Take care when lifting. Product should be assembled as near as possible to the point of use
3. Ensure that you have all required contents for complete assembly
4. Always read the assembly instructions carefully before beginning assembly.
5. Keep all hardware parts and packaging out of reach of small children.
6. Do not over tighten the screws and bolts as this may damage the threads

	
ALLOW 20 MINUTES	2 PEOPLE REQUIRED
ADDITIONAL TOOLS REQUIRED	


PARTS LIST




1	TOP	1 PC	2	LEGS	1 PC
3	MOUNTING PLATES	1 PC	4	INTERMEDIATE BOX	1 PC
5		CROSS BRACE	8 PCS		


A	BOLTS	B	BOLTS	C	BOLTS	D	FLAT WASHER	E	SPRING WASHER	F	KEY	G	SPANNER
													
M8x35: 8 pcs		M8x70: 4 pcs		M8x35: 8 pcs		M8x2x19: 20 pcs		M8x1.2x13: 20 pcs		M4x59: 1 pc		M13: 1 pc	


- Step 1 :**
- Attach the Intermediate Box (4) to the Cross Brace (5). Using Bolts (A), Spring Washer (E), Flat Washer (D) and tighten with Spanner (G).




A BOLTS	D FLAT WASHER	E SPRING WASHER	G SPANNER
			
M8x35: 4 pcs	M8x2x19: 4 pcs	M8x1.2x13: 4 pcs	M13: 1 pc



- Step 2 :**
- Attach the Intermediate Box (4) to the Cross Brace (5). Using Bolts (A), Spring Washer (E), Flat Washer (D) and tighten with Spanner (G).




A BOLTS  M8x35: 4 pcs	D FLAT WASHER  M8x2x19: 4 pcs	E SPRING WASHER  M8x1.2x13: 4 pcs	G SPANNER  M13: 1 pc
--	--	--	--


- Step 3 :**
- Attach the legs (2) to Cross Brace (5). Using Bolts (B), Spring Washer (E), Flat Washer (D) and tighten with Key (F).




B	BOLTS	D	FLAT WASHER	E	SPRING WASHER	F	KEY
							
M8x70: 4 pcs		M8x2x19: 4 pcs		M8x1.2x13: 4 pcs		M4x59: 1 pc	

Step 4 :
- Attach the Mounting Plate (3) to Cross Brace (5). Using Bolts (C), Spring Washer (E), Flat Washer (D) and tighten with Key (F).




C	BOLTS	D	FLAT WASHER	E	SPRING WASHER	F	KEY
							
M8x35: 4 pcs		M8x2x19: 4 pcs		M8x1.2x13: 4 pcs		M4x59: 1 pc	


Step 5 :
- Attach the Mounting Plate (3) to Tabletop (1). Using Bolts (C), Spring Washer (E), Flat Washer (D) and tighten with Key (F).



NOTE: ALWAYS USE TWO PEOPLE WHEN TURNING THE TABLE OVER

C	BOLTS	D	FLAT WASHER	E	SPRING WASHER	F	KEY
							
M8x35: 4 pcs		M8x2x19: 4 pcs		M8x1.2x13: 4 pcs		M4x59: 1 pc	

ASSEMBLY COMPLETE



DO NOT PUSH OR DRAG THIS TABLE - by doing so, it may cause damage to the legs.

DO NOT SIT OR LEAN ON THE EDGE OF THE TABLE - this may cause the table to tip to one side.



Product : **CHARLSBOURG 1200 ROUND DINING TABLE**
Item Code : **83215**

Product Care:

As you timber is supplied from sustainable forests there will be natural variations in surface texture and grain like knots, mineral streaks and sap runs that may affect the finish. These differences in character are not defects, but distinctions that make each piece of furniture unique. Our furniture is built to last. Following these steps for basic care should protect your investment for years to come.

- Dust frequently with a clean damp lint-free cloth. This will help remove abrasive build up which can damage a finish over time.
- Do not place hot objects on any furniture surface. Always use a hot plate or placemat. Laminate and lacquer finishes on table tops provide added scratch and heat resistance to our furniture, but they can still be damaged without proper care.
- Avoid exposing your furniture to strong sunlight, heat outlet, open windows or dampness. Prolonged exposure to direct sunlight can fade the finish of your furniture, while extreme temperature and humidity changes can cause cracking or splitting.
- Do not expose your furniture to any liquids. Never allow water to sit on your furniture. Alcohol, nail polish and perfume are also dangerous as they will dissolve the lacquer finish on contact and may require professional repairs.
- Do not allow plastic to come in direct contact with your furniture. Chemicals in the plastic of placemats etc may soften and mark the finish if left in contact with the furniture for a period of time.