


ASSEMBLY INSTRUCTION

MAHONEY ENTERTAINMENT UNIT

Item Code 83631






Imported by JWA Furniture Pty Ltd, Qld, Brisbane Australia.
For any assistance with assembly or for missing parts please refer to your receipt



PRE-ASSEMBLY PREPARATION

Before you start:
















1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product
2. Take care when lifting. Product should be assembled as near as possible to the point of use
3. Ensure that you have all required contents for complete assembly
4. Always read the assembly instructions carefully before beginning assembly
5. Keep all hardware parts and packaging out of reach of small children
6. Do not over tighten the screws and bolts as this may damage the threads
7. Assembly is to be carried out by a competent adult(s) ONLY
8. During assembly, children should be kept away from the product due to possible risk to injury
9. Do not use this item if any components are missing or damaged
10. Please keep the instructions for future reference.

		
Allow 30 min	For 1 person	Additional tools required

⚠ WARNING


		<p>Children have died from furniture tipover.</p> <ul style="list-style-type: none"> • NEVER allow children to stand, climb or hang on drawers, doors, or shelves. • ALWAYS secure your television with an anchor device or mount the television on a wall. <p style="color: red; font-weight: bold;">This is a permanent label. Do not remove!</p>
---	---	--

PARTS LIST

A Cam Bolt x12pcs 	B Cam Lock x12pcs 	C Wooden Dowel M6x30mmx20pcs 	E Handle Set x2pcs 
H Foot Pad Φ3x25mm x 4pcs 	I Plastic Wedge Set x 6pcs 	J Screw M6x40mmx8pcs 	K Sticker Φ18x8pcs 
L Allen key M4 x 1pc 	M Washer Φ4x12mm x 2pcs 	N Safe Strap x 2pcs 	Q Screw M4x14mmx10pcs 
R Metal Sheet x 2pcs 	X Wall Anchor M6x30mm x 2pcs 	Y Wall Screw M4x35mm x 2pcs 	


PARTS LIST

1	Side Panel(Left) x 1 pc	2	Side Panel(Right) x 1 pc
3	Top Panel x 1 pc	4	Bottom Panel x 1 pc
5	Shelf Panel x 1 pc	6	Back Panel x 1 pc
7	Door Panel x 2 pcs	8	Wooden Leg x 4pcs
9	Middle Wooden Leg x 2pcs	10	Median Septum(Left) x 1pc
11	Median Septum(Right) x 1pc		




STEP 1:

- Prepare a protected surface with a blanket or cardboard.
- Assemble the shelf panel(5) with the left&right median panel (10),(11)by hardware (A,B,C).




STEP 2:

- Assemble the median panel(10),(11), the left&right side panel (1),(2) with top panel (3) by hardware (A,B,C,K).




STEP 3:

- Attach the back panel (6) with chest frame.




STEP 4:

- Assemble the bottom panel (4) with the chest frame by hardware (C,J,L); Then, assemble the hardware (R) on the bottom panel (4) by hardware (Q).




STEP 5:

- Assemble the handle(E) with door panel (7).




STEP 6:

- Assemble the leg(8),(9);Then,attach the foot pad (H); Attach the hardware (I) on the back.




STEP 7:

- Assemble two doors (7).




Finished



SAFETY BRACKETS INSTRUCTIONS


STEP 1:

- Secure the safety strap(N) by hardware (M,Q).



STEP 2:

- Secure the safety strap(N) onto wall by hardware (M,X,Y).



PRODUCT CARE:

To protect your furniture, we suggest the following:

- Avoid placing your furniture in direct sunlight.
- Do not place furniture directly under windows.
- Do not place sharp materials (knife, fork, etc.) directly onto your furniture as sharp material may scrape and damage the finish.
- Do not place material with high temperature directly onto the surface of your furniture.
- Clean up spills quickly. Water left over a prolonged period of time may cause damage. Alcohol, perfume, nail polishes, aftershave and some medication may cause severe finish damage if not cleaned immediately.
- Use a clean, soft, dry, lint free absorbent cloth to clean your furniture. Do not use any detergent as they may contain ingredients that may react and damage the finish.