




ASSEMBLY INSTRUCTION

CHRYSTELLE DRESSER WITH MIRROR

ITEM CODE 80348


Imported by Amart Furniture Pty Ltd, Qld, Brisbane Australia.
For any assistance with assembly or for missing parts please phone
Amart Furniture, Customer Service Free call 1800 351 084




PRE-ASSEMBLY PREPARATION

Before you start:

1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product
2. Take care when lifting. Product should be assembled as near as possible to the point of use
3. Ensure that you have all required contents for complete assembly
4. Always read the assembly instructions carefully before beginning assembly.
5. Keep all hardware parts and packaging out of reach of small children.
6. Do not over tighten the screws and bolts as this may damage the threads

	 x2
ALLOW 20 MINUTES	2 PEOPLE REQUIRED
	
ADDITIONAL TOOL REQUIRED (not include)	

WARNING



Children have died from furniture tipover.


- ALWAYS secure it with an anchor device.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heavy items down low

NEVER put a TV on this furniture



**This is a permanent label.
Do not remove!**


PARTS LIST




NO.	PARTS LIST	QTY
1	DRESSER	1 pc
2	MIRROR	1 pc
3	MIRROR LEG	2 pcs

NO.	HARDWARE LIST	QTY
A	 BOLT M6 35MM	8 pcs
B	 Flat washer M6Ø14	8 pcs
C	 Allen Key 4mm	1 pc
D	 Adhesive felt pad Ø20x5mm	8 pcs

STEP 1: With two people carefully lay the Dresser on to a sheet or piece of cardboard.
Attach adhesive felt pad (D) onto the legs.
With two people carefully stand the Dresser upright.




STEP 2: Attach Mirror legs (3) to Mirror (2) and Dresser (1) with bolt (A) and washer (B), tighten it up by using an allen key (C)




Fixing the strap to the wall

As the wall materials vary, screws for fixing to the wall are not included.

For advice on suitable screws systems, contact your local specialised dealer.



ASSEMBLY IS COMPLETE



IMPORTANT: CARE GUIDE FOR YOUR TIMBER FURNITURE

Congratulations! You have just purchased a quality product from Amart furniture

Please read on for important information regarding your purchase...

A multi-step finish is applied to all our furniture, but all wood comes from nature. Because of this, there will be natural variations in surface texture and grain like knots, mineral streaks and sap runs that may affect the finish.

These differences in character are not defects, but distinctions that make each piece of furniture unique.

Our furniture is built to last. Following these steps, basic care should protect your investment for years to come.

- Dust frequently with a clean damp lint-free cloth. This will help remove abrasive build up which can damage a finish over time.
- Do not place hot objects on any furniture surface. Always use a suitable placemat. Laminate and lacquer finishes on table tops provide added scratch and heat resistance to our furniture, but they can still be damaged without proper care.
- Avoid exposing your furniture to strong sunlight, heat, open windows or dampness. Prolonged exposure to direct sunlight can fade the finish of your furniture, and sudden extreme temperature and humidity changes can cause cracking or splitting.
- Do not expose your furniture to any liquids. Never allow water to sit on your furniture. Alcohol, nail polish and perfume are also dangerous as they will dissolve the lacquer finish on contact and may require professional repairs.
- Do not allow plastic to come in direct contact with your furniture. Chemicals in the plastic of placemats ect may soften and mark the finish if left in contact with the furniture for a period of time.

GLASS:

- If the glass is chipped or broken, stop using the product and consult place of purchase
- WARNING:**
- Do not place very hot or cold items on the glass surface unless adequately thick table mats are used to prevent such items coming in contact with the glass
 - Do not sit or stand upon the glass surface
 - Do not use the glass as a chopping surface
 - Do not strike the glass with hard or pointed items
 - When cleaning the glass panels use a damp cloth or leather with washing up liquid or soft soap if necessary. Do not use washing powders or any other substances containing abrasives since these may scratch the glass.

