




# ASSEMBLY INSTRUCTION

## SHADOW2 1635 SQUARE OUTDOOR TABLE

### ITEM CODE 51382

Imported by Amart Furniture Pty Ltd, Qld, Brisbane Australia.  
For any assistance with assembly or for missing parts please phone  
Amart Furniture, Customer Service Free call 1800 009 466





Imported by Amart Furniture Pty Ltd, Qld, Brisbane Australia.  
For any assistance with assembly or for missing parts please phone  
Amart Furniture, Customer Service Free call 1800 009 466


# PRE-ASSEMBLY PREPARATION

## Before you start:






1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product
2. Take care when lifting. Product should be assembled as near as possible to the point of use
3. Ensure that you have all required contents for complete assembly
4. Always read the assembly instructions carefully before beginning assembly.
5. Keep all hardware parts and packaging out of reach of small children.
6. Do not over tighten the screws and bolts as this may damage the threads

	
ALLOW 15 MINUTES	2 PEOPLE REQUIRED
ADDITIONAL TOOL REQUIRED (not include)	


# PARTS LIST




NO	PART LIST	QT'Y
1	Table top	1 PC
2	Granite top	1 PC
3	Legs	4 PCS

<p><b>A</b> Bolt</p>  <p>M8 x 60mm 8xA</p>	<p><b>B</b> Spring washer</p>  <p>M8 x Ø11 x 1,5mm 8xB</p>	<p><b>C</b> Flat washer</p>  <p>M8 x Ø16 x 1mm 8xC</p>
<p><b>D</b> Allen key</p>  <p>4mm 1xD</p>	<p><b>E</b> Adhesive felt pad</p>  <p>100 x 100 x 5mm 4xE</p>	

Step 1: Using two people carefully turn the table top ( 1 ) upside down. Attach table top ( 1 ) and legs ( 3 ) as shown in diagram using bolts (A) and washers (B&C). Tighten using the allen key (D) provided, then attach adhesive felt pad (E) onto the legs.




Step2: Carefully turn the table upright and then place the granite stone on table top as shown in diagram.



**IMPORTANT NOTE:**  
ALWAYS USE TWO PEOPLE WHEN TURNING THE TABLE OVER

ASSEMBLY IS COMPLETE



**CAUTION:**  
ALWAYS LIFT YOUR PRODUCT WHEN MOVING/RELOCATING. DO NOT DRAG.  
DRAGGING CAN CAUSE DAMAGE TO THE LEGS.

**IMPORTANT NOTE:**  
THE FELT PAD ON THE BOTTOM OF THE CHAIR LEG IS SUBJECT TO WEAR. AMART  
RECOMMENDS REGULAR ROUTINE CHECKS AND REPLACEMENT WHERE NECESSARY.

# **IMPORTANT: CARE GUIDE FOR YOUR TIMBER FURNITURE**

*Congratulations! You have just purchased a quality product from Amart Furniture. Please read on for important information regarding your purchase...*

## **TIMBERS:**

To ensure the longevity and maintain the appearance of your outdoor timber furniture, please follow these care instructions:

- 1. Usage and Storage:** This furniture is designed for outdoor use, but prolonged exposure to harsh weather conditions can affect its integrity and appearance. To extend its life, avoid leaving the furniture exposed during extreme weather. Store it indoors or under cover when not in use or use a high-quality outdoor cover (do not store on grass).
- 2. Moisture Management:** Timber can be susceptible to moisture damage, including warping and mould growth. Avoid allowing the furniture to remain wet for long periods. Wipe off any spills immediately, and if the furniture becomes wet from rain, allow it to dry completely before covering it.
- 3. Protection from the Elements:** Different timbers have varying levels of natural resistance to the elements:  
Acacia: While naturally durable, acacia benefits from periodic oiling to maintain its colour and to protect it against moisture and UV damage. It is recommended to oil acacia every 6-12 months.
- 4. Avoid Exposure to Chlorine & Salt Water:** Chlorinated and saltwater environments can accelerate deterioration of timber. If your furniture is near a pool or coastal area, clean it more frequently and use protective covers when not in use.
- 5. Cleaning:** Clean your furniture with care. Avoid using harsh solvents, abrasives, or chemicals. To remove dirt and grime, rinse with fresh water and dry thoroughly. For a deeper clean, use a sponge and a mild detergent solution as needed. Abrasive cleaners will scratch/damage the surface.

Timber expands and contracts with fluctuations in temperature and humidity. This will result in minor cracking but will not compromise the structural integrity of the product. By following the simple steps above, you will help prevent this cracking as well as keep your timber furniture in great condition, ensuring it remains a beautiful and functional part of your outdoor space.

## **GRANITE:**

Do not place very hot or cold items on the granite surface unless adequately thick table mats are used to prevent such items coming in contact with the granite

Do not sit or stand upon the granite surface

Do not use the granite as a chopping surface

Do not strike the granite with hard or pointed items

When cleaning the granite panels use a damp cloth with washing up liquid or soft soap if necessary. Do not use washing powders or any other substances containing abrasives since these may scratch the granite.

