




ASSEMBLY INSTRUCTION

REPLICA ADIRONDACK OUTDOOR CHAIR

ITEM CODE 60266

Imported by Amart Furniture Pty Ltd, Qld, Brisbane Australia.
For any assistance with assembly or for missing parts please phone
Amart Furniture, Customer Service Free call 1800 009 466






Imported by Amart Furniture Pty Ltd, Qld, Brisbane Australia.
For any assistance with assembly or for missing parts please phone
Amart Furniture, Customer Service Free call 1800 009 466


PRE-ASSEMBLY PREPARATION

Before you start:










1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product
2. Take care when lifting. Product should be assembled as near as possible to the point of use
3. Ensure that you have all required contents for complete assembly
4. Always read the assembly instructions carefully before beginning assembly.
5. Keep all hardware parts and packaging out of reach of small children.
6. Do not over tighten the screws and bolts as this may damage the threads

	 x1
ALLOW 20 MINUTES	1 PEOPLE REQUIRED
	
ADDITIONAL TOOL REQUIRED (not include)	


PARTS LIST




NO	PART LIST	QT'Y
1	Seat	1 PC
2	Front Legs	2 PCS
3	Front Brace	1 PCS
4	Arms	2 PCS
5	Back	1 PC

A Screw  M4 x 40mm 2xA	B Bolt  M6 x 15mm 2xB	C Bolt  M6 x 50mm 6xC
D Allen key  4mm 1xD	E Bolt  M6 x 35mm 2xE	F Screw  M6 x 40mm 4xF
G Flat washer  M6 x Ø16 x 1mm 10xG	H Bolt  M8 x 50mm 2xH	I Adhesive felt pad  50 x 20 x 5mm 4xI


STEP 1: Using the bolts (C) and flat washers (G) attach the front legs (2) to the seat (1) with allen key (D) as show the diagram.




STEP 2: Using the screws (A) attach the front brace (3) to the front legs (2) by screwdriver as show the diagram.




STEP 3: Using the screws (F) attach the back (5) to the seat (1) with allen key as show the diagram.




STEP 4: Using the bolts (B), (E) and flat washers (G) attach the arms (4) to the front legs (2) with allen key as show the diagram.



STEP 5: Using the bolts (H) and flat washers (G) attach the back to the arms (4) with allen key as show the diagram



STEP 6: Attach adhesive felt pad (I) onto the legs.



IMPORTANT NOTE:

BEFORE FINALLY TIGHTENING THE BOLTS, PLACE THE ASSEMBLED CHAIR UPRIGHT ON A LEVEL SURFACE AND SIT CAREFULLY ON THE CHAIR TO ENSURE THE CHAIR LEGS ARE ALIGNED AND LEVEL. THEN TIGHTEN ALL BOLTS AND YOUR CHAIR IS READY TO USE.

ASSEMBLY IS COMPLETE



CAUTION:
DO NOT

- USE CHAIR/STOOL AS A LADDER
- CLIMB ON THE CHAIR/STOOL
- STAND ON THE FOOT REST OF THE CHAIR, AS THIS COULD LEAD TO THE STOOL BECOMING UNBALANCED AND OVERTURNING.

IMPORTANT NOTE:

THE FELT PAD ON THE BOTTOM OF THE CHAIR LEG IS SUBJECT TO WEAR. AMART RECOMMENDS REGULAR ROUTINE CHECKS AND REPLACEMENT WHERE NECCESARY.

IMPORTANT: CARE GUIDE FOR YOUR TIMBER FURNITURE

Congratulations! You have just purchased a quality product from Amart Furniture. Please read on for important information regarding your purchase...

TIMBERS:

To ensure the longevity and maintain the appearance of your outdoor timber furniture, please follow these care instructions:

- 1. Usage and Storage:** This furniture is designed for outdoor use, but prolonged exposure to harsh weather conditions can affect its integrity and appearance. To extend its life, avoid leaving the furniture exposed during extreme weather. Store it indoors or under cover when not in use or use a high-quality outdoor cover (do not store on grass).
- 2. Moisture Management:** Timber can be susceptible to moisture damage, including warping and mould growth. Avoid allowing the furniture to remain wet for long periods. Wipe off any spills immediately, and if the furniture becomes wet from rain, allow it to dry completely before covering it.
- 3. Protection from the Elements:** Different timbers have varying levels of natural resistance to the elements:

Acacia: While naturally durable, acacia benefits from periodic oiling to maintain its colour and to protect it against moisture and UV damage. It is recommended to oil acacia every 6-12 months.

- 4. Avoid Exposure to Chlorine & Salt Water:** Chlorinated and saltwater environments can accelerate deterioration of timber. If your furniture is near a pool or coastal area, clean it more frequently and use protective covers when not in use.
- 5. Cleaning:** Clean your furniture with care. Avoid using harsh solvents, abrasives, or chemicals. To remove dirt and grime, rinse with fresh water and dry thoroughly. For a deeper clean, use a sponge and a mild detergent solution as needed. Abrasive cleaners will scratch/damage the surface.

Timber expands and contracts with fluctuations in temperature and humidity. This will result in minor cracking but will not compromise the structural integrity of the product. By following the simple steps above, you will help prevent this cracking as well as keep your timber furniture in great condition, ensuring it remains a beautiful and functional part of your outdoor space.

