


ASSEMBLY INSTRUCTION
GRIMES GAMING OFFICE CHAIR
ITEM CODE 84109





Imported by JWA Furniture Pty Ltd, Qld, Brisbane Australia.
For any assistance with assembly or for missing parts please refer to your receipt


PRE-ASSEMBLY PREPARATION

Before you start:


1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product
2. Take care when lifting. Product should be assembled as near as possible to the point of use
3. Ensure that you have all required contents for complete assembly
4. Always read the assembly instructions carefully before beginning assembly.
5. Keep all hardware parts and packaging out of reach of small children.
6. Do not over tighten the screws and bolts as this may damage the threads

	
ALLOW 20 MINUTES	PEOPLE REQUIRED

PARTS LIST



1	BACKREST
2	SEAT CUSHION
3	LEFT ARMREST
4	RIGHT ARMREST
5	MECHANISM
6	DUST COVER
7	BASE
A	CASTOR



1-1pc
78*53*7CM



2-1pc
53*52*7CM



3-1pc
47*32*8CM



4-1pc
47*32*8CM



5-1pc
28*18*0.2CM




6-1pc
Φ 5*4.3*26.5CM




7-1pc
320#



A*5pc
Φ 50MM



B*4
M6*18MM



C*8
M8*25MM




D*8
Φ 15*18*7MM




E*1
3*7 CM


STEP 1: Push castors **A** into place in wheel base **7**. Turn and apply pressure at the same time to each castor until it slots into place. Attach gas lift **6** to wheel base **7**, as shown. Ensure part **6** is secure and unable to be removed.



STEP 2: Fix part **5** to underside of part **2** using bolts **B** and allen key **E**, as shown.




STEP 3: Fix parts **3** and **4** to parts **1** and **2** using bolts **C** and allen key **E**, as shown.




STEP 4: Push caps **D** in to cover the bolts, as shown.



STEP 5: Fix assembled chair seat to base, as shown. **Please note: You may need to carefully sit on the assembled gaming chair and use your weight to lock the gas lift fully into place. Please note: the maximum recommended weight for this chair is 120kg.**



Height Adjustment Instructions: To lower the height of the chair sit in chair and pull lever upwards. To increase height of chair remove yourself from chair and pull the lever upwards.



Tilt Adjustment Instructions: To use the tilt function on your chair, firstly turn the knob clockwise to activate. Then while sitting in the chair, pull the lever outwards to unlock the tilt function and slowly and carefully lean backwards to apply pressure to the backrest, your chair should now tilt back and forth freely. **Please note: the further you turn the knob clockwise, the more tilt the chair will achieve. The further you turn the knob anti-clockwise, the less tilt the chair will achieve.** To lock the tilt function, apply no pressure to the backrest so you are in the standard upright position. Then push the lever back inwards towards the chair. The chair should now be locked in the upright position and pressure to the backrest should not make the chair swing back.



ASSEMBLY IS COMPLETE



CARE AND MAINTENANCE

REGULAR CARE:

- Protect from direct sunlight
- Vacuum regularly using low suction
- Rotate reversible cushions regularly
- Avoid exposure to new clothing, cushions or throws as this may lead to dye transfer and permanent staining

CLEANING:

- Do not remove cushion covers for separate cleaning even though they may have zippers
- Do not wash, Do not dry clean, Do not shampoo clean
- Clean only with hot water extraction machine. Professional cleaning recommended
- Do not use dish washing liquid or laundry detergent. Use only upholstery detergents
- Do not wet filling
- Dry in shade away from direct heat and sunlight
- Allow to dry thoroughly before re-use

SPOT CLEANING:

- Do not rub
- Do not spot clean with any solvent
- Treat spills and stains as soon as possible
- Gently scrape off any soil or blot any liquid from the surface of the fabric before applying cleaner
- Apply proprietary cleaning agents strictly according to instructions to remove the residue of the spill
- Do not saturate the fabric or interior with water or other cleaning liquids

WARNING:

Apply only water-based soil resist (fabric protection) treatments. Do not use aerosol products

* PILLING IS NOT A FABRIC DEFECT OR FAULT AND IS NOT COVERED BY WARRANTY

* PILLING IS A NORMAL OCCURRENCE CAUSED BY WEAR AND TEAR AND DOES NOT AFFECT THE DURABILITY OR FUNCTIONALITY OF THE FABRIC AND IS EASILY REMOVED

• Do not:

- Use this product as a step stool or ladder
- Failure to follow this warning could result in injury