



SIGNATURE
— COLLECTION —


ASSEMBLY INSTRUCTION

PORTOFINO

2600 OUTDOOR DINING TABLE

ITEM CODE: 85085

Imported by Amart Furniture Pty Ltd, Qld, Brisbane, Australia. For any assistance with assembly or for missing parts please phone Amart Furniture, Customer Service Free call 1800 351 084




Imported by Amart Furniture Pty Ltd, Brisbane QLD Australia.
For any assistance with assembly or for missing parts please phone
Amart Furniture, Customer Service Free call 1800 351 084


PRE-ASSEMBLY PREPARATION

Before you start:

1. Choose a clean, level, spacious assembly area.
Avoid hard surfaces that may damage the product
2. Take care when lifting. Product should be assembled as near as possible to the point of use
3. Ensure that you have all required contents for complete assembly
4. Always read the assembly instructions carefully before beginning assembly.
5. Keep all hardware parts and packaging out of reach of small children.
6. Do not over tighten the screws and bolts as this may damage the threads









ALLOW 15 MINUTES




PEOPLE REQUIRED

PARTS LIST


<p>D</p>  <p>SCREW 7X70 4 X D</p>	<p>F</p>  <p>ALLENKEY M4 2 X F</p>
<p>E</p>  <p>SCREW 7X45 4 X E</p>	

	<p>TOP TABLE</p>	<p>A</p>	<p>1 pc</p>
	<p>CROSS BEAM</p>	<p>B</p>	<p>1 pc</p>
	<p>LEG FRAMES</p>	<p>C</p>	<p>2 pcs</p>


EXPLODED VIEW




STEP 1: Inserts Screw 7x45 (E) From Legs Frame (2xC) into Cross Beam. And use Allen key (F) to secure.



STEP 2: Insets Screw 7x70 (D) From Leg (2xC) Step 1 into Top Table. And use Allen key (F) to secure.



ASSEMBLY IS COMPLETE



IMPORTANT NOTE:

ALWAYS USE TWO PEOPLE WHEN TURNING THE TABLE OVER.

CAUTION:

ALWAYS LIFT YOUR PRODUCT WHEN MOVING/RELOCATING. DO NOT DRAG. DRAGGING CAN CAUSE DAMAGE TO LEGS.

CARE AND MAINTENANCE

To ensure the longevity and maintain the appearance of your outdoor timber furniture, please follow these care instructions:

- 1. Usage and Storage:** This furniture is designed for outdoor use, but prolonged exposure to harsh weather conditions can affect its integrity and appearance. To extend its life, avoid leaving the furniture exposed during extreme weather. Store it indoors or under cover when not in use or use a high-quality outdoor cover (do not store on grass).
- 2. Moisture Management:** Timber can be susceptible to moisture damage, including warping and mould growth. Avoid allowing the furniture to remain wet for long periods. Wipe off any spills immediately, and if the furniture becomes wet from rain, allow it to dry completely before covering it.
- 3. Protection from the Elements:** Different timbers have varying levels of natural resistance to the elements:
 - a. Acacia: While naturally durable, acacia benefits from periodic oiling to maintain its colour and to protect it against moisture and UV damage. It is recommended to oil acacia every 6-12 months.
 - b. Teak: Known for its natural oils, teak is highly resistant to water. For optimal care and to prevent it from weathering to a grey colour, apply teak oil every 6-12 months.
 - c. Karri Gum: This hardwood is robust but should be treated with a wood protector or sealer to enhance its durability and maintain its colour. Treatment intervals are dependent on exposure frequency however it is recommended this is applied every 6-12 months.
 - d. Eucalyptus: While naturally strong and durable, eucalyptus requires periodic oiling to maintain its colour and to protect it against moisture and UV damage. It is recommended to oil eucalyptus every 6-12 months.
- 4. Avoid Exposure to Chlorine & Salt Water:** Chlorinated and saltwater environments can accelerate deterioration of timber. If your furniture is near a pool or coastal area, clean it more frequently and use protective covers when not in use.
- 5. Cleaning:** Clean your furniture with care. Avoid using harsh solvents, abrasives, or chemicals. To remove dirt and grime, rinse with fresh water and dry thoroughly. For a deeper clean, use a sponge and a mild detergent solution as needed. Abrasive cleaners will scratch/damage the surface.

Timber expands and contracts with fluctuations in temperature and humidity. This will result in minor cracking but will not compromise the structural integrity of the product. By following the simple steps above, you will help prevent this cracking as well as keep your timber furniture in great condition, ensuring it remains a beautiful and functional part of your outdoor space.