



ASSEMBLY INSTRUCTION

ALBATROSS

DRESSER

ITEM CODE 85326





Imported by JWA Furniture Pty Ltd, Qld, Brisbane Australia.
For any assistance with assembly or for missing parts please refer to your receipt

PRE-ASSEMBLY PREPARATION


Before you start:

1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product
2. Take care when lifting. Product should be assembled as near as possible to the point of use
3. Ensure that you have all required contents for complete assembly
4. Always read the assembly instructions carefully before beginning assembly.
5. Keep all hardware parts and packaging out of reach of small children.
6. Do not over tighten the screws and bolts as this may damage the threads




		
Allow 1 hour	For 2 person	Additional tools required





WARNING

		Children have died from furniture tipover. • ALWAYS secure it with an anchor device. • NEVER allow children to stand, climb or hang on drawers, doors, or shelves. • NEVER open more than one drawer at a time. • Place heavy items down low NEVER put a TV on this furniture  This is a permanent label. Do not remove!
---	---	---

PARTS LIST





PARTS LIST



NO.	ITEM	QTY	NO.	ITEM	QTY
A	 $\Phi 6*35$	40PCS	K		2PCS
B	 $\Phi 12*10$	40PCS	L	 $\Phi 3*12$	48PCS
C	 $\Phi 6*30$	12PCS	M	 $\Phi 4*30$	2PCS
D		6PCS	N		5PCS
E	 $\Phi 3*12$	12PCS	O	 $\Phi 4*12$	20PCS
F	 $\Phi 4*35$	46PCS	P		5PCS
G		8PCS	Q	 CL	6PCS
H	 $\Phi 3*14$	8PCS		 CR	
I	 $\Phi 4*10$	4PCS		 DL	
J		2PCS		 DR	

NO.	ITEM	QTY	NO.	ITEM	QTY
①	TOP PANEL	1 PC	⑩	LEG	5 PCS
②	LEFT SIDE PANEL	1 PC	⑪	DRAWER FRONT PANEL	3 PCS
③	RIGHT SIDE PANEL	1 PC	⑫	DRAWER LEFT SIDE PANEL	6 PCS
④	MIDDLE PANEL	1 PC	⑬	DRAWER RIGHT SIDE PANEL	6 PCS
⑤	CROSSING BAR	1 PC	⑭	DRAWER BACK PANEL	6 PCS
⑥	BACK PANEL	1 PC	⑮	DRAWER BOTTOM PANEL	6 PCS
⑦	MIDDLE SUPPORT PANELL	1 PC	⑯	DRAWER SUPPORT PANEL	6 PCS
⑧	BACK PANEL	1 PC	⑰	DRAWER FRONT PANEL	3 PCS
⑨	BOTTOM PANEL	1 PC			

STEP 1:



STEP 2:




STEP 3:

Diagram illustrating Step 3: Attaching the side rails. The diagram shows a central panel with four side rails (Q) being attached. Two rails are labeled Q(CR) (Center Rail) and two are labeled Q(CL) (Corner Rail). The rails are shown being attached to the panel with screws (L). A callout shows a close-up of a rail (Q) being attached to a panel with a screw (L).


L	X12	Q	X3
			




STEP 5:




STEP 6:




STEP 7:




STEP 8:




STEP 9:



STEP 10:




STEP 11:



x3

A	X15	D	X3	E	X6
					


STEP 12:




x3

A	X15	D	X3	E	X6
					


STEP 13:




STEP 14:




STEP 15:




STEP 16:



STEP 17:



ASSEMBLY IS COMPLETE




DO NOT DRAG:

Do not drag the item as this may cause damage to the legs.
Instead, use 2 people to lift carefully and with caution from either end.

SAFETY BRACKETS INSTRUCTIONS

1. Attach the metal plate to the furniture frame with the small screw.
2. Move the furniture to its final position. Attach the metal plate to the wall with the large screw. If mounting into brick or masonry you will need to acquire wall anchors.
3. Make sure that the metal plate are firmly attached to the wall and furniture.



To protect your furniture, we suggest the following:

- Avoid placing your furniture in direct sunlight.
- Do not place furniture directly under windows.
- Do not place sharp materials (knife, fork, etc.) directly onto your furniture as sharp material may scrape and damage the finish.
- Do not place material with high temperature directly onto the surface of your furniture.
- Clean up spills quickly. Water left over a prolonged period of time may cause damage. Alcohol, perfume, nail polishes, aftershave and some medication may cause severe finish damage if not cleaned immediately.
- Use a clean, soft, dry, lint free absorbent cloth to clean your furniture. Do not use any detergent as they may contain ingredients that may react and damage the finish.

NOTE: If the above care advise is not adhered to your product warranty may become void