




ASSEMBLY INSTRUCTION

CASSEL 2100 DINING TABLE

ITEM CODE 85570

Imported by Amart Furniture Pty Ltd, Qld, Brisbane Australia.
For any assistance with assembly or for missing parts please phone
Amart Furniture Road, Customer Service Free call 1800 351 084




Imported by Amart Furniture Pty Ltd, Qld, Brisbane Australia.
For any assistance with assembly or for missing parts please phone
Amart Furniture Road, Customer Service Free call 1800 351 084

PRE-ASSEMBLY PREPARATION


Before you start:

1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product.
2. Take care when lifting. Product should be assembled as near as possible to the point of use.
3. Ensure that you have all required contents for complete assembly.
4. Always read the assembly instructions carefully before beginning assembly.
5. Keep all hardware parts and packaging out of reach of small children.
6. Do not over tighten the screws and bolts as this may damage the threads.

	
ALLOW 30 MINUTES	PEOPLE REQUIRED
	
	
ADDITIONAL TOOLS REQUIRED	


PARTS LIST

1	LEG
2	TOP PANEL




D foot pad  1×D	E bolt  8×E	F washer  8×F	G washer  8×G	H nut  8×H	I allen key  1×1
--	--	--	--	---	---


STEP1: Fix bolt (E) to panel (1).



STEP2: Fix panel (2) to legs with washer (F & G) ,nut (H) and bolt (E) using allen key (I).
Attach foot pad (D) to legs.



ASSEMBLY IS COMPLETE



General Product Care

To protect your furniture, we suggest the following:

- Avoid placing your furniture in direct sunlight.
- Do not place furniture directly under windows.
- Do not place sharp materials (knife, fork, etc.) directly onto your furniture as sharp material may scrape and damage the finish.
- Do not place material with high temperature directly onto the surface of your furniture.
- Clean up spills quickly. Water left over a prolonged period of time may cause damage. Alcohol, perfume, nail polishes, aftershave and some medication may cause severe finish damage if not cleaned immediately.
- Use a clean, soft, dry, lint free absorbent cloth to clean your furniture. Do not use any detergent as they may contain ingredients that may react and damage the finish.