


ASSEMBLY INSTRUCTION

CLINT

LOWER TIER DESK




ITEM CODE 70845



PRE-ASSEMBLY PREPARATION

Before you start:

1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product
2. Take care when lifting. Product should be assembled as near as possible to the point of use
3. Ensure that you have all required contents for complete assembly
4. Always read the assembly instructions carefully before beginning assembly.
5. Keep all hardware parts and packaging out of reach of small children.
6. Do not over tighten the screws and bolts as this may damage the threads

		
Allow 45min	For 2 person	Additional tools required



TIPPING WARNING





Serious or fatal injuries may occur from furniture toppling over. To help avoid this please follow the below recommendations;

- Install the provided "Tipping Kit" as per the instructions
- Never allow children to climb on or hang off of any part of this product
- Unless specifically designed to accommodate, do not set TVs or other heavy objects on top of this product








IF this product has drawers:

- Place the heaviest items in lowest drawers
- Do not open more than 1 drawer at a time as this may cause the product to become unbalanced
- Do not tamper with or remove any drawer interlocking/running system

Note: The use of the provided "Tipping Kit" may reduce but not necessarily eliminate the risk of furniture toppling over. Please use this product with caution.


This is a permanent label. Do not attempt to remove!

PARTS LIST

A  13pcs	B  M6X30 mm 5pcs	C  M6X40 mm 4pcs	D  4pcs	E  E2 E1 2pcs
F  ST3.5X12mm 8pcs	G  ST5X50mm 23pcs	H  4pcs		


1	Panel
2	Left side panel
3	Right side panel
4	Upper back panel
5	Lower panel

6	Lower back panel
P1	Main frame
P2	Supporting tube




STEP 1:

Install the fitting H on the bottom of P1.




STEP 2:

1. Connect P1 to both ends of P2 with fitting B.
2. Fix both ends of Panel 4 on the corresponding hole position of P1 with fitting G.




STEP 3:

Fix Panel 6 on Panel 5 with fitting G.





STEP 4:

Fix the pre-assembled Panel 5 assembly on the hole corresponding to P1 with fitting G.




STEP 5:

1. Fix Panel 1 on Panel 4 with fitting A.
2. Fix Panel 1 at the corresponding hole of P1 with fitting C.
3. Fix Panel 1 to P2 with fitting B.




STEP 6:

Split accessory E: Press the plastic part inside the E2 part by hand and pull out the E2 horizontally.





STEP 7:

Fix E1 on Panel 2 and Panel 3 with fitting F.




STEP 8:

Use fitting A and D to fix the Panel 2 assembly and Panel 3 assembly at the corresponding hole position at the bottom of Panel 1.





STEP 9:

Fix Panel 2 and Panel 3 on the corresponding hole of Panel 4 with fitting G.





STEP 10:

1. Fix Panel 8 and Panel 9 on both ends of Panel 10 with fitting G.
2. The Panel 11 is loaded along the slots of Panel 8 and Panel 9.
3. Fix Panel 7 on the corresponding holes of Panel 8 and Panel 9 with fitting A.




STEP 11:

E2 shall be fixed on the drawing holes of Panel 8 and Panel 9 respectively by fitting F.




STEP 12:

Place the assembled drawer assembly horizontally into the corresponding position of the table.



STEP 13:

Finished assembly;



To protect your furniture, we suggest the following:

- Avoid placing your furniture in direct sunlight.
- Do not place furniture directly under windows.
- Do not place sharp materials (knife, fork, etc.) directly onto your furniture as sharp material may scrape and damage the finish.
- Do not place material with high temperature directly onto the surface of your furniture.
- Clean up spills quickly. Water left over a prolonged period of time may cause damage. Alcohol, perfume, nail polishes, aftershave and some medication may cause severe finish damage if not cleaned immediately.
- Use a clean, soft, dry, lint free absorbent cloth to clean your furniture. Do not use any detergent as they may contain ingredients that may react and damage the finish.

NOTE: If the above care advise is not adhered to your product warranty may become void