




ASSEMBLY INSTRUCTION

SHADOW2 OUTDOOR CHAIR

ITEM CODE 51380

Imported by Amart Furniture Pty Ltd, Qld, Brisbane Australia.
For any assistance with assembly or for missing parts please phone
Amart Furniture, Customer Service Free call 1800 009 466




Imported by Amart Furniture Pty Ltd, Qld, Brisbane Australia.
For any assistance with assembly or for missing parts please phone
Amart Furniture, Customer Service Free call 1800 009 466


PRE-ASSEMBLY PREPARATION

Before you start:


1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product
2. Take care when lifting. Product should be assembled as near as possible to the point of use
3. Ensure that you have all required contents for complete assembly
4. Always read the assembly instructions carefully before beginning assembly.
5. Keep all hardware parts and packaging out of reach of small children.
6. Do not over tighten the screws and bolts as this may damage the threads

	 x1
ALLOW 15 MINUTES	1 PEOPLE REQUIRED
ADDITIONAL TOOL REQUIRED (not include)	


PARTS LIST




NO	PART LIST	QT'Y
1	Seat	1 PC
2	Backrest	1 PC
3	Armrest	2 PCS
4	Bottom crossbar	1 PC

A Hexagon head Screw  M6 x 100mm 8xA	B Hexagon head Screw  M6 x 40mm 2xB	C Seat cushion Back cushion  2xC
D Allen key  4mm 1xD	E Adhesive felt pad  50 x 20 x 5mm 4xE	


Step 1: Attach adhesive felt pad (E) onto the legs.




Step 2: Using the hexagon head screw (B) attach the seat (1) to the backrest (2). Carefully tighten all bolts.



Step 3: Using the hexagon head screw (A) attach the Seat (1) and Backrest (2) to the Armrest (3) with the allen key (D) as shown in the diagram.




Step 4: Place the seat and back cushion (C) on product and connect unnapper loop and napper loop on slats as show in the diagram.



IMPORTANT NOTE:

BEFORE FINALLY TIGHTENING THE BOLTS, PLACE THE ASSEMBLED CHAIR UPRIGHT ON A LEVEL SURFACE AND SIT CAREFULLY ON THE CHAIR TO ENSURE THE CHAIR LEGS ARE ALIGNED AND LEVEL. THEN TIGHTEN ALL BOLTS AND YOUR CHAIR IS READY TO USE.

ASSEMBLY IS COMPLETE



CAUTION:
DO NOT

- USE CHAIR/STOOL AS A LADDER
- CLIMB ON THE CHAIR/STOOL
- STAND ON THE FOOT REST OF THE CHAIR, AS THIS COULD LEAD TO THE STOOL BECOMING UNBALANCED AND OVERTURNING.

IMPORTANT NOTE:

THE FELT PAD ON THE BOTTOM OF THE CHAIR LEG IS SUBJECT TO WEAR. AMART RECOMMENDS REGULAR ROUTINE CHECKS AND REPLACEMENT WHERE NECCESARY.

IMPORTANT: CARE GUIDE FOR YOUR TIMBER FURNITURE

Congratulations! You have just purchased a quality product from Amart Furniture. Please read on for important information regarding your purchase...

CUSHIONS:

To keep your outdoor cushions looking their best and ensure they last, please follow these simple care instructions:

- 1. Sun Exposure:** Direct sunlight can cause rapid fading of the fabric. For best results, avoid exposing the cushions to direct sunlight.
- 2. Weather Protection:** To prolong the life of your cushions, do not leave them permanently exposed to weather conditions. Leaving cushions exposed puts the product at risk of mould and mildew growth. Store them indoors or under cover when not in use.
- 3. Cleaning:** Spot clean using a mild detergent and a damp cloth. After cleaning, dry the cushions by laying them flat in a shaded area to prevent any potential damage.
- 4. Handling:**
 1. Do not unzip the cushion covers.
 2. Do not remove the cushions from their covers.
 3. Do not put in the washing machine.
 4. Do not tumble dry.
 5. Do not bleach.
 6. Do not dry clean.

By following these simple steps, you will help keep your furniture in great condition and ensure it remains a beautiful and functional part of your outdoor space.

TIMBERS:

To ensure the longevity and maintain the appearance of your outdoor timber furniture, please follow these care instructions:

- 1. Usage and Storage:** This furniture is designed for outdoor use, but prolonged exposure to harsh weather conditions can affect its integrity and appearance. To extend its life, avoid leaving the furniture exposed during extreme weather. Store it indoors or under cover when not in use or use a high-quality outdoor cover (do not store on grass).
- 2. Moisture Management:** Timber can be susceptible to moisture damage, including warping and mould growth. Avoid allowing the furniture to remain wet for long periods. Wipe off any spills immediately, and if the furniture becomes wet from rain, allow it to dry completely before covering it.
- 3. Protection from the Elements:** Different timbers have varying levels of natural resistance to the elements:

Acacia: While naturally durable, acacia benefits from periodic oiling to maintain its colour and to protect it against moisture and UV damage. It is recommended to oil acacia every 6-12 months.
- 4. Avoid Exposure to Chlorine & Salt Water:** Chlorinated and saltwater environments can accelerate deterioration of timber. If your furniture is near a pool or coastal area, clean it more frequently and use protective covers when not in use.
- 5. Cleaning:** Clean your furniture with care. Avoid using harsh solvents, abrasives, or chemicals. To remove dirt and grime, rinse with fresh water and dry thoroughly. For a deeper clean, use a sponge and a mild detergent solution as needed. Abrasive cleaners will scratch/damage the surface.

Timber expands and contracts with fluctuations in temperature and humidity. This will result in minor cracking but will not compromise the structural integrity of the product. By following the simple steps above, you will help prevent this cracking as well as keep your timber furniture in great condition, ensuring it remains a beautiful and functional part of your outdoor space.

