




**ASSEMBLY INSTRUCTION**  
**NEREIDES DINING CHAIR A/WHT**  
**ITEM CODE 785910001**

Imported by Amart Furniture Pty Ltd, Qld, Brisbane Australia.  
For any assistance with assembly or for missing parts please phone  
Amart Furniture, Customer Service Free call 1800 351 084






Imported by Amart Furniture Pty Ltd, Qld, Brisbane Australia.  
For any assistance with assembly or for missing parts please phone  
Amart Furniture, Customer Service Free call 1800 351 084








# PRE-ASSEMBLY PREPARATION

## Before you start:


- 1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product
- 2. Take care when lifting. Product should be assembled as near as possible to the point of use
- 3. Ensure that you have all required contents for complete assembly
- 4. Always read the assembly instructions carefully before beginning assembly.
- 5. Keep all hardware parts and packaging out of reach of small children.
- 6. Do not over tighten the screws and bolts as this may damage the threads

	
ALLOW 20 MINUTES	1 PEOPLE REQUIRED
	
ADDITIONAL TOOLS REQUIRED	

# PARTS LIST


<div>A</div> <div></div> <div>Bolt M6x40mm Lock Washer Ø6/Ø9 Flat Washer Ø6/Ø19</div> <div>2xA</div>	<div>B</div> <div></div> <div>Bolt M6x70mm Lock Washer Ø6/Ø9 Flat Washer Ø6/Ø19</div> <div>4xB</div>	<div>C</div> <div></div> <div>Nut M6</div> <div>4xC</div>	<div>D</div> <div></div> <div>Lock Washer Ø6/Ø9</div> <div>4xD</div>
<div>E</div> <div></div> <div>Flat Washer Ø6/Ø19</div> <div>4xE</div>	<div>F</div> <div></div> <div>Wrench 10mm</div> <div>1xF</div>	<div>G</div> <div></div> <div>Screw Ø4x50mm</div> <div>6xG</div>	

# EXPLODED VIEW




C1	1	132x448x981mm
C2	1	90x460x460mm
C3	1	40x440x425mm
C4	1	40x440x425mm
C5	1	20x30x454mm
C6	1	20x30x454mm
C7	1	20x30x401mm


**STEP 1** Attach the seat frame (C2) to the chair back (C1), using bolt (A,B).



**STEP 2** Attach the Stretcher (C5,C6) to the chair back (C1), using screws (G)




**STEP 3** Attach the Leg (C3,C4) to the seat frame (C2), using nut (C) and Washer (D,E). Attach mid Stretcher (C7) using screws (G)



**IMPORTANT NOTE:**

Before finally tightening the bolts, place the assembled chair upright on a level surface and sit carefully on the chair to ensure the chair legs are aligned and level. Then tighten all bolts and your chair is ready for use.

**STEP 4**



**ASSEMBLY IS COMPLETE.**

## CARE AND MAINTENANCE

To protect your furniture, we suggest the following:

- Avoid placing your furniture in direct sunlight.
- Do not place furniture directly under windows.
- Do not place sharp materials (knife, fork, etc.) directly onto your furniture as sharp material may scrape and damage the finish.
- Do not place material with high temperature directly onto the surface of your furniture.
- Clean up spills quickly. Water left over a prolonged period of time may cause damage. Alcohol, perfume, nail polishes, aftershave and some medication may cause severe finish damage if not cleaned immediately.
- Use a clean, soft, dry, lint free absorbent cloth to clean your furniture. Do not use any detergent as they may contain ingredients that may react and damage the finish.