




ASSEMBLY INSTRUCTION

LA VIDA 4 PIECE CORNER OUTDOOR LOUNGE SETTING

ITEM CODE - 84800




Imported by Amart Furniture Pty Ltd, Brisbane QLD, Australia.
For any assistance with assembly or for missing parts please phone
Amart Furniture, Customer Service Freecall 1800 351 084


PRE-ASSEMBLY PREPARATION





Before you start:

1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product.
2. Take care when lifting. Product should be assembled as near as possible to the point of use.
3. Ensure that you have all required contents for complete assembly.
4. Always read the assembly instructions carefully before beginning assembly.
5. Keep all hardware parts and packaging out of reach of small children.
6. Do not over tighten the screws and bolts as this may damage the threads.




PARTS LIST



1	Sofa		1PC	2	Back Cushion		3PCS
3	Cushion		3PCS	4	Back Cushion		2PCS

**Be careful when you open the compressed foam packaging to
avoid cut damage to cushion by knife or scissors.**

ASSEMBLY IS COMPLETE






ASSEMBLY INSTRUCTION

LA VIDA 4 PIECE CORNER OUTDOOR LOUNGE SETTING

ITEM CODE - 84800




Imported by Amart Furniture Pty Ltd, Brisbane QLD, Australia.
For any assistance with assembly or for missing parts please phone
Amart Furniture, Customer Service Freecall 1800 351 084


PRE-ASSEMBLY PREPARATION





Before you start:

1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product.
2. Take care when lifting. Product should be assembled as near as possible to the point of use.
3. Ensure that you have all required contents for complete assembly.
4. Always read the assembly instructions carefully before beginning assembly.
5. Keep all hardware parts and packaging out of reach of small children.
6. Do not over tighten the screws and bolts as this may damage the threads.




PARTS LIST



5	Sofa		1PC	2	Back Cushion		3PCS
3	Cushion		3PCS	4	Back Cushion		1PCS
6	Velcro		2PCS				


Be careful when you open the compressed foam packaging to avoid cut damage to cushion by knife or scissors.

ASSEMBLY IS COMPLETE




Step 1:


ITEMS REQUIRED



- Attach sofa (1) to sofa (5) using velcro (6)



ASSEMBLY IS COMPLETE



IMPORTANT:


**PLEASE USE THE SOFA AT LEAST 48 HOURS AFTER OPENING TO ALLOW
THE COMPRESSED FOAM TO REBOUND.**



ASSEMBLY INSTRUCTION


LA VIDA 4 PIECE CORNER OUTDOOR LOUNGE SETTING

ITEM CODE - 84800



Imported by Amart Furniture Pty Ltd, Brisbane QLD, Australia.
For any assistance with assembly or for missing parts please phone
Amart Furniture, Customer Service Freecall 1800 351 084

ASSEMBLY IS COMPLETE






ASSEMBLY INSTRUCTION


LA VIDA 4 PIECE CORNER OUTDOOR LOUNGE SETTING

ITEM CODE - 84800



Imported by Amart Furniture Pty Ltd, Brisbane QLD, Australia.
For any assistance with assembly or for missing parts please phone
Amart Furniture, Customer Service Freecall 1800 351 084

ASSEMBLY IS COMPLETE



Care and maintenance

Weathergrain

To ensure the longevity and maintain the appearance of your outdoor furniture, please follow these care instructions:

- 1. Usage and Storage:** This furniture is designed for outdoor use; however, prolonged exposure to extreme weather conditions can affect its integrity and cause fading and brittleness over time. To extend its life, store the furniture indoors or under cover when not in use, or use a high-quality outdoor cover.
- 2. Avoid Heavy or Pointed Objects:** Do not place heavy or pointed objects on the surface, as this can lead to dents or scratches. Additionally, avoid placing magnifying objects such as wine glasses, reading glasses, or other glass items on the furniture, as they can focus sunlight and potentially burn the surface.
- 3. Heat Protection:** Avoid placing hot objects directly on the furniture, as high temperatures can weaken the material and lead to brittleness. Always use heat-resistant pads under hot items.
- 4. Cleaning:** Clean your furniture with care. Avoid using harsh solvents, abrasives, or chemicals. To remove dirt and grime, rinse with fresh water and dry thoroughly. For a deeper clean, use a sponge and a mild detergent solution as needed. Abrasive cleaners will scratch/damage the surface.

By following these simple steps, you will help keep your furniture in great condition, ensuring it remains a beautiful and functional part of your outdoor space.

Care and maintenance

Aluminium

To ensure the longevity and maintain the appearance of your aluminium outdoor furniture, please follow these care instructions:

1. Usage and Storage:

This item is designed for outdoor use, but, like all man-made materials, it can suffer damage if left exposed to the elements. To extend its life, avoid prolonged exposure to weather conditions. Store the furniture indoors or under cover when not in use or use an outdoor cover (do not store on grass).

2. Avoid Excess Moisture:

DO NOT allow the furniture to remain wet or sit in standing water for long periods. Wipe the furniture dry immediately if it becomes wet. Excess moisture can cause corrosion.

3. Avoid exposure to chlorine & salt water:

Chlorine/salt can disrupt the protective oxide layer on aluminium, leading to accelerated corrosion. This is particularly problematic in environments with high chlorine concentrations, such as in swimming pools, homes within a short distance of the ocean or areas with heavy chlorination.

4. Cleaning:

Clean your furniture with care. Avoid using harsh solvents, abrasives, or chemicals. To remove dirt and grime, rinse with fresh water and dry thoroughly. For a deeper clean, use a sponge and a mild detergent solution as needed. Abrasive cleaners will scratch/damage the surface.

Live by the beach? Due to a process called “aerosolization”, sea water is broken up into tiny droplets by the wind and waves and salt particles are released into the air. This process accelerates the corrosion of metal surfaces over time. It is essential to use furniture covers when the product is not in use and clean your product more frequently.

By following these simple steps, you will help keep your furniture in great condition and ensure it remains a beautiful and functional part of your outdoor space.

Care and maintenance

Cushions

To keep your outdoor cushions looking their best and ensure they last, please follow these simple care instructions:

1. Sun Exposure:

Direct sunlight can cause rapid fading of the fabric. For best results, avoid exposing the cushions to direct sunlight.

2. Weather Protection: To prolong the life of your cushions, do not leave them permanently exposed to weather conditions. Leaving cushions exposed puts the product at risk of mould and mildew growth. Store them indoors or under cover when not in use.

3. Cleaning: Spot clean using a mild detergent and a damp cloth. After cleaning, dry the cushions by laying them flat in a shaded area to prevent any potential damage.

4. Handling:

1. Do not unzip the cushion covers.
2. Do not remove the cushions from their covers.
3. Do not put in the washing machine.
4. Do not tumble dry.
5. Do not bleach.
6. Do not dry clean.

By following these simple steps, you will help keep your furniture in great condition and ensure it remains a beautiful and functional part of your outdoor space. By following these simple steps, you will help keep your furniture in great condition and ensure it remains a beautiful and functional part of your outdoor space.

Care and maintenance

Glass

To ensure the safety and longevity of your glass furniture, please follow these important care instructions:

1. Usage and Storage:

This item is designed for outdoor use, but, like all man-made materials, it can suffer damage if left exposed to the elements. To extend its life, avoid prolonged exposure to weather conditions. Store the furniture indoors or under cover when not in use or use an outdoor cover.

2. Inspect Upon Delivery:

If you notice that the glass is chipped or broken upon delivery, stop using the product immediately and contact Amart for assistance.

3. Inspect regularly:

If you notice that the glass is chipped or broken over its lifespan, stop using the product immediately as this may result in a sudden and premature cracking of the surface.

4. Avoid Impact:

Do not drop, drag, or strike the glass surface. Handle with care to avoid any damage.

5. Safe Usage:

Do not sit or stand on the glass surface. It is designed for use as a tabletop and is not designed to support weight.

6. Temperature Precautions:

Avoid placing very hot or very cold items directly on the glass. Use at least 6mm thick table mats or protective pads to prevent extreme temperatures from coming into direct contact with the glass.

7. Scratches:

Do not use the glass surface as a chopping board or allow it to come into contact with sharp or abrasive objects as this can cause scratches.

Cleaning:

Clean your furniture with care. Avoid using harsh solvents, abrasives, or chemicals. To remove dirt and grime, rinse with fresh water and dry thoroughly. For a deeper clean, use a sponge and a mild detergent solution as needed. Abrasive cleaners will scratch/damage the surface.

Care and maintenance

Exploding glass

"Exploding glass" refers to the phenomenon where glass suddenly shatters or breaks apart, often with a lot of force or in a dramatic fashion. There are several causes for this issue:

1.Thermal Stress:

Glass can break due to rapid changes in temperature. For example, if a hot object is placed on a cold glass surface, or if the glass is exposed to extreme heat or cold, it can expand or contract unevenly, causing it to crack or shatter.

2.Impact Damage:

Dropping or striking glass with a hard object can cause it to crack or break. Even a small impact can lead to a chain reaction of fractures, making the glass appear to "explode."

3.Unlevel surface: The uneven glass surface causes uneven stress distribution, making it more prone to breakage and fragmentation under pressure or impact, posing a danger to surrounding people and objects. For example, when a person leans on a glass partition with an uneven surface, the glass may break due to excessive local stress.

4.Chemical Reactions: Some types of glass can be sensitive to certain chemicals. Exposure to harsh chemicals or cleaning agents might weaken the glass over time, leading to sudden breakage.

If glass "explodes" or shatters, it is important to handle the situation carefully to avoid injury. Broken glass should be cleaned up promptly.

When choosing protective matting for your tabletop, consider the below:

1.Material:

Choose placemats made from materials that offer good insulation against heat, such as silicone, cork, or thick fabric. The thickness of this material should be a minimum of 6mm. These materials are effective at absorbing and diffusing heat.

2.Coverage:

Ensure that the placemat is large enough to cover the area where hot items will be placed. It should completely cover the base of pots, pans, or other hot items to provide adequate protection.

3.Heat Resistance:

Verify that the placemat is designed to handle high temperatures. Some placemats are specifically rated for heat resistance and can withstand higher temperatures without damage.

By following these simple steps, you will help keep your furniture in great condition and ensure it remains a beautiful and functional part of your outdoor space.