


ASSEMBLY INSTRUCTION

TARASCON

4 PIECE OUTDOOR LOUNGE SETTING

ITEM CODE 85227





Imported by JWA Furniture Pty Ltd, Brisbane, QLD, Australia
For any assistance with assembly or for missing parts, please refer to your receipt


PRE-ASSEMBLY PREPARATION

Before you start:

1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product.
2. Take care when lifting. Product should be assembled as near as possible to the point of use.
3. Ensure that you have all required contents for complete assembly.
4. Always read the assembly instructions carefully before beginning assembly.
5. Keep all hardware parts and packaging out of reach of small children.
6. Do not over tighten the screws and bolts as this may damage the threads.
7. Assembly is to be carried out by a competent adult(s) ONLY
8. During assembly, children should be kept away from the product due to possible risk to injury.
9. Do not use this item if any components are missing or damaged.
10. Please keep the instructions for future reference.

		
Allow 60min	For 2 person	You will need a tape measure.

PARTS LIST



X 2

1. Sofa		2PCS	2. Front Leg		4PCS
3. Back Leg		4PCS			
8. Seat Cushion		2PCS	9. Back Cushion		2PCS

A. Bolt	B. Washer	C. Allen Key
 M6*15 , 24PCS	 M6 , 24PCS	 M6 , 1PC


Part A:Single Sofa

You will need the following

1. Sofa 1PC	2. Front Leg 2PCS	3. Back Leg 2PCS
A. Bolt M6*15*12PCS	B. Washer M6*12PCS	C. Allen Key M6*1PC


Step 1:

- Attach front leg (2) and back leg (3) to sofa (1) using bolt (A) with washer (B) .
- Tighten with allen key (C) .




Part A:Single Sofa

You will need the following





Step 2:

- Put the seat cushion (8) and back cushion (9) on the seat .




Part A:Single Sofa

ASSEMBLY IS COMPLETE



PARTS LIST







4. Sofa	1PC	2. Front Leg	2PCS
3. Back Leg	2PCS	5. Leg	1PC
10. Seat Cushion	1PC	9. Back Cushion	3PCS

A. Bolt	B. Washer	C. Allen Key
M6*15 , 16PCS	M6 , 16PCS	M6 , 1PC


Part B: 2 Seater Sofa

You will need the following

4.	Sofa	1PC	2.	Front Leg	2PCS	3.	Back Leg	2PCS
								
A.	Bolt		B.	Washer		C.	Allen Key	
		M6*15*12PCS			M6*12PCS			M6*1PC


Step 1:

- Attach front leg (2) and back leg (3) to sofa (4) using bolt (A) with washer (B) .
- Tighten with allen key (C) .




Part B: 2 Seater Sofa

You will need the following

5. Leg 1PC		
A. Bolt	B. Washer	C. Allen Key
 M6*15*4PCS	 M6*4PCS	 M6*1PC


Step 2:

- Attach leg (5) to sofa (4) using bolt (A) with washer (B) .
- Tighten with allen key (C) .




Part B: 2 Seater Sofa

You will need the following




Step 3:


- Put the seat cushion (10) and back cushion (9) on the seat .





ASSEMBLY IS COMPLETE



PARTS LIST




6.	Table Top	1PC	7.	Leg	4PCS
11.	Glass	1PC			

A.	Bolt	B.	Washer	C.	Allen Key
					
	M6*15 , 16PCS		M6 , 16PCS		M6 , 1PC


Part C: Coffee Table

You will need the following

6.	Table Top	1PC	7.	Legs	4PCS
					
A.	Bolt		B.	Washer	
		M6*15*16PCS			M6*16PCS
C.	Allen Key				
					M6*1PC


Step 1:

- Attach legs (7) to table top (6) using bolt (A) with washer (B) .
- Tighten with allen key (C) .




Part C: Coffee Table

You will need the following




Step 2:

- Turn over the table frame.
- Place glass (11) on the top of the table.
- Glass is secured on the table with suckers.



ASSEMBLY IS COMPLETE



PRODUCT CARE:

Metal

To ensure the longevity and maintain the appearance of your steel outdoor furniture, please follow these care instructions:

1. Usage and Storage:

Galvanised steel is designed for short term outdoor use due to its protective zinc coating, but, like all man-made materials, it can suffer damage if left exposed to the elements. To extend its life, avoid prolonged exposure to weather conditions. Store the furniture indoors or under cover when not in use or use an outdoor cover (do not store on grass).

2. Avoid Excess Moisture:

DO NOT allow the furniture to remain wet or sit in standing water for long periods. Wipe the furniture dry immediately if it becomes wet. Excess moisture can compromise the protective coating and lead to rust formation.

3. Avoid exposure to chlorine & salt water:

Chlorine/salt can disrupt the protective zinc oxide layer on steel, leading to accelerated corrosion. Once the protective layer is compromised it more susceptible to rust. This is particularly problematic in environments with high chlorine concentrations, such as in swimming pools, homes within a short distance of the ocean or areas with heavy chlorination.

4. Cleaning:

Clean your furniture with care. Avoid using harsh solvents, abrasives, or chemicals. To remove dirt and grime, rinse with fresh water and dry thoroughly. For a deeper clean, use a sponge and a mild detergent solution as needed. Abrasive cleaners will scratch/damage the surface.

Live by the beach? Due to a process called “aerosolisation”, sea water is broken up into tiny droplets by the wind and waves and salt particles are released into the air. This process accelerates the corrosion of metal surfaces over time. It is essential to use furniture covers when the product is not in use and clean your product more frequently.

By following these simple steps, you will help keep your furniture in great condition and ensure it remains a beautiful and functional part of your outdoor space.

PRODUCT CARE:

Wicker

Wicker is a weaving technique used to create outdoor furniture, baskets, and decorative items. It involves weaving thin, flexible strands of materials like rattan, bamboo, or synthetic materials to form intricate patterns.

To ensure the longevity and maintain the appearance of your outdoor furniture, please follow these care instructions:

- 1. Usage and Storage:** This item is designed for outdoor use, but, like all man-made materials, it can suffer damage if left exposed to the elements. To extend its life, avoid prolonged exposure to weather conditions. Store the furniture indoors/under cover when not in use and use an outdoor cover (do not store on grass).
- 2. Sun Exposure:** Prolonged exposure to sunlight can cause wicker to dry out and become brittle, leading to cracks and potential unravelling of the weave. Sun exposure can also cause fading. To protect your furniture from UV damage, we recommend using a furniture cover when not in use, even when stored undercover or under an awning.
- 3. Moisture Management:** While wicker is made from weather-resistant materials, prolonged exposure to moisture can still lead to mould or mildew. If the furniture gets wet, dry it thoroughly to prevent moisture buildup.
- 4. Cleaning:** Regular cleaning is essential to maintain the appearance of your wicker furniture. Use a soft brush or vacuum with a brush attachment to remove dust and debris. For deeper cleaning, mix mild soap with warm water and gently scrub the surface with a cloth or sponge. Rinse thoroughly and dry immediately.

By following these care instructions, you can help ensure your outdoor wicker furniture remains attractive and functional for many seasons to come.

PRODUCT CARE:

Cushions

To keep your outdoor cushions looking their best and ensure they last, please follow these simple care instructions:

1. Sun Exposure:

Direct sunlight can cause rapid fading of the fabric. For best results, avoid exposing the cushions to direct sunlight.

2. Weather Protection: To prolong the life of your cushions, do not leave them permanently exposed to weather conditions. Leaving cushions exposed puts the product at risk of mould and mildew growth. Store them indoors or under cover when not in use.

3. Cleaning: Spot clean using a mild detergent and a damp cloth. After cleaning, dry the cushions by laying them flat in a shaded area to prevent any potential damage.

4. Handling:

1. Do not unzip the cushion covers.
2. Do not remove the cushions from their covers.
3. Do not put in the washing machine.
4. Do not tumble dry.
5. Do not bleach.
6. Do not dry clean.

By following these simple steps, you will help keep your furniture in great condition and ensure it remains a beautiful and functional part of your outdoor space. By following these simple steps, you will help keep your furniture in great condition and ensure it remains a beautiful and functional part of your outdoor space.

PRODUCT CARE:

Glass

To ensure the safety and longevity of your glass furniture, please follow these important care instructions:

1. Usage and Storage:

This item is designed for outdoor use, but, like all man-made materials, it can suffer damage if left exposed to the elements. To extend its life, avoid prolonged exposure to weather conditions. Store the furniture indoors or under cover when not in use or use an outdoor cover.

2. Inspect Upon Delivery:

If you notice that the glass is chipped or broken upon delivery, stop using the product immediately and contact Amart for assistance.

3. Inspect regularly:

If you notice that the glass is chipped or broken over its lifespan, stop using the product immediately as this may result in a sudden and premature cracking of the surface.

4. Avoid Impact:

Do not drop, drag, or strike the glass surface. Handle with care to avoid any damage.

5. Safe Usage:

Do not sit or stand on the glass surface. It is designed for use as a tabletop and is not designed to support weight.

6. Temperature Precautions:

Avoid placing very hot or very cold items directly on the glass. Use at least 6mm thick table mats or protective pads to prevent extreme temperatures from coming into direct contact with the glass.

7. Scratches:

Do not use the glass surface as a chopping board or allow it to come into contact with sharp or abrasive objects as this can cause scratches.

Cleaning:

Clean your furniture with care. Avoid using harsh solvents, abrasives, or chemicals. To remove dirt and grime, rinse with fresh water and dry thoroughly. For a deeper clean, use a sponge and a mild detergent solution as needed. Abrasive cleaners will scratch/damage the surface.

PRODUCT CARE:

Exploding glass

"Exploding glass" refers to the phenomenon where glass suddenly shatters or breaks apart, often with a lot of force or in a dramatic fashion. There are several causes for this issue:

1.Thermal Stress:

Glass can break due to rapid changes in temperature. For example, if a hot object is placed on a cold glass surface, or if the glass is exposed to extreme heat or cold, it can expand or contract unevenly, causing it to crack or shatter.

2.Impact Damage:

Dropping or striking glass with a hard object can cause it to crack or break. Even a small impact can lead to a chain reaction of fractures, making the glass appear to "explode."

3.Unlevel surface: The uneven glass surface causes uneven stress distribution, making it more prone to breakage and fragmentation under pressure or impact, posing a danger to surrounding people and objects. For example, when a person leans on a glass partition with an uneven surface, the glass may break due to excessive local stress.

4.Chemical Reactions: Some types of glass can be sensitive to certain chemicals. Exposure to harsh chemicals or cleaning agents might weaken the glass over time, leading to sudden breakage.

If glass "explodes" or shatters, it is important to handle the situation carefully to avoid injury. Broken glass should be cleaned up promptly.

When choosing protective matting for your tabletop, consider the below:

1.Material:

Choose placemats made from materials that offer good insulation against heat, such as silicone, cork, or thick fabric. The thickness of this material should be a minimum of 6mm. These materials are effective at absorbing and diffusing heat.

2.Coverage:

Ensure that the placemat is large enough to cover the area where hot items will be placed. It should completely cover the base of pots, pans, or other hot items to provide adequate protection.

3.Heat Resistance:

Verify that the placemat is designed to handle high temperatures. Some placemats are specifically rated for heat resistance and can withstand higher temperatures without damage.

By following these simple steps, you will help keep your furniture in great condition and ensure it remains a beautiful and functional part of your outdoor space.