




SIGNATURE
COLLECTION

ASSEMBLY INSTRUCTION MONTANA DINING CHAIR ITEM CODE - 87108

Imported by Amart Furniture Pty Ltd, Qld, Brisbane Australia.
For any assistance to assemble or for missing parts please phone
Amart Furniture, Customer Service Freecall 1800 351 084.




Imported by Amart Furniture Pty Ltd, Qld, Brisbane Australia.
For any assistance to assemble or for missing parts please phone
Amart Furniture, Customer Service Freecall 1800 351 084.

PRE-ASSEMBLY PREPARATION


Before you start:

1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product.
2. Take care when lifting. Product should be assembled as near as possible to the point of use.
3. Ensure that you have all required contents for complete assembly
4. Always read the assembly instructions carefully before beginning assembly.
5. Keep all hardware parts and packaging out of reach of small children.
6. Do not over tighten the screws and bolts as this may damage the threads.



PARTS LIST


No	Description	Qty
1	Back leg frame	1PC
2	Front right leg	1PC
3	Front left leg	1PC
4	Seat frame	1PC
5	Side Stretcher	2PCS




HARDWARE PARTS

<p>A. METAL WASHER</p>  <p style="text-align: right;">10 PCS</p>	<p>B. HEXAGON SOCKET BOLT M6x40</p>  <p style="text-align: right;">2 PCS</p>	<p>C. HEXAGON SOCKET BOLT M6x75</p>  <p style="text-align: right;">4 PCS</p>	<p>D. HEXAGON SOCKET BOLT M6x100</p>  <p style="text-align: right;">4 PCS</p>
<p>E. SCREW M4x50</p>  <p style="text-align: right;">4 PCS</p>	<p>F. HEXAGON KEY N4</p>  <p style="text-align: right;">1 PC</p>		


Step:1 Attach front leg 2,3 to seat frame 4, with bolts C and washers A, using allen key F.




Step:2 Attach side stretcher 5, to front leg 2,3 with screw E.



Step:3 Attach back leg frame 1 to stretcher 5, with screw E. Attach back leg frame 1 to seat frame 4, with bolts B,D and washers A, using allen key F.



ASSEMBLY IS COMPLETE



CAUTION:

DO NOT

- USE CHAIR/STOOL AS A LADDER.
- CLIMB ON THE CHAIR/STOOL.
- STAND ON THE FOOT REST OF THE CHAIR, AS THIS COULD LEAD TO THE STOOL BECOMING UNBALANCED AND OVERTURNING.

IMPORTANT NOTE:

- BEFORE FINALLY TIGHTENING THE BOLTS, PLACE THE ASSEMBLED CHAIR UPRIGHT ON A LEVEL SURFACE AND SIT CAREFULLY ON THE CHAIR TO ENSURE THE CHAIR LEGS ARE ALIGNED AND LEVEL. THEN TIGHTEN ALL BOLTS AND YOUR CHAIR IS READY TO USE.

CARE AND MAINTENANCE

As our timber is supplied from sustainable forests there will be natural variations in surface texture and grain like knots, mineral streaks and sap runs that may affect the finish. These differences in character are not defects, but distinctions that make each piece of furniture unique

Our furniture is built to last. Following these steps for basic care should protect your investment for years to come

- Dust frequently with a clean damp lint-free cloth. This will help remove abrasive build up which can damage a finish over time
- Do not place hot objects on any furniture surface. Always use a hot plate or placemat. Laminate and lacquer finishes on table tops provide added scratch and heat resistance to our furniture, but they can still be damaged without proper care
- Avoid exposing your furniture to strong sunlight, heat outlet, open windows or dampness. Prolonged exposure to direct sunlight can fade the finish of your furniture, while extreme temperature and humidity changes can cause cracking or splitting
- Do not expose your furniture to any liquids. Never allow water to sit on your furniture. Alcohol, nail polish and perfume are also dangerous as they will dissolve the lacquer finish on contact and may require professional repairs
- Do not allow plastic to come in direct contact with your furniture. Chemicals in the plastic of placemats etc. may soften and mark the finish if left in contact with the furniture for a period of time