



ASSEMBLY INSTRUCTION


Spacesaver Pantry 1 Door All Shelf

ITEM CODE 49176

Imported by Amart Furniture Pty Ltd, Qld, Brisbane Australia.

For any assistance with assembly or for missing parts please phone

Amart Furniture, Customer Service Free call 1800 351 084



Imported by Amart Furniture Pty Ltd, Qld, Brisbane Australia.






For any assistance with assembly or for missing parts please phone

Amart Furniture, Customer Service Free call 1800 351 084


PRE-ASSEMBLY PREPARATION

Before you start:

1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product.
2. Take care when lifting. Product should be assembled as near as possible to the point of use.
3. Ensure that you have all required contents for complete assembly.
4. Always read the assembly instructions carefully before beginning assembly.
5. Keep all hardware parts and packaging out of reach of small children.
6. Do not over tighten the screws and bolts as this may damage the threads.

 60min	 2 People Required	IF REQUIRED  Low speed (Ø6mm)
    ADDITIONAL TOOLS REQUIRED		

WARNING




Children have died from furniture tipover.

- ALWAYS secure it with an anchor device.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heavy items down low



NEVER put a TV on this furniture




**This is a permanent label.
Do not remove!**




Item Code- 49176

Panel(Mark)	Packing carton	Quantily	Picture	Dimension
A	(Box 1)	1 PC		390 x 375 x 15 mm
B	(Box 1)	1 PC		390 x 375 x 15 mm
C	(Box 1)	1 PC		1804 x 390 x 15 mm
D	(Box 1)	1 PC		1804 x 390 x 15 mm
E	(Box 1)	1 PC		1708 x 403 x 15 mm
F	(Box 1)	1 PC		390 x 375 x 15 mm
G	(Box 1)	2 PCS		388 x 373 x 15 mm
H	(Box 1)	1 PC		375 x 90 x 15 mm
I	(Box 1)	1 PC		1714 x 402 x 3 mm


Please note - All Hardwares in box 1.

① 12 PCS  Ø10 x Ø7 x 50 mm	③ 16 PCS  Ø8 x 30 mm	④ 3 Sets  100 x 60 x 35 mm	⑤ 14 PCS  Ø4 x 14 mm	⑥ 8 PCS  Ø5 x 22 x17x 9 mm	⑦ 1 PC  115 x 10 x 30 mm	⑧ 2 PCS  Ø8 x M4 x 19 mm
⑨ 46 PCS  Ø4 x Ø2 x15 mm	⑩ 1 PC  20 x 40 x 1.2 mm	⑪ 1 PC  Ø9 x Ø6 x 25 mm	⑫ 1 PC  Ø9 x Ø4 x 15 mm	⑬ 1 PC  Ø9 x Ø4 x 25 mm	⑭ 2 PCS  40 x 20 x 2 mm	⑮ 1 PC  365 x 28 x 15 mm




1

 ③ x 16





2


 ⑤ x 2  ⑭ x 2




3



4




5




6



① x 6



7






8




9

10




11




12

15 x 1



13


⑤ x 6




14




Adjusting possibilities



- Lateral adjustment by screw adjustment



- Front-to-back by slackening the hinge-arm mounting screw



- Vertical adjustment via mounting plate(via slots or, if in two pieces,by screws)

SAFETY BRACKETS INSTRUCTIONS


This furniture poses a tipping risk and as such must be secured to a wall using the provided tipping kit.

1. Attach one Mounting plate to the wall with the Large screws. Make sure to attach the Mounting Plate into a stud. If mounting into brick or masonry you will need to acquire wall anchors. Please enquire with your local hardware supplier for appropriate fixings.
2. Attach the second Mounting Plate to the furniture frame with the Short screws .
3. Move the furniture to its final position. Thread a Wall Strap through the both mounting plates and tighten until snug. Do not over tighten.
4. Make sure that the mounting plates are firmly attached to the wall and furniture, and that the Wall Strap is snug.


HARDWARE




1 PC
20 x 40 x 1.2mm
Wall Bracket




1 PC
Ø9 x Ø6 x 25mm
Plastic Screw




1 PC
Ø9 x Ø4 x 15mm
Screw




1 PC
Ø9 x Ø4 x 25mm
Screw



15




16




17




⑩ x 1




⑫ x 1




⑬ x 1



ASSEMBLY IS COMPLETE




 on the back side of the top panel next to coo label

 WARNING		
		Children have died from furniture tipover. • ALWAYS secure it with an anchor device. • NEVER allow children to stand, climb or hang on drawers, doors, or shelves. • NEVER open more than one drawer at a time. • Place heavy items down low NEVER put a TV on this furniture  This is a permanent label. Do not remove!



Please note – Some floors could possibly not be level or flat so it is best to ensure the wardrobe carcass frame is square and level prior to fitting of doors. This might involve the use of packing material under the base.

Product Care



Our furniture is built to last. Following these steps for basic care should protect your investment for years to come

- Dust frequently with a clean damp lint-free cloth. This will help remove abrasive build up which can damage a finish over time
- Do not place hot objects on any furniture surface. Always use a hot plate or placemat.
- Avoid exposing your furniture to strong sunlight, heat outlet, open windows or dampness. Prolonged exposure to direct sunlight can fade the finish of your furniture, while extreme temperature and humidity changes can cause cracking or splitting
- Do not expose your furniture to any liquids. Never allow water to sit on your furniture. Alcohol, nail polish and perfume are also dangerous as they will dissolve the finish on contact and may require professional repairs
- Do not allow plastic to come in direct contact with your furniture. Chemicals in the plastic of placemats etc. may soften and mark the finish if left in contact with the furniture for a period of time

1