




ASSEMBLY INSTRUCTION
CHARLSBOURG ROUND COFFEE TABLE
ITEM CODE - 87487




Imported by Amart Furniture Pty Ltd, Qld, Brisbane Australia.
for any assistance to assembly or for missing parts please phone
Amart Furniture, Customer Service Freecall 1800 351 084


PRE-ASSEMBLY PREPARATION

BEFORE YOU START :

1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product
2. Take care when lifting. Product should be assembled as near as possible to the point of use
3. Ensure that you have all required contents for complete assembly
4. Always read the assembly instructions carefully before beginning assembly.
5. Keep all hardware parts and packaging out of reach of small children.
6. Do not over tighten the screws and bolts as this may damage the threads

	
ALLOW 20 MINUTES	2 PEOPLE REQUIRED
ADDITIONAL TOOLS REQUIRED	

PARTS LIST




1	TOP	1 PC	2	BOTTOM PEDESTAL	1 PC
3	TOP PEDESTAL	1 PC	4	MOUNTING PLATE	1 PC

A	BOLTS	B	BOLTS	C	SPRING WASHER	D	FLAT WASHER	E	ALLEN KEY
									
M6x40: 10 pcs		M6x30: 1 pc		M6x1.2x10: 11 pcs		M6x2x19: 11 pcs		M4x59: 1 pc	

tighten

Bolts (B),

Washer




B	BOLTS	C	SPRING WASHER	D	FLAT WASHER	E	ALLEN KEY
							
M6x30: 1 pc		M6x1.2x10: 1 pc		M6x2x19: 1 pc		M4x59: 1 pc	

Washer

tighten

Bolts (A),




A BOLTS  M6x40: 2 pcs	C SPRING WASHER  M6x1.2x10: 2 pcs	D FLAT WASHER  M6x2x19: 2 pcs	E ALLEN KEY  M4x59: 1 pc
---	---	---	--

Washer


tighten

Bolts (A),



A BOLTS  M6x40: 8 pcs	C SPRING WASHER  M6x1.2x10: 8 pcs	D FLAT WASHER  M6x2x19: 8 pcs	E ALLEN KEY  M4x59: 1 pc
---	---	---	--

ASSEMBLY COMPLETE



DO NOT PUSH OR DRAG THIS TABLE - by doing so, it may cause damage to the legs.

DO NOT SIT OR LEAN ON THE EDGE OF THE TABLE - this may cause the table to tip to one side.

Product Care:

As your timber is supplied from sustainable forests there will be natural variations in surface texture and grain like knots, mineral streaks and sap runs that may affect the finish. These differences in character are not defects, but distinctions that make each piece of furniture unique. Our furniture is built to last. Following these steps for basic care should protect your investment for years to come.

- Dust frequently with a clean damp lint-free cloth. This will help remove abrasive build up which can damage a finish over time.
- Do not place hot objects on any furniture surface. Always use a hot plate or placemat. Laminate and lacquer finishes on table tops provide added scratch and heat resistance to our furniture, but they can still be damaged without proper care.
- Avoid exposing your furniture to strong sunlight, heat outlet, open windows or dampness. Prolonged exposure to direct sunlight can fade the finish of your furniture, while extreme temperature and humidity changes can cause cracking or splitting.
- Do not expose your furniture to any liquids. Never allow water to sit on your furniture. Alcohol, nail polish and perfume are also dangerous as they will dissolve the lacquer finish on contact and may require professional repairs.
- Do not allow plastic to come in direct contact with your furniture. Chemicals in the plastic of placemats etc may soften and mark the finish if left in contact with the furniture for a period of time.