ASSEMBLY INSTRUCTION
GOMEZ 3 SEAT SOFA
ITEM CODE 88933



Imported by JWA Furniture Pty Ltd, Qld, Brisbane Australia.
For any assistance with assembly or for missing parts please refer to your receipt

PRE-ASSEMBLY PREPARATION

Before you start:

1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product
2. Take care when lifting. Product should be assembled as near as possible to the point of use
3. Ensure that you have all required contents for complete assembly
4. Always read the assembly instructions carefully before beginning assembly.
5. Keep all hardware parts and packaging out of reach of small children.

ALLOW 15 MINUTES	PEOPLE REQUIRED

ASSEMBLY DIAGRAM



TIPS:

Our frameless foam and spring sofa bodies are designed with industry-leading technology from the consumer goods sector and can restore more than 90% of their original state after **72 hours to 1 week** of decompression, so customers need to be patient. Minor wrinkles and bends are common occurrences and do not indicate quality issues.

EXTRA CAUTION WARNING
(PRODUCT DESCRIPTION)

SOFA

CAUTION:

- When repositioning or moving the sofa to a new location, lift the entire base of the sofa off the ground before relocating it. Never drag, push, pull or slide the sofa directly on the floor.
- This sofa is constructed with compressed pure sponge, featuring no leg supports or rigid load-bearing frame at the bottom. Dragging it will create friction against the floor that tugs the bottom fabric cover and easily wears through the outer upholstery. Meanwhile, the pulling force will cause the internal compressed sponge to separate, shift and collapse, resulting in permanent loss of its rebound and fluffy performance.
- When lifting, grip only the thick, solid sections of the sofa base. Do not lift the sofa solely by the backrest or edge armrests. The pure sponge material is soft by nature; lifting from one side will twist and deform the sponge, tear fabric seams, and damage the compressed shaping structure irreversibly.
- If you need to clean the floor underneath the sofa, lift the whole sofa away completely instead of sliding it across the floor.

- It is strictly prohibited to use this sofa as a step ladder or footstool. Do not stand on the seat cushion, armrest or footrest to reach items placed at height.
- Climbing the backrest, stepping on the edge of armrests, or standing with one foot on the footrest are all forbidden. The sofa is made of pure sponge with weak supporting performance; local point load will easily cause sinking and tilting.
- This sofa is only designed for normal sitting and resting. The armrests and footrest are merely auxiliary parts for resting legs and cannot bear the weight of a standing human body. Do not gather multiple people to press heavily on one side, or jump and stamp on the sofa.
- Avoid leaning against or applying sudden heavy pressure to one side of the sofa, which will unbalance the force on the sponge and lead to permanent indentation and distortion.

Product Care for Fabric Items

REGULAR CARE:

- Protect from direct sunlight
- Vacuum regularly using low suction
- Rotate reversible cushions regularly
- Avoid exposure to new clothing, cushions or throws as this may lead to dye transfer and permanent staining

CLEANING:

- Do not remove cushion covers for separate cleaning even though they may have zippers
- Do not wash, Do not dry clean, Do not shampoo clean
- Clean only with hot water extraction machine. Professional cleaning recommended
- Do not use dishwashing liquid or laundry detergent. Use only upholstery detergents
- Do not wet filling
- Dry in shade away from direct heat and sunlight
- Allow to dry thoroughly before re-use

SPOT CLEANING:

- Do not rub
- Do not spot clean with any solvent
- Treat spills and stains as soon as possible
- Gently scrape off any soil or blot any liquid from the surface of the fabric before applying cleaner
- Apply proprietary cleaning agents strictly according to instructions to remove the residue of the spill
- Do not saturate the fabric or interior with water or other cleaning liquids

WARNING:

Apply only water-based soil resist (fabric protection) treatments. Do not use aerosol products

* PILLING IS NOT A FABRIC DEFECT OR FAULT AND IS NOT COVERED BY WARRANTY
* PILLING IS A NORMAL OCCURRENCE IN WOVEN FABRICS AND DOES NOT AFFECT THE DURABILITY OR FUNCTIONALITY OF THE FABRIC. IT IS EASILY REMOVED BY USE OF A BATTERY OPERATED DE-PILLING MACHINE AS THE NEED ARISES

General Product Care

CLEANING:

To protect your furniture, we suggest the following:

- Avoid placing your furniture in direct sunlight.
- Do not place furniture directly under windows.
- Do not place sharp materials (knife, fork, etc.) directly onto your furniture as sharp material may scrape and damage the finish
- Do not place material with high temperature directly onto the surface of your furniture.
- Clean up spills quickly. Water left over a prolonged period of time may cause damage. Alcohol, perfume, nail polishes, aftershave and some medication may cause severe finish damage if not cleaned immediately.
- Use a clean, soft, dry, lint free absorbent cloth to clean your furniture. Do not use any detergent as they may contain ingredients that may react and damage the finish.