





Imported by Amart Furniture Pty Ltd, Brisbane QLD, Australia.
For any assistance with assembly or for missing parts please phone
Amart Furniture, Customer Service Freecall 1800 351 084


PRE-ASSEMBLY PREPARATION

Before you start:

1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product.
2. Take care when lifting. Product should be assembled as near as possible to the point of use.
3. Ensure that you have all required contents for complete assembly.
4. Always read the assembly instructions carefully before beginning assembly.
5. Keep all hardware parts and packaging out of reach of small children.
6. Do not over tighten the screws and bolts as this may damage the threads.




PARTS LIST




x 2





1.	sofa		2PCS	2.	Cushion		2PCS
----	------	---	------	----	---------	---	------

ASSEMBLY IS COMPLETE







PARTS LIST




3 Table Top			1PC	
4 Leg			1PC	
5 Leg			1PC	
A. Bolt	B. Bolt		C. Washer	D. Nut
				
M6*15*4PCS		M6*38*1PC		M6*5PCS
M6*1PC		M6*1PC		M6*1PC
E. Allen Key	F. Wrench			
				
M6*1PC		M6*1PC		

Step 1:

ITEMS REQUIRED


3. Table Top 1PC	4. Leg 1PC	5. Leg 1PC
		
A. Bolt	C. Washer	E. Allen Key
		
M6*15*4PCS	M6*4PCS	M6*1PC

- Attach leg (4) and leg (5) to table top (3) using bolt (A) with washer (C) .
- Insert all bolts before fully tightening .
- Tighten with allen key (E) .




Step 2:

ITEMS REQUIRED

B. Bolt  M6*38*1PC	C. Washer  M6*2PCS	D. Nut  M6*1PC	E. Allen Key  M6*1PC
F. Wrench  M6*1PC			

- Attach leg (4) to leg (5) using bolt (B) with washer (C) and nut (D).
- Insert all bolts before fully tightening .
- Tighten with allen key (E) and wrench (F).




ASSEMBLY IS COMPLETE

CAUTION:

ALWAYS LIFT YOUR PRODUCT WHEN MOVING/RELOCATING.

DO NOT DRAG. DRAGGING CAN CAUSE DAMAGE TO THE LEGS



Care and maintenance

Iron

To ensure the longevity and maintain the appearance of your iron outdoor furniture, please follow these care instructions:

1. Usage and Storage:

This item is designed for outdoor use; however, like all man-made materials, it can suffer damage if left exposed to the elements for extended periods. Iron is particularly susceptible to corrosion if its protective finish becomes damaged. To maximise its lifespan, store the furniture indoors or under cover when not in use, or use a quality outdoor furniture cover. Note: Do not store the furniture directly on grass, as ground moisture can accelerate rusting.

2. Avoid Excess Moisture:

DO NOT allow the furniture to remain wet or sit in standing water for long periods. Wipe the furniture dry immediately if it becomes wet. Prolonged exposure to moisture can lead to rust and deterioration of the protective coating.

3. Avoid Exposure to Chlorine & Salt Water:

Salt and chlorine can accelerate corrosion and cause premature deterioration of painted or powder-coated iron surfaces. This is particularly important in coastal environments, around swimming pools, or areas exposed to salt spray or heavy chlorination. Any scratches or chips in the coating should be repaired promptly to prevent rust from forming.

4. CLEANING:

Clean your furniture regularly using a soft cloth or sponge with mild soap and fresh water. Rinse thoroughly and dry completely after cleaning. Do not use abrasive cleaners, steel wool, harsh chemicals, or solvents, as these may damage the protective finish and expose the metal to corrosion.

5. Routine Inspection & Repair:

Periodically inspect your furniture for scratches, chips, or signs of rust. If you notice any damage to the coating, repair it immediately. Lightly sand the affected area with fine-grit sandpaper, wipe clean, and apply a matching touch-up paint or clear sealant to prevent rust from spreading.

Living Near the Coast? Due to a process known as aerosolisation, sea water is broken into tiny droplets by wind and waves, releasing salt particles into the air. These airborne salts settle on outdoor furniture and significantly increase the risk of corrosion over time. If you live near the coast, we recommend cleaning your furniture more frequently and using a protective cover whenever it is not in use.

By following these simple care steps, you will help keep your furniture in excellent condition and ensure it remains a beautiful and functional part of your outdoor space.

Iron furniture is a handmade product, as part of its characteristics, there will be slight variations in welds and joints.

Care and maintenance

Cushions

To keep your outdoor cushions looking their best and ensure they last, please follow these simple care instructions:

1.Sun Exposure:

Direct sunlight can cause rapid fading of the fabric. For best results, avoid exposing the cushions to direct sunlight.

2.Weather Protection: To prolong the life of your cushions, do not leave them permanently exposed to weather conditions. Leaving cushions exposed puts the product at risk of mould and mildew growth. Store them indoors or under cover when not in use.

3.Cleaning: Spot clean using a mild detergent and a damp cloth. After cleaning, dry the cushions by laying them flat in a shaded area to prevent any potential damage.

4.Handling:

- 1.Do not unzip the cushion covers.
- 2.Do not remove the cushions from their covers.
- 3.Do not put in the washing machine.
- 4.Do not tumble dry.
- 5.Do not bleach.
- 6.Do not dry clean.

By following these simple steps, you will help keep your furniture in great condition and ensure it remains a beautiful and functional part of your outdoor space. By following these simple steps, you will help keep your furniture in great condition and ensure it remains a beautiful and functional part of your outdoor space.

Care and maintenance

Wicker

Wicker is a weaving technique used to create outdoor furniture, baskets, and decorative items. It involves weaving thin, flexible strands of materials like rattan, bamboo, or synthetic materials to form intricate patterns.

To ensure the longevity and maintain the appearance of your outdoor furniture, please follow these care instructions:

1. **Usage and Storage:** This item is designed for outdoor use, but, like all man-made materials, it can suffer damage if left exposed to the elements. To extend its life, avoid prolonged exposure to weather conditions. Store the furniture indoors/under cover when not in use and use an outdoor cover (do not store on grass).
2. **Sun Exposure:** Prolonged exposure to sunlight can cause wicker to dry out and become brittle, leading to cracks and potential unravelling of the weave. Sun exposure can also cause fading. To protect your furniture from UV damage, we recommend using a furniture cover when not in use, even when stored undercover or under an awning.
3. **Moisture Management:** While wicker is made from weather-resistant materials, prolonged exposure to moisture can still lead to mould or mildew. If the furniture gets wet, dry it thoroughly to prevent moisture buildup.
4. **Cleaning:** Regular cleaning is essential to maintain the appearance of your wicker furniture. Use a soft brush or vacuum with a brush attachment to remove dust and debris. For deeper cleaning, mix mild soap with warm water and gently scrub the surface with a cloth or sponge. Rinse thoroughly and dry immediately.

By following these care instructions, you can help ensure your outdoor wicker furniture remains attractive and functional for many seasons to come.