


ASSEMBLY INSTRUCTION

SAN BERNARDO

KING SINGLE BED

70586




Imported by JWA Furniture Pty Ltd, Qld, Brisbane Australia.
For any assistance with assembly or for missing parts please refer to your receipt

PRE-ASSEMBLY PREPARATION


Before you start:

1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product
2. Take care when lifting. Product should be assembled as near as possible to the point of use
3. Ensure that you have all required contents for complete assembly
4. Always read the assembly instructions carefully before beginning assembly.
5. Keep all hardware parts and packaging out of reach of small children.
6. Do not over tighten the screws and bolts as this may damage the threads
7. Assembly is to be carried out by a competent adult(s) ONLY
8. During assembly, children should be kept away from the product due to possible risk to injury.
9. Do not use this item if any components are missing or damaged.
10. Please keep the instructions for future reference.

	
Allow 20 min	For 2 person

PARTS LIST

A M6x20mm bolts x 8pcs



B M6x30mm bolts x 11pcs




C M6x50mm bolts x 6pcs




D JCN M6x12mm nuts
x 3pcs



E M4 Allen Key x 1pc
(used with M6 bolts)




1	Headboard x 1pc	6	Cross Bar x 3pcs
2	Footboard x 1pc	7	Slat (1100mm) x 14pcs
3	Head Post x 2pcs	8	End Cap x 28pcs
4	Foot Post x 2pcs	9	Centre Bar x 1pc
5	Siderail x 2pcs		




STEP 1:

- Prepare a protected surface with a blanket or cardboard.
- Attach headboard(1) to the head post(3). Secure with 2x bolt(B) per side. Fasten with Allen Key(E).
- Repeat for the footboard(2) and foot post(4).
- Connect a side rail(5) to the head post and foot post. Secure with 2x bolt(A) per corner. Fasten with Allen Key(E).
- Repeat for the other side rail.




STEP 2:

- Attach the 3x cross bars(6) to the side rail(5), as shown below. Use 2x bolt(C) per bar. Fasten with allen key(E).
- Attach the centre bar(9) to the cross bars(6), as shown below. Thread bolt(B) from the top, in the middle of each cross bars(6), and lock with nut(D). Fasten with allen key(E).



STEP 3:

- Attach an end cap(8) onto every slat, 2 per slat(7).
- Attach the slat to the bed as shown below. Push the caps into the holes.



Assembly Is Complete



PRODUCT CARE:

FURNITURE / BED

- 1. When assembling your furniture / bed please ensure that you have checked the contents for all relevant parts.**
- 2. When tightening bolts make sure that they are fully tightened but not forced.**
- 3. When moving your fully assembled bed you must first remove the mattress and lift the frame into position, take care when lifting and always have two people handling the bed. PLEASE DO NOT DRAG THE BED as this will cause damage to the rail.**
- 4. It is advisable to use approved cleaning products when cleaning the furniture and bed frame as certain chemical based cleaners could have an adverse effect on the bed finish.**