




Imported by Amart Furniture Pty Ltd, Qld, Brisbane Australia.
for any assistance to assembly or for missing parts please phone
Amart Furniture, Customer Service Freecall 1800 351 084


PRE-ASSEMBLY PREPARATION

BEFORE YOU START :







1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product
2. Take care when lifting. Product should be assembled as near as possible to the point of use
3. Ensure that you have all required contents for complete assembly
4. Always read the assembly instructions carefully before beginning assembly.
5. Keep all hardware parts and packaging out of reach of small children.
6. Do not over tighten the screws and bolts as this may damage the threads

	
ALLOW 30 MINUTES	2 PEOPLE REQUIRED
	<p>We recommend using screw driver to put this item together. However if you choose to use a power drill it must be used on LOW SPEED (LOW TORQUE) as too much pressure could damage the product.</p>
ADDITIONAL TOOLS REQUIRED	

PARTS LIST








1	HEADBOARD	1 PC	2	FOOTBOARD	1 PC
3	SIDE RAILS	2 PCS	4	SLATS	13 PCS
5	CENTER RAIL	1 PC	6	SUPPORT LEGS	3 PCS

A	BOLTS	B	FLAT WASHER	C	SPRING WASHER	D	BOLTS	E	ALLEN KEY	F	SCREW
											
M8x30: 8 pcs		M8x2x19: 8 pcs		M8x1.2x13: 8 pcs		M6x35: 3 pcs		M4x60: 1 pc		Ø4X30: 26pcs	

Step 1 :


Attach the Side rail (3) with the Headboard (1) using Bolts (A), Flat washer (B), Spring washer (C) and tighten with Allen key (E).





A	BOLTS	B	FLAT WASHER	C	SPRING WASHER	E	ALLEN KEY
							
M8x30: 8 pcs		M8x2x19: 8 pcs		M8x1.2x13: 8 pcs		M4x60: 1 pc	

Step 2 :


Attach the Center rail (5) with the Support legs (6) using Bolts (D) and tighten with Allen key (E).



D	BOLTS	E	ALLEN KEY
			
M6x35: 3 pcs		M4x60: 1 pc	



Step 3 :

- Push the Center rail (5) with Support legs (6) into the hole of the Headboard (1).
- Slot the Center Rail (5) with Support legs (6) into the bracket of the Footboard (2).




Step 4 :

Attach the Slats (4) to the Side rails (3) with Screws (F) tighten the Screws.




F

SCREW



Ø4X30: 26pcs

ASSEMBLY COMPLETE



CAUTION:
ALWAYS LIFT YOUR BED WHEN MOVING/RELOCATING
- DO NOT DRAG.
DRAGGING CAN CAUSE THE CENTRE SUPPORT LEGS
TO BEND/BREAK.



Product : **DEANDRE QUEEN BED**

Item Code : **84776**

Product Care:

As you timber is supplied from sustainable forests there will be natural variations in surface texture and grain like knots, mineral streaks and sap runs that may affect the finish. These differences in character are not defects, but distinctions that make each piece of furniture unique. Our furniture is built to last. Following these steps for basic care should protect your investment for years to come.

- Dust frequently with a clean damp lint-free cloth. This will help remove abrasive build up which can damage a finish over time.
- Do not place hot objects on any furniture surface. Always use a hot plate or placemat. Laminate and lacquer finishes on table tops provide added scratch and heat resistance to our furniture, but they can still be damaged without proper care.
- Avoid exposing your furniture to strong sunlight, heat outlet, open windows or dampness. Prolonged exposure to direct sunlight can fade the finish of your furniture, while extreme temperature and humidity changes can cause cracking or splitting.
- Do not expose your furniture to any liquids. Never allow water to sit on your furniture. Alcohol, nail polish and perfume are also dangerous as they will dissolve the lacquer finish on contact and may require professional repairs.
- Do not allow plastic to come in direct contact with your furniture. Chemicals in the plastic of placemats etc may soften and mark the finish if left in contact with the furniture for a period of time.