


# ASSEMBLY INSTRUCTION BARBOSA 1800 OUTDOOR DINING TABLE ITEM CODE - 53366

Imported by Amart Furniture PtyLtd,QId,Brisbane Australia. For any assistance with assembly or for missing parts please phone Amart Furniture,Customer Service Freecall 1800 351 084




Imported by Amart Furniture Pty Ltd, Qld, Brisbane Australia. For any assistance with assembly or for missing parts please phone Amart Furniture, Customer Service Freecall 1800 351 084


## PRE-ASSEMBLY PREPARATION


# Before you start:

- 1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product.
- 2. Take care when lifting. Product should be assembled as near as possible to the point of use.
- 3. Ensure that you have all required contents for complete assembly.
- 4. Always read the assembly instructions carefully before beginning assembly.
- 5. Keep all hardware parts and packaging out of reach of small children.
- 6. Do not over tighten the screws and bolts as this may damage the threads.




# **PARTS LIST**






# Step 1:

## ITEMS REQUIRED




- Align holes in Table Top (1) over threads in Table Legs (2)
- Attach Table Legs (2)to Table Top(1)using Bolt (A)with Spring Washer (D)and Nut(E) and then using Bolt (B)with Spring Washer (C)and Washer (D).
- Tighten with Wrench (F) and Hexagan Key (G) ■Be careful not to over tighten the bolts.




# Step 2:


# ITEMS REQUIRED



- Place Glass (3) on top of table
- Glass is secured on table with suckers .



# **ASSEMBLY IS COMPLETE**



# Care and maintenance



#### Metal

- Item is designed for use outdoors. However we do not recommend leaving this product outside when not in use. To preserve the life of this item, avoid prolonged exposure to the elements & store inside/under cover or use an outdoor cover.
- DO NOT allow the furniture to be left in the rain or left wet for extended periods of time.
- DO NOT clean your furniture down with any harsh solvents, abrasives or chemicals.
- ▼ To remove dirt and grime, simply rinse with fresh water or periodically clean using a sponge and mild detergent solution as required

#### Wicker

- Regular vacuuming and dusting of items is recommended.
- ☑ If weave on wicker becomes lacerated/damaged, do not pull on it as this may cause unravelling.
- Prolonged exposure to the elements may cause colour fading.
- To extend the life of your product the use of an Amart approved Outdoor Furniture Cover is highly recommended. Please contact store of purchase for further details.

#### Glass

- If the glass is chipped or broken, stop using the product and consult place of purchase.
- Do not drop, drag or strike glass.
- Do not sit or stand upon the glass surface .
- Do not place very hot or cold items on the glass surface unless adequately thick table mats are used to prevent such items coming in contact with the glass.
- Do not place heavy objects on glass.
- Avoid scratching the glass or using as a chopping surface.
- Do not strike the glass with hard or pointed items.
- When cleaning the glass panels use a damp cloth with washing up liquid or soft soap if necessary. Do not use washing powders or any other substances containing abrasives since these may scratch the glass.