


ASSEMBLY INSTRUCTION

EXMOUTH

Dining Table


ITEM CODE 81568



PRE-ASSEMBLY PREPARATION






Before you start:

1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product
2. Take care when lifting. Product should be assembled as near as possible to the point of use
3. Ensure that you have all required contents for complete assembly
4. Always read the assembly instructions carefully before beginning assembly.
5. Keep all hardware parts and packaging out of reach of small children.
6. Do not over tighten the screws and bolts as this may damage the threads




 TIPPING WARNING 	
	<p>Serious or fatal injuries may occur from furniture toppling over. To help avoid this please follow the below recommendations;</p> <ul style="list-style-type: none">• Install the provided "Tipping Kit" as per the instructions• Never allow children to climb on or hang off of any part of this product• Unless specifically designed to accommodate, do not set TVs or other heavy objects on top of this product <p>IF this product has drawers:</p> <ul style="list-style-type: none">• Place the heaviest items in lowest drawers• Do not open more than 1 drawer at a time as this may cause the product to become unbalanced• Do not tamper with or remove any drawer interlocking/running system <p>Note: The use of the provided "Tipping Kit" may reduce but not necessarily eliminate the risk of furniture toppling over. Please use this product with caution.</p> <p><i>This is a permanent label. Do not attempt to remove!</i></p>

PARTS LIST


A  M8X40mm 4pcs	B  M6X50mm 4pcs	C  4pcs	D  1pc	E  1pc
--	--	---	---	--

1	Top Panel
2	Metal Frame
3	Metal Frame
4	Metal Frame
5	Metal Frame




STEP 1:

1. Attach 4 to 5 with part C at the groove position.




STEP 2:

1. Attach punching 3 to the connection of 4 and 5 as the instruction shown. After placing, twist screw A 80 % with wrench E.




STEP 3:

1. Repeat Step 2 for the remaining 3 corners.




STEP 4:

1. Attach top panel to the frame with part B.




STEP 5:

1. Fasten screw E
100%.



STEP 6:

1. Assembly complete!



To protect your furniture, we suggest the following:

- Avoid placing your furniture in direct sunlight.
- Do not place furniture directly under windows.
- Do not place sharp materials (knife, fork, etc.) directly onto your furniture as sharp material may scrape and damage the finish.
- Do not place material with high temperature directly onto the surface of your furniture.
- Clean up spills quickly. Water left over a prolonged period of time may cause damage. Alcohol, perfume, nail polishes, aftershave and some medication may cause severe finish damage if not cleaned immediately.
- Use a clean, soft, dry, lint free absorbent cloth to clean your furniture. Do not use any detergent as they may contain ingredients that may react and damage the finish.

NOTE: If the above care advise is not adhered to your product warranty may become void