


ASSEMBLY INSTRUCTION
AMBERVALE ELECTRIC LIFT RECLINER
ITEM CODE 84601



Imported by JWA Furniture Pty Ltd, Qld, Brisbane Australia.
For any assistance with assembly or for missing parts please refer to your receipt

PRE-ASSEMBLY PREPARATION

Before you start:


1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product
2. Take care when lifting. Product should be assembled as near as possible to the point of use
3. Ensure that you have all required contents for complete assembly
4. Always read the assembly instructions carefully before beginning assembly.
5. Keep all hardware parts and packaging out of reach of small children.
6. Do not over tighten the screws and bolts as this may damage the threads






WARNING

DO NOT ALLOW CHILDREN TO PLAY ON THIS MECHANISED FURNITURE OR OPERATE THE MECHANISM.LEG REST FOLDS DOWN ON CLOSING SO THAT A CHILD COULD POSSIBLY BE INJURED.ALWAYS LEAVE IN AN UPRIGHT AND CLOSED POSITION.KEEP HANDS AND FEET CLEAR OF MECHANISM.ONLY THE OCCUPANT SHOULD OPERATE IT.


PARTS LIST




A	SEAT
B	BACK CUSHION

 AX1 74x77x62cm	 BX1 78x58x23cm	 CX1	 DX1
--	--	--	---


STEP 1: Insert backrest B into bracket of Seat A, push backrest from top side to make sure both brackets well connected and in position.



STEP 2: Connect the plug D to the adapter C and get through the other end of cable of the adapter to the cable reserved on the chair, make sure each part connected well.




STEP 3: Push front button to recline chair, push rear button to close chair, keep continued pushing to lift the chair. Stop pushing at any position you want.



Press the button to turn on the power.
Press the button to activate the power mechanism.

ASSEMBLY IS COMPLETE



CARE AND MAINTENANCE

REGULAR CARE:

- Protect from direct sunlight
- Vacuum regularly using low suction
- Rotate reversible cushions regularly
- Avoid exposure to new clothing, cushions or throws as this may lead to dye transfer and permanent staining

CLEANING:

- Do not remove cushion covers for separate cleaning even though they may have zippers
- Do not wash, Do not dry clean, Do not shampoo clean
- Clean only with hot water extraction machine. Professional cleaning recommended
- Do not use dishwashing liquid or laundry detergent. Use only upholstery detergents
- Do not wet filling
- Dry in shade away from direct heat and sunlight
- Allow to dry thoroughly before re-use

SPOT CLEANING:

- Do not rub
- Do not spot clean with any solvent
- Treat spills and stains as soon as possible
- Gently scrape off any soil or blot any liquid from the surface of the fabric before applying cleaner
- Apply proprietary cleaning agents strictly according to instructions to remove the residue of the spill
- Do not saturate the fabric or interior with water or other cleaning liquids

WARNING:

Apply only water-based soil resist (fabric protection) treatments. Do not use aerosol products

* PILLING IS NOT A FABRIC DEFECT OR FAULT AND IS NOT COVERED BY WARRANTY

* PILLING IS A NORMAL OCCURRENCE CAUSED BY WEAR AND TEAR AND DOES NOT AFFECT THE DURABILITY OR FUNCTIONALITY OF THE FABRIC AND IS EASILY REMOVED

• Do not:

- Use this product as a step stool or ladder
- Failure to follow this warning could result in injury