




ASSEMBLY INSTRUCTION
AQUATA LOUNGE DINING SETTING

ITEM CODE - 68640

Imported by Amart Furniture Pty Ltd, Qld, Brisbane Australia .
For any assistance with assembly or for missing parts please phone
Amart Furniture , Customer Service Freecall 1800 351 084




Imported by Amart Furniture Pty Ltd, Qld, Brisbane Australia .
For any assistance with assembly or for missing parts please phone
Amart Furniture, Customer Service Freecall 1800 351 084


PRE-ASSEMBLY PREPARATION

Before you start:

1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product.
2. Take care when lifting. Product should be assembled as near as possible to the point of use.
3. Ensure that you have all required contents for complete assembly.
4. Always read the assembly instructions carefully before beginning assembly.
5. Keep all hardware parts and packaging out of reach of small children.
6. Do not over tighten the screws and bolts as this may damage the threads.

	
ALLOW 20 MINUTES	PEOPLE REQUIRED
ADDITIONAL TOOLS REQUIRED	

PARTS LIST



11. Table top  1PC	12. Fixed link  2PCS
13. Legs  2PCS	14. Glass  1PC


A. Bolt  M6*15*4PCS	B. Bolt  M6*30*8PCS	C. Shim  M6*12PCS	D. Hexagon key  M6*1PC
---	---	--	--

Step 1:

ITEMS REQUIRED

11. Table top 1PC 	13. Legs 2PCS 	
A. Bolt  M6*15*4PCS	C. Shim  M6*4PCS	D. Hexagon key  M6*1PC

- Attach legs (13) to table top (11) using bolt (A) and shim (C) .
- Insert all bolts before fully tightening.
- Tighten with hexagon key (D) .




Step 2:

ITEMS REQUIRED


12. Fixed link 2PCS 		
B. Bolt  M6*30*8PCS	C. Shim  M6*8PCS	D. Hexagon key  M6*1PC

- Attach fixed link (12) to legs (13) using bolt (B) and shim (C).
- Insert all bolts before fully tightening.
- Tighten with hexagon key (D).




Step 3:


ITEMS REQUIRED



- Turn over the table frame.
- Place glass (14) on the top of the table.
- Glass is secured on the table with suckers.



ASSEMBLY IS COMPLETE



Care and maintenance



Metal

- ☒ Item is designed for use outdoors. However we do not recommend leaving this product outside when not in use. To preserve the life of this item, avoid prolonged exposure to the elements & store inside/under cover or use an outdoor cover.
- ☒ DO NOT allow the furniture to be left in the rain or left wet for extended periods of time.
- ☒ Wipe furniture Dry immediately after it becoming wet.
- ☒ DO NOT clean your furniture down with any harsh solvents, abrasives or chemicals.
- ☒ To remove dirt and grime, simply rinse with fresh water or periodically clean using a sponge and mild detergent solution as required

Wicker

- ☒ Regular vacuuming and dusting of items is recommended.
- ☒ If weave on wicker becomes lacerated/damaged, do not pull on it as this may cause unravelling.
- ☒ Prolonged exposure to the elements may cause colour fading.
- ☒ To extend the life of your product the use of an Amart approved Outdoor Furniture Cover is highly recommended. Please contact store of purchase for further details.

Glass

- ☒ If the glass is chipped or broken, stop using the product and consult place of purchase .
- ☒ Do not drop, drag or strike glass .
- ☒ Do not sit or stand upon the glass surface .
- ☒ Do not place very hot or cold items on the glass surface unless adequately thick table mats are used to prevent such items coming in contact with the glass .
- ☒ Do not place heavy objects on glass .
- ☒ Avoid scratching the glass or using as a chopping surface .
- ☒ Do not strike the glass with hard or pointed items .
- ☒ When cleaning the glass panels use a damp cloth with washing up liquid or soft soap if necessary. Do not use washing powders or any other substances containing abrasives since these may scratch the glass.