



ASSEMBLY INSTRUCTION


CALISTO QUEEN LIFT BED

ITEM CODE 79658

Imported by Amart Furniture Pty Ltd.Qld.Brisbane Australia.

For any assistance with assembly or for missing parts please phone

Amart Furniture, Customer Service Free call 1800 351 084



Imported by Amart Furniture Pty Ltd.Qld.Brisbane Australia.


For any assistance with assembly or for missing parts please phone Amart Furniture
Customer Service Free call 1800 351 084

79658

PRE-ASSEMBLY PREPARATION

Before you start:

1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product
2. Take care when lifting. Product should be assembled as near as possible to the point of use
3. Ensure that you have all required contents for complete assembly.
4. Always read the assembly instructions carefully before beginning assembly.
5. Keep all hardware parts and packaging out of reach of small children.
6. Do not over tighten the screws and bolts as this may damage the threads



WARNING

Do not allow children to play on this mechanised furniture or operate the mechanism. Children should always be supervised when using furniture. Always ensure that the locking mechanism is utilised during the operation of this furniture. Please keep your body clear of the mechanism when opening and closing-a failure to do this could result in serious injury.

CAM Lock and Pins


step 1

HOW TO USE CAM LOCK FASTENERS


To assemble this product hardware called Cam Lock Fasteners are used.

The below is information on how these work.

Cam Locks are fasteners used to join two boards together, usually the edge of one board(A) to the flat side of another board(B)



Ensure that you use the correct images that are representative of the hardware used in the product




step 2

To use Cam Lock Fasteners

The Cam Pin is inserted into the flat side of a board, it is important that:


- * The cam pin is kept vertical and is not put in on an angle
- * Cam Pin is inserted up to the collar
 - * Too far and it wont catch the Cam Lock (Do not Over Tighten)
 - * Not enough and the resulting product wont be stable



step 3

To use Cam Lock Fasteners

Now fit the hole in the edge of the joining board over the Cam Pin




step 4

To use Cam Lock Fasteners


The Head of the Cam Pin will be visible in the large hole on the side of the joining board

head of the Cam Pin



To use Cam Lock Fasteners

Notice the Cam Lock has a "C" Shaped back An Arrow or +/- signs on the front, indicated the open section on the back of the Cam Pin



Cam Lock

step 5


To use Cam Lock Fasteners

In sert the Cam Lock into the large hole so the opening of the "C" fits over the head of the Cam Pin. You must ensure that the Cam Lock is pushed to the bottom of the hole to catch the top of the Cam Pin

Arrow or +/- signs

head of the Cam Pin


Open section of back fits over the head of the Cam Pin




step 6

To use Cam Lock Fasteners





















Use a flat screwdriver to turn the Cam Lock clockwise one half a turn so it Locks onto the head of the Cam Pin. Turn only until it is snug-over-tightening could cause the Cam to bend or break. If it will not turn the full amount, turn the Cam Pin out (counter-clockwise) one full turn, and try the Cam Lock again.




PARTS LIST




C1	Front Rail	C13	Left Side Panel
C2	Headboard Front Panel	C14	Right Side Panel
C3	Headboard Left Panel	C15	FootboardC
C4	Hearboard Right Panel	C16	Middle Support Panel
C5	Middle Support Panel	C17	Middle Support Panel
C6	Headboard Top Panel	C18	Rail
C7	Headboard Bottom Panel	C19	Rail
C8	Shelf Panel	C20	Rail
C9	Headboard Back Panel	C21	Bottom Panel
C10	Left Side Panel	C22	Slats
C11	Right Side Panel	C23	Handle
C12	Footboard	C24	Gas Lift

<input type="checkbox"/> A.Cam lock and Cam pin Ø15X35	<input type="checkbox"/> B.Dowel Ø8X30	<input type="checkbox"/> C.Screw Ø3X18	<input type="checkbox"/> D.Connector	<input type="checkbox"/> E.Glue	<input type="checkbox"/> F.Bolt M8x90	<input type="checkbox"/> G.Bolt M8x20
 77PCS	 42PCS	 8PCS	 8PCS	 1PCE	 4PCS	 8PCS
<input type="checkbox"/> H.Bolt M6x50	<input type="checkbox"/> I.Bolt M6x35	<input type="checkbox"/> J.Half Round Nuts M8	<input type="checkbox"/> K.Hexagonal Nuts M8	<input type="checkbox"/> L.Hexagonal Nuts M6	<input type="checkbox"/> M:Wrench M14	<input type="checkbox"/> N:Wrench M10
 10PCS	 14PCS	 4PCS	 4PCS	 6PCS	 1PCE	 1PCE
<input type="checkbox"/> O.Washer Ø13	<input type="checkbox"/> P.Washer Ø16	<input type="checkbox"/> Q.Hex Key 5MM	<input type="checkbox"/> R.Hex Key 4MM	<input type="checkbox"/> S.Cover Ø38	<input type="checkbox"/> T.Protect foam 20x14x5mm	
 16PCS	 8PCS	 1PCE	 1PCE	 4PCS	 20PCS	


Step 1: Insert the Dowel(B) into the Middle Support Panel(C5) and Headboard Bottom Panel(C7) and Middle Support Panel(C16) and Middle Support Panel(C17) and Left Side Panel(C10) and Right Side Panel(C11). Use Phillips Head Screw to insert the Cam Pin(A) to the Headboard Bottom Panel(C7).




Step 2: Insert the Dowel(B) into the Headboard Left Panel(C3) and Headboard Right Panel(C4) and Headboard Top Panel(C6) and Shelf Panel(C8) and Footboard(C15). Use Phillips Head Screw to insert the Cam Pin(A) to the Headboard Left Panel(C3) and Headboard Right Panel(C4) and Headboard Top Panel(C6) and Headboard Bottom Support Panel(C8) and Footboard(C15) and Rail(C19/C20).




Step 3: Use Phillips Head Screw to insert the Cam Pin(A) to the Headboard Front Panel(C2) and Headboard Front Panel(C1) and Footboard (C12). And turn over the the Headboard Bottom Panel(C2) to insert the Cam Pin(A).




Step 4: Insert the Dowel(B) into the Left Side Panel(C13) and the Right Side Panel(C14). And use Phillips Head Screw to insert the Cam Pin(A) to the Left Side Panel(C13) and the Right Side Panel(C14)




Step 5: Attach the Middle Support Panel(C5) to the Headboard Bottom Panel(C7) and the Shelf Panel(C8). And use a Phillips Head Screw to turn the Cam Lock(A) to lock into the head of the Cam Pin(A).




Step 6: Attach the Headboard Left Panel(C3) and Headboard Right Panel(C4) to the Headboard Bottom Panel(C7) and the Shelf Panel(C8). And use a Phillips Head Screw to turn the Cam Lock(A) to lock into the head of the Cam Pin(A).




Step 7: Insert the Headboard Back Panel(C9) to the groove.




Step 8: Attach the Headboard Top Panel(C6) to the Headboard Left Panel(C3) and Headboard Right Panel(C4). And use a Phillips Head Screw to turn the Cam Lock(A) to lock into the head of the Cam Pin(A).




Step 9: Attach the Front Rail(C1) to the Headboard Top Panel(C6) and the Headboard Left Panel(C3) and Headboard Right Panel(C4).And use a Phillips Head Screw to turn the Cam Lock(A) to lock into the head of the Cam Pin(A).




Step 10: Attach the Headboard Front Panel(C2) to the Headboard Left Panel(C3) and Headboard Right Panel(C4).And use a Phillips Head Screw to turn the Cam Lock(A) to lock into the head of the Cam Pin(A).




Step 11: Use a Phillips Head Screw to attach the Connector(D) to the back corner with Screw(C).




Step 12: Attach the Middle Support Panel(C17) to the Rail(C20) and attach the Footboard(C15) to the Rail(C18). And use a Phillips Head Screw to turn the Cam Lock(A) to lock into the head of the Cam Pin(A).




Step 13: Insert Middle Support Panel(C16) to the groove.Use a Phillips Head Screw to turn the Cam Lock(A) to lock into the head of the Cam Pin(A).




Step 14: Attach the Right Side Panel(C14) to the Rail(C18/19) and the Middle Support Panel(C17) and Footboard(C15).Use a Phillips Head Screw to turn the Cam Lock(A) to lock into the head of the Cam Pin(A).



Step 15: Attach the Left Side Panel(C13)to the Rail(C18/19) and the Middle Support Panel(C17) and Footboard(C15).Use a Phillips Head Screw to turn the Cam Lock(A) to lock into the head of the Cam Pin(A).




Step 16: Align the Dowels(B) in the Headboard to the Left Side Panel(C13) and the Right Side Panel(C14). Use Wrench(M) and Hey key(Q)to secure Bolt(F) and Half Round Nuts(J) and Hexagonal Nuts(K).




79658


Step 17: Attach Left Side Panel(C10) and Right Side Panel(C11) to the Headboard.
Use a Phillips Head Screw to turn the Cam Lock(A) to lock into the head of the Cam Pin(A).




Step 18: Attach the Footboard(C12) to the Left Side Panel(C10) and Right Side Panel(C11).
Use a Phillips Head Screw to turn the Cam Lock(A) to lock into the head of the Cam Pin(A).




Step 19: Use Hex key(R) to secure Bolt(I) to tighten the Left Side Panel(C10) and Right Side Panel(C11).




Step 20: Use Hex Key(Q) to attach the Gas Lift(C24) to the Left Side Panel(C13) and the Right Side Panel(C14) with Bolt(G) and Washer(P).




Step 21: Use Hex Key(R) to attach the Handle(C23) to the Slats(C22) with Bolt(H) and Washer(O).




Step 22: Use Hex Key(R) and Wrench(N) to attach Slats(C22) and Gas Lift(C23) with Bolt(H) and Washer(O).



Step 23: Put Bottom Panel(C21) into the Bedframe.



Assembly is complete



IMPORTANT NOTE:

Once the bed is positioned and the support legs are adjusted to touch floor , the slats can then be laid down and secured before putting on the mattress. **DO NOT** push or pull the bed if there is a need for re-positioning as this may result in broken support legs for the centre rail.

79658

IMPORTANT: CARE GUIDE FOR YOUR HI-GLOSS FURNITURE

Congratulations! You have just purchased a quality product from Amart Furniture, Australia's largest discount furniture retail store. Please read on for important information regarding your purchase...

Hi-gloss lacquered furniture is more sensitive to marks and scratching than some other furniture products. It is important to exercise caution and care to maximise the life and beauty of this product.

Following the below simple guidelines when using your hi-gloss product will protect your investment for years to come:

- Dust frequently with a clean damp, lint-free cloth. This will help remove abrasive build up which can damage a finish over time.
- Avoid using chemicals or solvents when cleaning the product.
- Do not place hot objects on any furniture surface. Always use a hot plate or placemat. Lacquer finishes provide added scratch and heat resistance to our furniture, but they can still be damaged without proper care.
- Avoid exposing your furniture to strong sunlight. Prolonged exposure to direct sunlight can fade the finish of your furniture.
- Do not expose your furniture to any liquids. Avoid allowing water to sit on your furniture. Alcohol, nail polish and perfume are particularly harmful as they will dissolve the lacquer finish on contact.
- Do not allow plastic to come in direct contact with your furniture. Chemicals in the plastic of some placemats etc may soften and mark the finish if left in contact with the furniture for a period of time.
- Avoid placing sharp or rough objects on the surface of your furniture. These may scratch the surface of the product.
- When moving your furniture, do not drag it across the floor. This may damage the product. Instead use two people to lift carefully with caution from either end.