


## ASSEMBLY INSTRUCTION

### CAPTAIN JACK TRUNDLE BED

ITEM CODE : 55251

Imported by Amart Furniture Pty Ltd, Qld, Brisbane Australia.  
For any assistance with assembly or for missing parts please phone  
Amart Furniture Pty Ltd Customer Service Free call 1800 351 084





Imported by Amart Furniture Pty Ltd, Qld, Brisbane Australia.  
For any assistance with assembly or for missing parts please phone  
Amart Furniture Pty Ltd, Customer Service Free call 1800 351 084


## PRE-ASSEMBLY PREPARATION

### Before you start:

1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product.
2. Take care when lifting. Product should be assembled as near as possible to the point of use.
3. Ensure that you have all required contents for complete assembly.
4. Always read the assembly instructions carefully before beginning assembly.
5. Keep all hardware parts and packaging out of reach of small children.
6. Do not over tighten the screws and bolts as this may damage the threads.

|  |   |
|--|---|
|   |   |
| ALLOW 45 MINUTES   | 2 PERSON REQUIRED   |
|  |  |
| ADDITIONAL TOOLS REQUIRED  | NO POWER DRILL  |



# PART LIST



|    |                             |      |     |                             |      |
|----|-----------------------------|------|-----|-----------------------------|------|
| 1  | HEADBOARD                   | (X1) | 9   | CENTER SUPPORTER            | (X1) |
| 2  | FOOTBOARD                   | (X1) | 10  | WOODEN SLAT (64 x 912 = 12) | (X1) |
| 3  | SIDE RAIL                   | (X2) | 11  | DRAWER FACE                 | (X3) |
| 4  | WOODEN SLAT (64 x 912 = 12) | (X1) | 12L | DRAWER SIDE - L             | (X3) |
| 5  | FRONT FRAME                 | (X1) | 12R | DRAWER SIDE - R             | (X3) |
| 6  | REAR FRAME                  | (X1) | 13  | DRAWER REAR                 | (X3) |
| 7L | SIDE PANEL - L              | (X1) | 14  | DRAWER BASE                 | (X3) |
| 7R | SIDE PANEL - R              | (X1) | 15  | DRAWER BASE SUPPORT         | (X3) |
| 8  | DRAWER SUPPORTER            | (X2) |     |                             |      |

## HARDWARE LIST

### PACK 1 : CAPTAIN BED (CTN 3 OF 3)


|   |  |  |
|---|--|--|
| <p><b>A. PLASTIC DOWEL (M10 x 35MM)</b></p> <div style="text-align: center;">  </div> <p style="text-align: right;"><b>4 PCS</b></p> | <p><b>B. JCBC BOLT (M6 x 60MM)</b></p> <div style="text-align: center;">  </div> <p style="text-align: right;"><b>8 PCS</b></p> | <p><b>C. JRN NUT (M6 x 13MM)</b></p> <div style="text-align: center;">  </div> <p style="text-align: right;"><b>8 PCS</b></p> |
| <p><b>D. CSK C/B SCREW (M4 x 32MM)</b></p> <div style="text-align: center;">  </div> <p style="text-align: right;"><b>6 PCS</b></p>  | <p><b>E. ALLEN KEY (M4 x 60MM)</b></p> <div style="text-align: center;">  </div> <p style="text-align: right;"><b>1 PC</b></p>  |  |

### PACK 2 : TRUNDLE BED (CTN 3 OF 3)

|   |   |   |
|---|---|---|
| <p><b>F. PLASTIC DOWEL (M6 x 30MM)</b></p> <div style="text-align: center;">  </div> <p style="text-align: right;"><b>36 PCS</b></p> | <p><b>G. JCBC BOLT (M6 x 35MM)</b></p> <div style="text-align: center;">  </div> <p style="text-align: right;"><b>12 PCS</b></p>       | <p><b>H. CONNECTING BOLT (34MM)</b></p> <div style="text-align: center;">  </div> <p style="text-align: right;"><b>6 PCS</b></p> |
| <p><b>J. MINIFIX (9MM)</b></p> <div style="text-align: center;">  </div> <p style="text-align: right;"><b>6 PCS</b></p>            | <p><b>K. CSK C/B SCREW (M4 x 32MM)</b></p> <div style="text-align: center;">  </div> <p style="text-align: right;"><b>16 PCS</b></p> | <p><b>L. ALLEN KEY (M4 x 60MM)</b></p> <div style="text-align: center;">  </div> <p style="text-align: right;"><b>1 PC</b></p> |


## STEP 1 - CAPTAIN BED

Insert **Dowels (A)** into  $\varnothing$ 10MM holes on **Side Rails** by using a Rubber Hammer.



## STEP 2 - CAPTAIN BED


Attach **Side Rails** to **Headboard & Footboard** by using **Bolts (B)** and **Nuts (C)**, tighten it up by using an **Allen Key (E)**.



### STEP 3 - CAPTAIN BED


Attach **Wooden Slats** onto **Side Rails** by using **Screws (D)**, tighten it up by using a Crosshead Screw Driver. Go on to complete the **Assembly**.

\*Align both **Side Rails** before tightening the screws.




## STEP 4 - TRUNDLE BED

Attach **Side Panels** to **Front** and **Rear Frames** by using **Bolts (G)**, tighten it up by using an **Allen Key (L)**.




## STEP 5 - TRUNDLE BED

Attach **Drawer Supporters** to **Front** and **Rear Panels** by using **Bolts (G)**, tighten it up by using an **Allen Key (L)**.



## STEP 6 - TRUNDLE BED


Attach **Center Supporter** to bed frame by using **Screws (K)** and tighten it up by using a Crosshead Screw Driver.



## STEP 7 - TRUNDLE BED


Attach the **Wooden Slats** onto the slat supporters by using **Screws (K)** and tighten it up by using a Crosshead Screw Driver.

\*Align both **Front & Rear Frame** before tightening the screws.




## STEP 8 - TRUNDLE BED

Attach **Drawer Sides** to **Drawer Rear** by using **Dowels (F)** and **Screws (K)**, tighten it up by using a Crosshead Screw Driver.




## STEP 9 - TRUNDLE BED

Attach **Drawer Base Support** to **Drawer Rear** by using **Dowels (F)**.




## STEP 10 - TRUNDLE BED

Slot Drawer Base into Drawer Sides.




## STEP 11 - TRUNDLE BED

Attach Drawer Face to Drawer Sides by using Dowels (F), Connecting Bolts (H) and Minifix (J).




## STEP 12 - TRUNDLE BED

Insert **Drawers** into **Bed Frame** and complete the assembly.



## STEP 13 - TRUNDLE BED

Slot entire **Trundle Bed** under previously assembled **Captain Bed**.




\* Trundle Bed can be assembled either side.

## ASSEMBLY IS COMPLETE

### CAUTION

ALWAYS LIFT YOUR BED WHEN MOVING/RELOCATING-DO NOT DRAG.  
DRAGGING CAN CAUSE DAMAGE TO THE BED



## **IMPORTANT : PRODUCT CARE FOR TIMBER ITEMS**

As our timber is supplied from sustainable forests there will be natural variations in surface texture and grain like knots, mineral streaks and sap runs that may affect the finish. These differences in character are not defects, but distinctions that make each piece of furniture unique.

Our furniture is built to last. Following these steps for basic care should protect your investment for years to come.

- Dust frequently with a clean damp lint-free cloth. This will help remove abrasive build up which can damage a finish over time.
- Do not place hot objects on any furniture surface. Always use a hot plate or placemat. Laminate and lacquer finishes on table tops provide added scratch and heat resistance to our furniture, but they can still be damaged without proper care.
- Avoid exposing your furniture to strong sunlight, heat outlet, open windows or dampness. Prolonged exposure to direct sunlight can fade the finish of your furniture, while extreme temperature and humidity changes can cause cracking or splitting.
- Do not expose your furniture to any liquids. Never allow water to sit on your furniture. Alcohol, nail polish and perfume are also dangerous as they will dissolve the lacquer finish on contact and may require professional repairs.
- Do not allow plastic to come in direct contact with your furniture. Chemicals in plastic of placemats etc. may soften and mark the finish if left in contact with the furniture for a period of time.