




ASSEMBLY INSTRUCTION

COLWYN BAY BEDSIDE TABLE

ITEM CODE 82504



Imported by Amart Furniture Pty Ltd.Qld.Brisbane Australia.

For any assistance with assembly or for missing parts please phone Amart Furniture
Customer Service Free call 1800 351 084


PRE-ASSEMBLY PREPARATION

Before you start:















1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product
2. Take care when lifting. Product should be assembled as near as possible to the point of use
3. Ensure that you have all required contents for complete assembly.
4. Always read the assembly instructions carefully before beginning assembly.
5. Keep all hardware parts and packaging out of reach of small children.
6. Do not over tighten the screws and bolts as this may damage the threads

 <p>ALLOW 30 MINUTES</p>	 <p>2 PEOPLE REQUIRED</p>	
<p>! WARNING</p>		
		<p>Children have died from furniture tipover.</p> <ul style="list-style-type: none">• ALWAYS secure it with an anchor device.• NEVER allow children to stand, climb or hang on drawers, doors, or shelves.• NEVER open more than one drawer at a time.• Place heavy items down low <p>NEVER put a TV on this furniture </p> <p><small>This is a permanent label. Do not remove!</small></p>

PARTS LIST




C1	Top Panel	C7	Drawer Left Side Panel
C2	Bottom Panel	C8	Drawer Right Side Panel
C3	Left Side Panel	C9	Drawer Back Panel
C4	Right Side Panel	C10	Drawer Bottom Panel
C5	Back Panel	C11	Leg
C6	Drawer Front Panel	C12	Leg

<input type="checkbox"/> A. Cam lock and Cam pin Ø15X35  16PCS	<input type="checkbox"/> B. Dowel Ø8x30  12PCS	<input type="checkbox"/> C. Screw Ø3.5x12  24PCS	<input type="checkbox"/> D. Screw Ø3.5x30  8PCS	<input type="checkbox"/> E. Bolt M4x20  4PCE	<input type="checkbox"/> F. Connector 18x16x10  4PCS	<input type="checkbox"/> G. Screw Ø3x18  4PCS
<input type="checkbox"/> H. Bolt M6x35  10PCS	<input type="checkbox"/> I. Hex key M4  1PCE	<input type="checkbox"/> J. Runner 250mm  4PCS	<input type="checkbox"/> K. Protect foam Ø35x5  4PCS	<input type="checkbox"/> L. GLUE  1PCE	<input type="checkbox"/> M. Safety Bracket Kit  1PCS	<input type="checkbox"/> N. Handle  2PCS

STEP 1:


Runner slide separately ($K=K1+K2$)

Carefully pull out the runner slide ($K2$) and press plastic clip to fully separate runner slide as diagram shown




STEP 2:

Insert Cam Pin(A) and Bowel(B) to Panel(C1&C2&C3&C4&C6). Attach Runner(K1) to Panel(C3&C4) with Screw(C).




STEP 3:

Attach Panel(C3&C4) to Panel(C2). And turn Cam Lock(A) to lock into the head of Cam Pin(A).




STEP 4:

Use Hex Key(I) to attach Leg(C11&C12) to Panel(C2) with Bolt(H). Then attach Protect Foam(K) to Panel(C11&C12).




STEP 5:

Insert Back Panel(C5) to the groove. □




STEP 6:

Attach Panel(C1) to Panel(C3&C4). And turn Cam Lock(A) to lock into the head of Cam Pin(A).




STEP 7:

Attach Connector(F) to back corner with Screw(G).



STEP 8:


Attach Panel(C7&C8) to Panel(C6). And turn Cam Lock(A) to lock into the head of Cam Pin(A). Insert Panel(C10) to groove. Then attach Panel(C9) to Panel(C7&C8) with Screw(D).



82504


STEP 9:

Attach Runner(K2) to Panel(C7&C8) with Screw(C). And attach Handle(N) to Panel(C6) with Bolt(E).




STEP 10:

Insert drawers into the body. Please insert the drawer with Tit Kip Label into Top drawer slot.



Assembly is complete



SAFETY BRACKETS INSTRUCTIONS

This furniture poses a tipping risk and as such must be secured to a wall using the provided tipping kit.

1. Attach one Mounting Plate to the wall with the Large Screws. Make sure to attach the Mounting Plate into a stud. If mounting into brick or masonry you will need to acquire wall anchors. Please enquire with your local hardware supplier for appropriate fixings.
2. Attach the second Mounting Plate to the furniture frame with the Short Screws.
3. Move the furniture to its final position. Thread a Wall Strap through the both Mounting Plates and tighten until snug. Do not over tighten.
4. Make sure that the Mounting Plates are firmly attached to the wall and furniture and that the Wall Strap is snug.

HARDWARE



Mounting Plate x 2




Wall Strap x 1



Large Screw x2



Small Screw x2



PRODUCT CARE:

To protect your furniture, we suggest the following:

- Avoid placing your furniture in direct sunlight.
- Do not place furniture directly under windows.
- Do not place sharp materials (knife, fork, etc.) directly onto your furniture as sharp material may scrape and damage the finish.
- Do not place material with high temperature directly onto the surface of your furniture.
- Clean up spills quickly. Water left over a prolonged period of time may cause damage. Alcohol, perfume, nail polishes, aftershave and some medication may cause severe finish damage if not cleaned immediately.
- Use a clean, soft, dry, lint free absorbent cloth to clean your furniture. Do not use any detergent as they may contain ingredients that may react and damage the finish.
- NOTE: If the above care advise is not adhered to your product warranty may become void