




ASSEMBLY INSTRUCTION

VESPERA QUEEN BED

ITEM CODE 85176






Imported by Amart Furniture Pty Ltd.Qld.Brisbane Australia.
For any assistance with assembly or for missing parts please phone Amart Furniture
Customer Service Free call 1800 351 084

85176

PRE-ASSEMBLY PREPARATION

Before you start:

- 1. Choose a clean,level.spacious assembly area.Avoid hard surfaces that may damage the product
- 2. Take care when lifting.Product should be assembled as near as possible to the point of use
- 3. Ensure that you have all required contents for complete assembly.
- 4. Always read the assembly instructions carefully before beginning assembly.
- 5. Keep all hardware parts and packaging out of reach of small children.
- 6. Do not over tighten the screws and bolts as this may damage the threads

 ALLOW TWO HOUSE	 x 2 2 PEOPLE REQUIRED
 ADDITIONAL TOOLS REQUIRED	



WARNING





Do not allow children to play on this mechanised furniture or operate the mechanism. Ensure that the mattress and lift mechanism has been returned to the lowered position before lying or sitting on the mattress. Always ensure that your body is clear of the lift mechanism when lifting and lowering the mechanism

CAM Lock and Pins

step 1

HOW TO USE CAM LOCK FASTENERS

To assemble this product hardware called Cam Lock Fasteners are used.
The below is information on how these work.
Cam Locks are fasteners used to join two boards together,
usually the edge of one board(A) to the flat side of another board(B)




Ensure that you use the correct images that are representative of the hardware used in the product

step 2

To use Cam Lock Fasteners

The Cam Pin is inserted into the flat side of a board, it is important that:


- * The cam pin is kept vertical and is not put in on an angle
- * Cam Pin is inserted up to the collar
 - * Too far and it wont catch the Cam Lock (Do not Over Tighten)
 - * Not enough and the resulting product wont be stable



step 3

To use Cam Lock Fasteners


Now fit the hole in the edge of the joining board over the Cam Pin



step 4

To use Cam Lock Fasteners

The Head of the Cam Pin will be visible in the large hole on the side of the joining board



To use Cam Lock Fasteners

Notice the Cam Lock has a "C" Shaped back An Arrow or +/- signs on the front, indicated the open section on the back of the Cam Pin




Cam Lock

step 5

To use Cam Lock Fasteners


In sert the Cam Lock into the large hole so the opening of the "C" fits over the head of the Cam Pin.You must ensure that the Cam Lock is pushed to the bottom of the hole to catch the top of the Cam Pin




step 6

To use Cam Lock Fasteners




























Use a flat screwdriver to turn the Cam Lock clockwise one half a turn so it Locks onto the head of the Cam Pin.Turn only until it is snug-over-tightening could cause the Cam to bend or break. If it will not turn the full amount,turn the Cam Pin out (counter-clockwise)one full turn,and try the Cam Lock again.




PARTS LIST




C1	Headboard Top Rail	C18	Footboard Leg
C2	Headboard Top Panel	C19	Footboard Leg
C3	Headboard Back Panel	C20x2	Bottom Rail
C4	Headboard Shelf Panel	C21x4	Bottom Rail
C5	Headboard Back Panel	C22x4	Bottom Rail
C6	Headboard Support Panel	C23	Bottom Front Panel
C7	Headboard Shelf Panel	C24	Drawer Leftside Panel
C8	Headboard Front Panel	C25	Drawer Rightside Panel
C9	Headboard Left Side Panel	C26	Drawer Connect panel
C10	Headboard Right Side Panel	C27	Drawer Back Panel
C11	Left Side Rail	C28	Drawer Bottom Panel
C12	Right Side Rail	C29x4	Bottom Panel
C13	Middle Support Panel	C30	Gas Lift
C14	Support Panel	C31	Gas Lift
C15x2	Connect Panel	C32x2	Lifting Handle
C16	Connect Panel	C33	Slat
C17	Connect Panel	C34x2	Headboard Door Panel

<input type="checkbox"/> A.Cam lock and Cam pin Ø15X35  84PCS	<input type="checkbox"/> B.Dowel Ø8X30  36PCS	<input type="checkbox"/> C.Bolt M8x80  6PCS	<input type="checkbox"/> D.Half Round Nuts M8  10PCS	<input type="checkbox"/> E.Hexagonal Nuts M8  16PCS	<input type="checkbox"/> F.Cover Ø38  10PCS	<input type="checkbox"/> G.Wrench M14  1PCE
<input type="checkbox"/> H.Screw Ø3.5X16  42PCS	<input type="checkbox"/> I.Screw Ø3.5X30  10PCS	<input type="checkbox"/> J.Screw Ø3X18  8PCS	<input type="checkbox"/> K.Connector 18x16x10  8PCS	<input type="checkbox"/> L.Bolt M6x45  4PCS	<input type="checkbox"/> M.Bolt M8x20  8PCS	<input type="checkbox"/> N.Bolt M8x50  6PCS
<input type="checkbox"/> O.Bolt M8x80  4PCS	<input type="checkbox"/> P.Hex Key 4MM  1PCE	<input type="checkbox"/> Q.Hex Key 5MM  1PCE	<input type="checkbox"/> R.Washer M8  4PCS	<input type="checkbox"/> S.Wheel  5PCS	<input type="checkbox"/> T.Hinge  4PCS	<input type="checkbox"/> U. Hinge  2PCS
<input type="checkbox"/> V.Power Adapter  1PCS	<input type="checkbox"/> W.Glue  1PCE	<input type="checkbox"/> X.Protect foam 20x14x5mm  30PCS	<input type="checkbox"/> Y.Clip&Sticker  4PCS	<input type="checkbox"/> Z. Led Connect wire  1PCS	<input type="checkbox"/> Z1. Led Bottom  1PCS	


STEP 1: Use Phillips Head Screwdrive to attach Cam Pin(A) and Dowel(B) to Panel (C3,C4,C8,C14,C18,C19,C22).Insert the Bolt(C) to the Footboard Leg(C18,C19).Dower with Glue(W).Stick the Protect Foam(T) to the Panel(C3,C4,C8,C14,C18,C19).



Step 2: Use Phillips Head Screwdriver to attach Cam Pin(A) to Panel(4,C7,C9,C10,C23,C24,C25, 27,C28)
Insert the Dowel(B) to the Panel(C9,C10,C4,C7) with Glue(W).






Step 3: Use Phillips Head Screwdriver to assemble Headboard Top Rail(C1) to Headboard Top Panel(C2) with Cam Lock(A).assemble Headboard Support (C6) to Panel(C4,C7) with Cam Lock(A).Assemble Headboard Shelf(C7) to the Headboard Front Panel(C8) with Cam Lock(A).






85176

Step 4: Use Phillips Head Screwdriver to assemble Panel(C1,C2,C4,C7,C8) to the Headboard Right Side Panel(C10) with Cam Lock(A).Dowel with Gule(W).




Step 5: Insert the Headboard Back Panel(C3,C5) to the Groove.
Use Phillips Head Screwdriver to assemble Panel(C1,C2,C4,C7,C8) to the Headboard Left Side Panel(C9) with Cam Lock(A).Dowel with Gule(W).




Step 6: Insert the Led Botton(Z1) to the Headboard Shelf Panel(C7).

Use Phillips Head Screwdrive to assemble Hinge(T) to the Door Panel(C34) and Headboard Shelf Panel(C7) with Screw(H),assemble the Hinge(U) to the Door Panel(C34) and Headboard Support Panel(C6) with Screw (H).




Step 7: Use Wrench (G)ssemble the Connect Panel(C16) to the Footboard Leg(C10,C11) with Half Round Nuts(D) and Hexagonal Nut(E). Cover the Cap(F) on the hole.


Use Phillips Head Screwdrive to assemble Connect Panel(C17) to the Connect Panel(C16) with Screw(I).Dowel with Glue(W).



Step 8: Use Phillips Head Screwdriver to assemble Support Panel(C13,C15) to the Support Panel(C14) with Cam Lock(A).Dowel with Glue(W).




Step 9: Use Phillips Head Screwdriver to assemble Support Panel(C14) Connect Panel(C15) to the Side Rail(C11,C12) with Cam Lock(A).Dowel with Glue(W).




Step 10: Use Wrench (G) to ssemble the Side Rail(C11,C12) to the Headboard Front Panel(C18) with Half Round Nuts(D) and Hexagonal Nut(E). Cover the Cap(F) on the hole.

Use Phillips Head Screwdrive to assemble Support Panel(C13) to Headboard Front Panel(C8) with Cam Lock(A).




Step 11: Use Wrench (G) to ssemble the Side Rail(C11,C12) to the Footboard Leg(C18,C19) with Half Round Nuts(D) and Hexagonal Nut(E). Cover the Cap(F) on the hole.


Use Phillips Head Screwdrive to assemble Connect Panel(C15) to Foot Leg(C18,C19).wit Cam Lock(A).




Step 12: Use Phillips Head Screwdriver to assemble Bottom Rail(C20,C21) to Bottom Rail (C22) with Cam Lock (A).




Step 13: Insert The Bottom Rail to the bed inside bottom than insert the Bottom Panel(C23) on the Bottom Rail.




Step 14: Use Hex Key(P)to assemble the Lifting Handle(C32)to the Slat(C33) with Bolt(L).



Step 15:
Use Hex Key(Q)to assemble the Gas(C30,C31)to the Siderail(C11,C12)with Bolt(M).




Step 16:
Use Hex Key(Q)and Wrench(G)to assemble the Gas(C31,C32)to the Slat(C33)with Bolt (N)and Hexagonal Nuts(E).




SAFETY CAUTION WARNING

Please always lock the safety lock mechanism while the bed base is in lifting position.
Unlock it before you want to put the bed base back into normal position.




UNLOCK POSITION




LOCK POSITION


Step 17: (C28) with Cam Lock(A),assemble Drawer Back Panel(C27) to Drawer Side Panel(C24,C25) with Screw(I),assemble Drawer Back Panel(C27)and Drawer Side Panel(C24,C25) and Drawer Front Panel(C23) to the Drawer Bottom Panel(C28) with Cam Lock(A).




Step 18: Use Phillips Head Screwdriver to attach Wheel(S) to the Drawer Bottom Panel(C28) with Screw(H).



Step 19: Insert the Drawer to the Footboard.



Step 20: Use a Phillips Head Screwdriver to assemble Connector(K) to the Back Corner with Screw(J).
Connect the Led Wire(Z) and Led Botton(Z1)to the Power Adepter(V).




Assembly is complete

WARNING
PINCH HAZARD: BEWARE OF YOUR FINGERS WHEN LIFTING AND LOWERING THE MECHANISM

GAS LIFT BED

IMPORTANT NOTE:

PINCH HAZARD: BEWARE OF YOUR FINGERS WHEN LIFTING AND LOWERING THE MECHANISM



IMPORTANT NOTE:

Once the bed is positioned and the support legs are adjusted to touch floor , the slats can then be laid down and secured before putting on the mattress. **DO NOT** push or pull the bed if there is a need for re-positioning as this may result in broken support legs for the centre rail.

85176

General Product Care

To protect your furniture, we suggest the following:

- Avoid placing your furniture in direct sunlight.
- Do not place furniture directly under windows.
- Do not place sharp materials (knife, fork, etc.) directly onto your furniture as sharp material may scrape and damage the finish.
- Do not place material with high temperature directly onto the surface of your furniture.
- Clean up spills quickly. Water left over a prolonged period of time may cause damage. Alcohol, perfume, nail polishes, aftershave and some medication may cause severe finish damage if not cleaned immediately.
- Use a clean, soft, dry, lint free absorbent cloth to clean your furniture. Do not use any detergent as they may contain ingredients that may react and damage the finish.